

Opportunistic Frequency Stability Transfer for Extending the Coherence Time of GNSS Receiver Clocks


Kyle D. Wesson, Kenneth M. Pesyna, Jr., Jahshan A. Bhatti,
and Todd E. Humphreys

The University of Texas at Austin

ION GNSS 2010
Portland, OR
24 September 2010

The Problem


GNSS signals attenuate **30–50 dB** in indoor environments



GNSS receivers can't acquire or track indoors
with a $C/N_0 \approx 7$ dB-Hz

A Possible Solution

Coherently integrate long enough to recover signal power!



How long do we have to wait to acquire?

Rule-of-thumb from detection theory:

$$\text{SNR} = \frac{C}{N_0} \cdot T \geq 14 \text{ dB}$$



for fixed $P_d = 0.95$ and $P_{fa} = 0.001$

How long do we have to wait to acquire?

Rule-of-thumb from detection theory:

$$\text{SNR} = \frac{C}{N_0} \cdot T \geq 14 \text{ dB}$$

for fixed $P_d = 0.95$ and $P_{fa} = 0.001$



"Now's the time, the time is now" -Led Zeppelin



.01 s/s



0.1 s/s



10^{-5} s/s



10^{-6} s/s



10^{-9} s/s



10^{-12} s/s

What Are Our Options?

1. Carry an atomic clock →
2. Use chip-scale atomic clocks in RX
3. Use small, portable OCXOs



leapsecond.com/pages/atomic-bill

What Are Our Options?

1. Carry an atomic clock →
2. Use chip-scale atomic clocks in RX
3. Use small, portable OCXOs
4. **Pull a clock out of thin air**



leapsecond.com/pages/atomic-bill

What Are Our Options?

4. Pull a clock out of thin air



leapsecond.com/pages/atomic-bill

Oscillator Model

Oscillator generates **sinusoidal output** voltage:

$$v(t) = \cos(2\pi\nu_0 t + \phi(t))$$

where ν_0 is nominal frequency and $\phi(t)$ is time-varying phase.

Ideal oscillators are deterministic:

$$V(t) = \cos(2\pi\nu_0 t) \quad (\text{no offset})$$


$$V(t) = \cos(2\pi\nu_0 t + \Phi) \quad (\text{constant offset})$$

Oscillator Comparison Experiment

- ▶ Estimated phase using receiver driven by TCXO and OCXO
- ▶ Removed deterministic component due to satellite orbit leaving:
 1. ionospheric errors
 2. ephemeris errors
 3. timing errors in range computation
 4. receiver position errors
- ▶ Linear fit removes 2, 3, and 4
- ▶ Remaining phase represents phase history of the driving oscillator


TCXO Referenced Carrier Phase Observable

$$\lambda\phi(t) = r(t) + c[\delta t_{\mathbf{R}}(t) - \delta t_S(t)] + \lambda(\gamma_0 - \psi_0) + \epsilon_{\text{atmo}}(t) + \lambda n_\phi$$




TCXO & OCXO Referenced Carrier Phase Observables

$$\lambda\phi(t) = r(t) + c[\delta t_R(t) - \delta t_S(t)] + \lambda(\gamma_0 - \psi_0) + \epsilon_{\text{atmo}}(t) + \lambda n_\phi$$




OCXO Referenced Carrier Phase Observable




$$\lambda\phi(t) = r(t) + c[\delta t_{\mathbf{R}}(t) - \delta t_{\mathbf{S}}(t)] + \lambda(\gamma_0 - \psi_0) + \epsilon_{\text{atmo}}(t) + \lambda n_{\phi}$$



TCXO vs. OCXO




TCXO vs. OCXO




Frequency Stability Transfer Model

Rotate GNSS phase by the change in aiding signal's phase relative to local oscillator over j th intermediate accumulation interval:

$$\Delta\phi = \left(\frac{f_{\text{GNSS}}}{f_{\text{AID}}} \right) \cdot (\phi_{\text{AID}}[n_j] - \phi_{\text{AID}}[n_{j-1}] + n_\phi)$$




Frequency Stability Transfer Phasor “Fix-Up”



Synthetic Oscillator Phase History

Create synthetic oscillator via single differencing: $\Delta\hat{\phi}_{\text{AID}} = \phi_{\text{PRN 22}}$



Ambient Stable Signals

1. WWVB

- ▶ broadcast from NIST in Colorado
- ▶ designed to synchronize time
- ▶ only stable locally due to ground wave propagation
- ▶ 60 kHz broadcast


2. High-Definition TV (HDTV)

- ▶ available in major metropolitan areas
- ▶ signal is designed to penetrate buildings
- ▶ approx. 700 MHz broadcast

3. Cellular Code Division Multiple Access (CDMA)


Why CDMA?

- ▶ CDMA is similar to GPS from receiver standpoint
- ▶ Widely available in U.S.
- ▶ Base station clocks very stable and synched to GPS
- ▶ UHF Band 1930–1990 MHz (tends to attenuate phase noise)
- ▶ Dataless pilot channel allows direct computation of phase




Verizon Wireless Coverage Map, 2010


CDMA Laboratory Setup




Frequency Stability Transfer Block Diagram




Oscillator Coherence




Oscillator Coherence



Oscillator Coherence




Oscillator Coherence



Coherence and SNR Relation

$$\text{SNR}(t) = \langle C_{\text{coh}}^2(t) \rangle \cdot t \cdot (C/N_0) \quad \text{for fixed } C/N_0$$



Conclusion

Indoor GNSS tracking and acquisition is possible with **commercial GNSS receivers** using **stable signals of opportunity** if you're willing to hold still for a few seconds!