

Copyright  
by  
Christopher Ainslie van der Hoeven  
2013

**The Dissertation Committee for Christopher Ainslie van der Hoeven Certifies that  
this is the approved version of the following dissertation:**

**Generation of High Fidelity Covariance Data Sets for the Natural  
Molybdenum Isotopes Including a Series of Molybdenum Sensitive  
Critical Experiment Designs**

**Committee:**

---

Erich Schneider, Supervisor

---

Sheldon Landsberger

---

Steven Biegalski

---

Mark Deinert

---

Luiz Leal

**Generation of High Fidelity Covariance Data Sets for the Natural  
Molybdenum Isotopes Including a Series of Molybdenum Sensitive  
Critical Experiment Designs**

**by**

**Christopher Ainslie van der Hoeven, B.S., M.S.E.,**

**Dissertation**

Presented to the Faculty of the Graduate School of  
The University of Texas at Austin  
in Partial Fulfillment  
of the Requirements  
for the Degree of

**Doctor of Philosophy**

**The University of Texas at Austin**

**August 2013**

## **Dedication**

To Amy.



## **Acknowledgements**

This work would not have been possible without the help and support of many people. I would especially like to thank Erich Schneider, my advisor, for all of his guidance and mentorship throughout my graduate career. I would also like to thank Luiz Leal, my mentor while working at Oak Ridge National Laboratory, for taking the time to help me through the learning process needed to complete this research project.

I would like to thank my parents for their never ending supply of support and encouragement.

Finally, I thank my loving wife Amy, who has always been there for me as I've worked towards this goal.

# **Generation of High Fidelity Covariance Data Sets for the Natural Molybdenum Isotopes Including a Series of Molybdenum Sensitive Critical Experiment Designs**

Christopher Ainslie van der Hoeven, Ph.D.

The University of Texas at Austin, 2013

Supervisor: Erich A. Schneider

Quantification of uncertainty in computational models of nuclear systems is required for assessing margins of safety for both design and operation of those systems. The largest source of uncertainty in computational models of nuclear systems derives from the nuclear cross section data used for modeling. There are two parts to cross section uncertainty data: the relative uncertainty in the cross section at a particular energy, and how that uncertainty is correlated with the uncertainty at all other energies. This cross section uncertainty and uncertainty correlation is compiled as covariance data. High fidelity covariance data exists for a few key isotopes, however the covariance data available for many structural materials is considered low fidelity, and is derived primarily from integral measurements with little meaningful correlation between energy regions. Low fidelity covariance data is acceptable for materials to which the operating characteristics of the modeled nuclear system are insensitive. However, in some cases, nuclear systems can be sensitive to isotopes with only low fidelity covariance data. Such is the case for the new U(19.5%)-10Moly foil fuel form to be produced at the Y-12 National Security Complex for use in research and test reactors. This fuel is ten weight percent molybdenum, the isotopes of which have only low fidelity covariance data.

Improvements to the molybdenum isotope covariance data would benefit the modeling of systems using the new fuel form. This dissertation provides a framework for deriving high fidelity molybdenum isotope covariance data from a set of elemental molybdenum experimental cross section results. Additionally, a series of critical experiments featuring the new Y-12 fuel form was designed to address deficiencies in the critical experiment library with respect to molybdenum isotopes. Along with existing molybdenum sensitive critical experiments, these proposed experiments were used as a basis to compare the performance of the new high fidelity molybdenum covariance data set with the existing low fidelity covariance data set using the nuclear modeling code SCALE. The use of the high fidelity covariance data was found to result in reduced overall bias, reduced bias due to the molybdenum isotopes, and improved goodness-of-fit of computational results to experimental results.

## Table of Contents

List of Tables .....	xi
List of Figures .....	xiii
Chapter 1: Introduction .....	1
Chapter 2: Literature Review and Theory .....	5
Nuclear Data .....	5
Interaction Cross Section Data.....	5
Cross Section Covariance Data.....	12
Current Molybdenum Cross Section and Covariance Data .....	18
Existing Molybdenum Sensitive Critical Experiments.....	26
Sensitivity and Uncertainty Analysis.....	32
SCALE: TSUNAMI.....	32
SCALE: TSURFER .....	35
Chapter 3: Critical Experiment Designs .....	38
Initial Scoping Studies and Existing Critical Experiments.....	41
ORNL Fast Burst Reactor Critical Experiments.....	45
Proposed Critical Experiment Designs .....	65
Fast Spectra Experiment Designs .....	65
Fast Bare Critical Experiment.....	65
Fast Reflected Critical Experiment.....	67
Thermal Spectra Experiment Designs .....	76
Thermal Standard Molybdenum Critical Experiment.....	77
Thermal Maximum Molybdenum Critical Experiment .....	81
Concluding Remarks.....	90
Chapter 4: Covariance Data Generation .....	92
File 32 Format Covariance Data .....	92
RPI Experimental Data .....	92
Analysis with SAMMY .....	94

File 33 Format Covariance Data .....	100
Integral Measurement Uncertainty .....	101
Dispersion Method.....	102
Empire-KALMAN High Energy Covariances.....	103
Concluding Remarks.....	107
Analytical Comparison of Low Fidelity and High Fidelity Molybdenum Covariance Data.....	109
Cross-section and Covariance Processing .....	110
Goodness-of-Fit and Bias Comparison.....	112
Cross Section Adjustment Comparisons.....	122
Concluding Remarks.....	132
Chapter 5: Conclusions .....	133
Appendices.....	136
Appendix A: Experimental Plans.....	137
Appendix B: MCNP Materials and Inputs.....	149
Appendix C: File 32 and File 33 Covariance Plots.....	160
<sup>92</sup> Mo .....	160
Total Covariance Data .....	161
Elastic Scattering Covariance Data.....	163
Capture Covariance Data .....	165
<sup>94</sup> Mo .....	167
Total Covariance Data .....	168
Elastic Scattering Covariance Data.....	170
Capture Covariance Data .....	172
<sup>95</sup> Mo .....	174
Total Covariance Data .....	175
Elastic Scattering Covariance Data.....	177
Capture Covariance Data .....	179
<sup>96</sup> Mo .....	181

Total Covariance Data .....	182
Elastic Scattering Covariance Data.....	184
Capture Covariance Data .....	186
<sup>97</sup> Mo .....	188
Total Covariance Data .....	189
Elastic Scattering Covariance Data.....	191
Capture Covariance Data .....	193
<sup>98</sup> Mo .....	195
Total Covariance Data .....	196
Elastic Scattering Covariance Data.....	198
Capture Covariance Data .....	200
<sup>100</sup> Mo .....	202
Total Covariance Data .....	203
Elastic Scattering Covariance Data.....	205
Capture Covariance Data .....	207
Appendix D: ENDF Listing for JENDL 4.0 with RPI Resonance Parameters and High Fidelity Covariance Data .....	209
References.....	308
Vita .....	314

## List of Tables

Table 1) $^{92}\text{Mo}$ Energy Region Limits .....	19
Table 2) $^{94}\text{Mo}$ Energy Region Limits .....	20
Table 3) $^{95}\text{Mo}$ Energy Region Limits .....	20
Table 4) $^{96}\text{Mo}$ Energy Region Limits .....	20
Table 5) $^{97}\text{Mo}$ Energy Region Limits .....	20
Table 6) $^{98}\text{Mo}$ Energy Region Limits .....	21
Table 7) $^{100}\text{Mo}$ Energy Region Limits .....	21
Table 8) Comparison of number of resonances for ENDF, JEFF, and JENDL libraries .....	22
Table 9) $^{95}\text{Mo}$ resonances sorted by quantum numbers for ENDF, JEFF, and JENDL .....	22
Table 10) ICSBEP Molybdenum Sensitive Critical Experiments [20] .....	31
Table 11) Multiplication Factors for Infinite Metal.....	41
Table 12) Multiplication Factors for Infinite Square Lattice.....	42
Table 13) FBR Crit. Experiment #1, #2, and #3 .....	47
Table 14) FBR Crit. Experiment #4 and #5 .....	51
Table 15) Differences in Modeled Fast Critical Experiment $k_{\text{eff}}$ Due to Cross Section Library.....	75
Table 16) Integral Molybdenum Isotope Sensitivity for Standard and Maximum Molybdenum Critical Experiment Designs .....	89
Table 17) Differences in Modeled Thermal Critical Experiment $K_{\text{eff}}$ Due to Cross Section Library.....	89
Table 18) Molybdenum Experimental Details.....	93

Table 19) Elemental Metal Molybdenum Samples .....	94
Table 20) Integral Uncertainties for Natural Molybdenum Isotopes [37] .....	101
Table 21) $\chi^2$ for ENDF, JEFF, and JENDL .....	111
Table 22) TSURFER bias: ENDF/B-VII.1 cross-sections and low fidelity covariance data.....	113
Table 23) TSURFER bias: ENDF/B-VII.1 cross-sections and high fidelity covariance data.....	113
Table 24) TSURFER bias: RPI resonance parameters and low fidelity covariance data .....	113
Table 25) TSURFER bias: RPI resonance parameters and high fidelity covariance data.....	114
Table 27) Total Bias for Molybdenum Isotopes for Fast Reflected Critical Experiment .....	118
Table 28) Total Bias for Molybdenum Isotopes for Thermal Standard Critical Experiment.....	119
Table 29) Total Bias for Molybdenum Isotopes for Thermal Max Critical Experiment .....	120
Table 30) Goodness of Fit for Combinations of Cross-Section and Covariance Data .....	122



## List of Figures

Figure 1) Generalized cross-section regions .....	5
Figure 2) $^{238}\text{U}$ total cross section resolved resonance region .....	6
Figure 3) Channel interaction visualization [11] .....	10
Figure 4) Example Time-of-Flight System .....	13
Figure 5) $^{97}\text{Mo}$ 238-group library comparison (total cross section) .....	19
Figure 6) $^{97}\text{Mo}$ Low Fidelity Elastic Scattering Covariance Data .....	24
Figure 7) $^{97}\text{Mo}$ Low Fidelity Capture Covariance Data .....	24
Figure 8) $^{235}\text{U}$ High Fidelity Elastic Scattering Covariance Data .....	25
Figure 9) $^{235}\text{U}$ High Fidelity Capture Covariance Data .....	25
Figure 10) ORNL FBR Core Diagram .....	28
Figure 11) U-Mo cylindrical critical assembly experiment .....	29
Figure 12) General Flow Diagram for TSUNAMI .....	34
Figure 13) Comet Vertical Split Table Test Device .....	39
Figure 14) Proposed Experimental Set Up .....	40
Figure 15) Infinite Lattice of Cylindrical U(19.5%)-10Mo Fuel Elements .....	42
Figure 16) Spectra for Infinite Metal and Infinite Moderated Lattice of U-10Moly Fuel .....	43
Figure 17) Delta K/K vs. Fuel/Moderator Ratio .....	44
Figure 18) Spectra of three bare unmoderated FBR critical experiments .....	46
Figure 19) Total Sensitivity vs. Energy for Molybdenum Isotopes in ORNL FBR Crit. Experiment #1 .....	48
Figure 20) Flux Spectra for ORNL FBR Crit. Exps. #1, #4, and #5 .....	50

Figure 21) Total Sensitivity vs. Energy for Molybdenum Isotopes in ORNL FBR Crit. Experiment #4 .....	52
Figure 22) Total Sensitivity vs. Energy for Molybdenum Isotopes in ORNL FBR Crit. Experiment #5 .....	53
Figure 23) $^{92}\text{Mo}$ Cross Section Adjustments for Set 1, 1.2 Chi-squared .....	55
Figure 24) $^{98}\text{Mo}$ Cross Section Adjustments for Set 1, 1.2 Chi-squared .....	56
Figure 25) Molybdenum Elastic Scattering Cross Section Adjustments for Set 1, 1.2 Chi-squared .....	57
Figure 26) $^{235}\text{U}$ Cross Section Adjustments for Set 1, 1.2 Chi-squared .....	58
Figure 27) $^{238}\text{U}$ Cross Section Adjustments for Set 1, 1.2 Chi-squared .....	59
Figure 28) $^{98}\text{Mo}$ Cross Section Adjustments for Set 2, 1.2 Chi-squared .....	61
Figure 29) $^{92}\text{Mo}$ Cross Section Adjustments for Set 2, 1.2 Chi-squared .....	61
Figure 30) Molybdenum Elastic Scattering Cross Section Adjustments for Set 2, 1.2 Chi-squared .....	62
Figure 31) Molybdenum Capture Cross Section Adjustments for Set 2, 1.2 Chi- squared .....	63
Figure 32) $^{235}\text{U}$ Cross Section Adjustments for Set 2, 1.2 Chi-squared .....	64
Figure 33) $^{238}\text{U}$ Cross Section Adjustments for Set 2, 1.2 Chi-squared .....	64
Figure 34) Fast Bare Critical Experiment MCNP Model .....	66
Figure 35) Fast Bare Critical Experiment Spectra .....	67
Figure 36) Fast Reflected Critical Experiment MCNP Model .....	68
Figure 37) Fast Reflected Critical Experiment Spectra .....	69
Figure 38) $^{92}\text{Mo}$ Sensitivity for Fast Spectra Critical Experiment Designs.....	70
Figure 39) $^{94}\text{Mo}$ Sensitivity for Fast Spectra Critical Experiment Designs.....	70
Figure 40) $^{95}\text{Mo}$ Sensitivity for Fast Spectra Critical Experiment Designs.....	71

Figure 41) $^{96}\text{Mo}$ Sensitivity for Fast Spectra Critical Experiment Designs.....	71
Figure 42) $^{97}\text{Mo}$ Sensitivity for Fast Spectra Critical Experiment Designs.....	72
Figure 43) $^{98}\text{Mo}$ Sensitivity for Fast Spectra Critical Experiment Designs.....	72
Figure 44) $^{100}\text{Mo}$ Sensitivity for Fast Spectra Critical Experiment Designs .....	73
Figure 45) $^{235}\text{U}$ Sensitivity for Fast Spectra Critical Experiment Designs .....	74
Figure 46) $^{238}\text{U}$ Sensitivity for Fast Spectra Critical Experiment Designs .....	75
Figure 47) Calculated Spectra of Homogenized U-Moly Fuel and Lucite Moderator .....	78
Figure 48) Thermal Standard Molybdenum Critical Experiment MCNP Model ..	80
Figure 49) Thermal Standard Molybdenum Critical Experiment Spectra .....	81
Figure 50) Thermal Maximum Molybdenum Critical Experiment MCNP Model	82
Figure 51) Spectra for Standard and Maximum Molybdenum Thermal Critical Experiments .....	83
Figure 52) $^{92}\text{Mo}$ Sensitivity for Thermal Spectra Critical Experiment Designs....	84
Figure 53) $^{94}\text{Mo}$ Sensitivity for Thermal Spectra Critical Experiment Designs....	84
Figure 54) $^{95}\text{Mo}$ Sensitivity for Thermal Spectra Critical Experiment Designs....	85
Figure 55) $^{96}\text{Mo}$ Sensitivity for Thermal Spectra Critical Experiment Designs....	85
Figure 56) $^{97}\text{Mo}$ Sensitivity for Thermal Spectra Critical Experiment Designs....	86
Figure 57) $^{98}\text{Mo}$ Sensitivity for Thermal Spectra Critical Experiment Designs....	86
Figure 58) $^{100}\text{Mo}$ Sensitivity for Thermal Spectra Critical Experiment Designs ..	87
Figure 59) $^1\text{H}$ Sensitivity for Thermal Spectra Critical Experiment Designs.....	88
Figure 60) Calculated Spectra for Proposed Critical Experiment Designs.....	91
Figure 61) SAMMY fit to 2004 Natural Molybdenum Transmission Data .....	95
Figure 62) SAMMY fit to 1995 Natural Molybdenum Capture Data .....	95
Figure 63) ENDF/B-VII.1 $^{97}\text{Mo}$ Total Cross Section, 0-600 eV highlighted.....	97

Figure 64) $^{97}\text{Mo}$ Total Retroactive Resolve Resonance Covariance .....	99
Figure 65) $^{97}\text{Mo}$ Total Current ENDF/B-VII.1 Covariance.....	99
Figure 66) $^{97}\text{Mo}$ Total File 33 Covariance.....	106
Figure 67) $^{97}\text{Mo}$ Total Current ENDF/B-VII.1 Covariance.....	106
Figure 68) $^{97}\text{Mo}$ Total Cross Section CVDH Covariance Data .....	108
Figure 69) $^{97}\text{Mo}$ Total Cross Section LOFI Covariance Data .....	108
Figure 70) Absolute Bias Comparison across Experiment Designs and Nuclear Data Sets .....	115
Table 26) Total Bias for Molybdenum Isotopes for Fast Bare Critical Experiment Design .....	117
Figure 71) Molybdenum Isotope Bias Comparison across Nuclear Data Sets for Fast Bare Critical Experiment Design .....	117
Figure 72) Molybdenum Isotope Bias Comparison across Nuclear Data Sets for Fast Reflected Critical Experiment Design .....	118
Figure 73) Molybdenum Isotope Bias Comparison across Nuclear Data Sets for Thermal Standard Critical Experiment Design.....	119
Figure 74) Molybdenum Isotope Bias Comparison across Nuclear Data Sets for Thermal Max Critical Experiment Design.....	120
Figure 75) Total Molybdenum Bias.....	121
Figure 76) Cross Section Adjustment to Elastic Scattering of Molybdenum Isotopes for ENDF/B-VII.1 & LOFI Covariance.....	123
Figure 77) Cross Section Adjustment to Elastic Scattering of Molybdenum Isotopes for ENDF/B-VII.1 & CVDH Covariance .....	123
Figure 78) Cross Section Adjustment to Elastic Scattering of Molybdenum Isotopes for JENDL4.0 with RPI resonance parameters & LOFI Covariance.....	124

Figure 79) Cross Section Adjustment to Elastic Scattering of Molybdenum Isotopes for JENDL4.0 with RPI resonance parameters & CVDH Covariance	124
Figure 80) Cross Section Adjustment to Capture of Molybdenum Isotopes for ENDF/B-VII.1 & LOFI Covariance .....	125
Figure 81) Cross Section Adjustment to Capture of Molybdenum Isotopes for ENDF/B-VII.1 & CVDH Covariance.....	126
Figure 82) Cross Section Adjustment to Capture of Molybdenum Isotopes for JENDL4.0 with RPI resonance parameters & LOFI Covariance ...	126
Figure 83) Cross Section Adjustment to Capture of Molybdenum Isotopes for JENDL4.0 with RPI resonance parameters & CVDH Covariance.	127
Figure 84) Cross Section Adjustment to Hydrogen for Molybdenum Cross Sections from ENDF/B-VII.1 .....	128
Figure 85) Cross Section Adjustment to Hydrogen for Molybdenum Cross Sections from JENDL4.0 with RPI Resonance Parameters .....	128
Figure 86) Cross Section Adjustment to $^{238}\text{U}$ for Molybdenum Cross Sections from ENDF/B-VII.1 .....	129
Figure 87) Cross Section Adjustment to $^{238}\text{U}$ for Molybdenum Cross Sections from JENDL4.0 with RPI resonance parameters .....	130
Figure 88) Cross Section Adjustment to $^{235}\text{U}$ for Molybdenum Cross Sections from ENDF/B-VII.1 .....	131
Figure 89) Cross Section Adjustment to $^{235}\text{U}$ for Molybdenum Cross Sections from JENDL4.0 with RPI resonance parameters .....	131
Figure C.1) ENDF/B-VII.1 $^{92}\text{Mo}$ Total Cross Section, 0-600 eV highlighted ....	160
Figure C.2) $^{92}\text{Mo}$ Total File 32 Covariance .....	161
Figure C.3) $^{92}\text{Mo}$ Total File 33 Covariance .....	161

Figure C.4) $^{92}\text{Mo}$ CVDHCOV Total Covariance Data .....	162
Figure C.5) $^{92}\text{Mo}$ LOFI Total Covariance Data .....	162
Figure C.6) $^{92}\text{Mo}$ Elastic Scattering File 32 Covariance .....	163
Figure C.7) $^{92}\text{Mo}$ Elastic Scattering File 33 Covariance .....	163
Figure C.8) $^{92}\text{Mo}$ CVDHCOV Elastic Scattering Covariance Data .....	164
Figure C.9) $^{92}\text{Mo}$ LOFI Elastic Scattering Covariance Data .....	164
Figure C.10) $^{92}\text{Mo}$ Capture File 32 Covariance .....	165
Figure C.11) $^{92}\text{Mo}$ Capture File 33 Covariance .....	165
Figure C.12) $^{92}\text{Mo}$ CVDHCOV Capture Covariance Data .....	166
Figure C.13) $^{92}\text{Mo}$ LOFI Capture Covariance Data .....	166
Figure C.14) ENDF/B-VII.1 $^{94}\text{Mo}$ Total Cross Section, 0-600 eV highlighted	167
Figure C.15) ENDF/B-VII.1 $^{94}\text{Mo}$ Total Cross Section, 0-2000 eV highlighted	167
Figure C.16) $^{94}\text{Mo}$ Total File 32 Covariance Data .....	168
Figure C.17) $^{94}\text{Mo}$ Total File 33 Covariance Data .....	168
Figure C.18) $^{94}\text{Mo}$ CVDHCOV Total Covariance Data .....	169
Figure C.19) $^{94}\text{Mo}$ LOFI Total Covariance Data .....	169
Figure C.20) $^{94}\text{Mo}$ Elastic Scattering File 32 Covariance Data .....	170
Figure C.21) $^{94}\text{Mo}$ Elastic Scattering File 33 Covariance Data .....	170
Figure C.22) $^{94}\text{Mo}$ CVDHCOV Elastic Scattering Covariance Data .....	171
Figure C.23) $^{94}\text{Mo}$ LOFI Elastic Scattering Covariance Data .....	171
Figure C.24) $^{94}\text{Mo}$ Capture File 32 Covariance Data .....	172
Figure C.25) $^{94}\text{Mo}$ Capture File 33 Covariance Data .....	172
Figure C.26) $^{94}\text{Mo}$ CVDHCOV Capture Covariance Data .....	173
Figure C.27) $^{94}\text{Mo}$ LOFI Capture Covariance Data .....	173
Figure C.28) ENDF/B-VII.1 $^{95}\text{Mo}$ Total Cross Section, 0-600 eV highlighted ..	174

Figure C.29) $^{95}\text{Mo}$ Total File 32 Covariance Data .....	175
Figure C.30) $^{95}\text{Mo}$ Total File 33 Covariance Data .....	175
Figure C.31) $^{95}\text{Mo}$ CVDHCOV Total Covariance Data .....	176
Figure C.32) $^{95}\text{Mo}$ LOFI Total Covariance Data .....	176
Figure C.33) $^{95}\text{Mo}$ Elastic Scattering File 32 Covariance Data .....	177
Figure C.34) $^{95}\text{Mo}$ Elastic Scattering File 33 Covariance Data .....	177
Figure C.35) $^{95}\text{Mo}$ CVDHCOV Elastic Scattering Covariance Data .....	178
Figure C.36) $^{95}\text{Mo}$ LOFI Elastic Scattering Covariance Data .....	178
Figure C.37) $^{95}\text{Mo}$ Capture File 32 Covariance Data .....	179
Figure C.38) $^{95}\text{Mo}$ Capture File 33 Covariance Data .....	179
Figure C.39) $^{95}\text{Mo}$ CVDHCOV Capture Covariance Data .....	180
Figure C.40) $^{95}\text{Mo}$ LOFI Capture Covariance Data .....	180
Figure C.41) ENDF/B-VII.1 $^{96}\text{Mo}$ Total Cross Section, 0-600 eV highlighted ..	181
Figure C.42) $^{96}\text{Mo}$ Total File 32 Covariance Data .....	182
Figure C.43) $^{96}\text{Mo}$ Total File 33 Covariance Data .....	182
Figure C.44) $^{96}\text{Mo}$ CVDHCOV Total Covariance Data .....	183
Figure C.45) $^{96}\text{Mo}$ LOFI Total Covariance Data .....	183
Figure C.46) $^{96}\text{Mo}$ Elastic Scattering File 32 Covariance Data .....	184
Figure C.47) $^{96}\text{Mo}$ Elastic Scattering File 33 Covariance Data .....	184
Figure C.48) $^{96}\text{Mo}$ CVDHCOV Elastic Scattering Covariance Data .....	185
Figure C.49) $^{96}\text{Mo}$ LOFI Elastic Scattering Covariance Data .....	185
Figure C.50) $^{96}\text{Mo}$ Capture File 32 Covariance Data .....	186
Figure C.51) $^{96}\text{Mo}$ Capture File 33 Covariance Data .....	186
Figure C.52) $^{96}\text{Mo}$ CVDHCOV Capture Covariance Data .....	187
Figure C.53) $^{96}\text{Mo}$ LOFI Capture Covariance Data .....	187

Figure C.54) ENDF/B-VII.1 $^{97}\text{Mo}$ Total Cross Section, 0-600 eV highlighted ..	188
Figure C.55) $^{97}\text{Mo}$ Total File 32 Covariance Data .....	189
Figure C.56) $^{97}\text{Mo}$ Total File 33 Covariance Data .....	189
Figure C.57) $^{97}\text{Mo}$ CVDHCOV Total Covariance Data .....	190
Figure C.58) $^{97}\text{Mo}$ LOFI Total Covariance Data .....	190
Figure C.59) $^{97}\text{Mo}$ Elastic Scattering File 32 Covariance Data .....	191
Figure C.60) $^{97}\text{Mo}$ Elastic Scattering File 33 Covariance Data .....	191
Figure C.61) $^{97}\text{Mo}$ CVDHCOV Elastic Scattering Covariance Data .....	192
Figure C.62) $^{97}\text{Mo}$ LOFI Elastic Scattering Covariance Data .....	192
Figure C.63) $^{97}\text{Mo}$ Capture File 32 Covariance Data .....	193
Figure C.64) $^{97}\text{Mo}$ Capture File 33 Covariance Data .....	193
Figure C.65) $^{97}\text{Mo}$ CVDHCOV Capture Covariance Data .....	194
Figure C.66) $^{97}\text{Mo}$ LOFI Capture Covariance Data .....	194
Figure C.67) ENDF/B-VII.1 $^{98}\text{Mo}$ Total Cross Section, 0-600 eV highlighted ..	195
Figure C.68) $^{98}\text{Mo}$ Total File 32 Covariance Data .....	196
Figure C.69) $^{98}\text{Mo}$ Total File 33 Covariance Data .....	196
Figure C.70) $^{98}\text{Mo}$ CVDHCOV Total Covariance Data .....	197
Figure C.71) $^{98}\text{Mo}$ LOFI Total Covariance Data .....	197
Figure C.72) $^{98}\text{Mo}$ Elastic Scattering File 32 Covariance Data .....	198
Figure C.73) $^{98}\text{Mo}$ Elastic Scattering File 33 Covariance Data .....	198
Figure C.74) $^{98}\text{Mo}$ CVDHCOV Elastic Scattering Covariance Data .....	199
Figure C.75) $^{98}\text{Mo}$ LOFI Elastic Scattering Covariance Data .....	199
Figure C.76) $^{98}\text{Mo}$ Capture File 32 Covariance Data .....	200
Figure C.77) $^{98}\text{Mo}$ Capture File 33 Covariance Data .....	200
Figure C.78) $^{98}\text{Mo}$ CVDHCOV Capture Covariance Data .....	201



Figure C.79) $^{98}\text{Mo}$ LOFI Capture Covariance Data.....	201
Figure C.80) ENDF/B-VII.1 $^{100}\text{Mo}$ Total Cross Section, 0-600 eV highlighted.	202
Figure C.81) $^{100}\text{Mo}$ Total File 32 Covariance Data .....	203
Figure C.82) $^{100}\text{Mo}$ Total File 33 Covariance Data .....	203
Figure C.83) $^{100}\text{Mo}$ CVDHCOV Total Covariance Data.....	204
Figure C.84) $^{100}\text{Mo}$ LOFI Total Covariance Data .....	204
Figure C.85) $^{100}\text{Mo}$ Elastic Scattering File 32 Covariance Data .....	205
Figure C.86) $^{100}\text{Mo}$ Elastic Scattering File 33 Covariance Data .....	205
Figure C.87) $^{100}\text{Mo}$ CVDHCOV Elastic Scattering Covariance Data .....	206
Figure C.88) $^{100}\text{Mo}$ LOFI Elastic Scattering Covariance Data.....	206
Figure C.89) $^{100}\text{Mo}$ Capture File 32 Covariance Data .....	207
Figure C.90) $^{100}\text{Mo}$ Capture File 33 Covariance Data .....	207
Figure C.91) $^{100}\text{Mo}$ CVDHCOV Capture Covariance Data .....	208
Figure C.92) $^{100}\text{Mo}$ LOFI Capture Covariance Data .....	208

## Chapter 1: Introduction

As advanced nuclear fuels are being developed, increasing attention is being paid to assessing uncertainty in the physics of nuclear systems and associated sensitivities in both system design and operation. Characteristics of nuclear systems such as multiplication factor, flux, and dose levels are often sensitive to variables such as system dimensions and operating environment, which may have some level of associated uncertainty. However, the greatest source of uncertainty in most real world nuclear systems arises from the evaluated nuclear data used for reactor physics modeling [1].

The use of accurate cross-section data is critical to modeling nuclear systems. Cross-section data is typically derived from a combination of experimental measurements and particle interaction models. Both of these sources inevitably contain some uncertainty. Uncertainty in experimental data arises from systematic error or bias as well as variables in the experimental systems that are difficult or impossible for the experimenter to control. Uncertainty in interaction models derives from the differences between the model's approximations and the physical reality of the particle interaction.

To be taken into account, this uncertainty data must be assessed and compiled in evaluated nuclear data files in a format that can be used in analysis code packages. A suitable format for this uncertainty data, referred to as covariance data and including both the relative uncertainty in the cross section at a given energy and the how that uncertainty is correlated with uncertainty at other energies, has been included in the last two generations of ENDF [2][3][4]. High fidelity covariance data has been produced for key isotopes such as  $^{235}\text{U}$ ,  $^{238}\text{U}$ ,  $^{239}\text{Pu}$ , and  $^1\text{H}$  [5]. However, the majority of fission product isotopes and isotopes found in structural reactor components either lack covariance data

entirely or has low fidelity data only [6]. This can be problematic when isotopes lacking high fidelity covariance data comprise significant fractions of fuel material, such as is the case for the low enriched U-10Moly fuel form developed at the Y-12 National Security Complex.

In conjunction with the Reduced Enrichment for Research and Test Reactors (RERTR) program of the DOE, Y-12 has developed a monolithic uranium-molybdenum foil fuel form, which will first be used in the Advanced Test Reactor at Idaho National Laboratory [7][8]. This fuel form is advantageous for non-proliferation reasons as at 19.5%  $^{235}\text{U}$  it is low-enriched while maintaining the uranium density of high enriched fuels which it will be replacing. The ten weight percent molybdenum provides structural stability to the fuel as well as helping to prevent swelling due to irradiation. But there is currently no high fidelity covariance data for the molybdenum isotopes, only low-fidelity covariance data derived from integral measurements. But if molybdenum makes up a substantial fraction of the fuel material itself, higher quality uncertainty data for molybdenum cross-section data is desired.

Once a new cross section or covariance evaluation has been completed, the next step is to validate the new data. One of the primary means of doing so is through the use of critical benchmark experiments. Critical benchmark experiments are used to determine critical parameters, such as mass and geometry specifications, for combinations of fuel, moderator, reflector, and other structural elements. At their most simple, a critical benchmark experiment might take the form of a bare sphere or cylinder of uranium metal. At the other end of the spectrum, complex arrays of moderated and reflected fuel elements could form a benchmark experiment. Critical benchmark experiments seek to provide a means of mimicking the operating characteristics of real world nuclear systems at the lab level. As such, they are performed at various nuclear

critical facilities throughout the world. The results of critical benchmarks are most often used in criticality safety studies to validate computational methods of establishing minimum safe subcritical margins for operations with fissile materials. Additionally, critical benchmarks can also be used in validation of nuclear cross section data, as computational integral system parameters such as  $k_{\text{eff}}$  derive ultimately from the underlying nuclear cross section data. However, in order for critical benchmarks to serve their purpose with regards to real world nuclear systems, they must have a degree of similarity to the real world system in terms of shared cross section data and neutron spectra. There is currently a lack of critical experiments exhibiting this degree of similarity to the new U-Moly fuel form previously discussed, particularly in regards to molybdenum serving as an integral constituent of the fuel, and to the system having a thermalized spectrum as in the Advanced Test Reactor.

A key goal of this research project is to provide a new set of high fidelity covariance data for the naturally occurring molybdenum isotopes utilizing a newly completed experimental evaluation of molybdenum cross-section data by Rensselaer Polytechnic Institute and the retroactive approach of the SAMMY code package. The experimental data provided by RPI is for an elemental molybdenum sample, from which isotopic high fidelity covariance data will be generated. Deriving isotopic covariance data from an elemental sample has not previously been attempted, this work should illustrate a new potential capability of the SAMMY code package. The improved covariance data produced will make possible more accurate modeling of nuclear systems containing molybdenum; in particular sensitivity and uncertainty studies of such systems will benefit. The final goal of this portion of the project would see the new set of molybdenum covariance data distributed in an ENDF nuclear data release.

Additionally, a series of critical experiments will be designed, featuring a new U(19.5%)-10Mo fuel form, which will address deficiencies in the current critical experiment database with respect to the molybdenum isotopes. The design of this series of experiments will be based on prior critical experiments, and will seek to characterize the effects of molybdenum isotope cross section data throughout the energy region. The final goal of this portion of the project would see the new series of critical experiments submitted for eventual completion at the National Criticality Experiments Research Center.

The remainder of this document is organized as follows: chapter 2 provides a literature review and theoretical overview, chapter 3 details existing molybdenum sensitive critical experiments and a set of proposed benchmark critical experiments to utilize the U(19.5%)-10Mo fuel, chapter 4 details the method used to generate high fidelity covariance data for the molybdenum isotopes, chapter 5 compares uncertainty studies of the proposed critical experiment designs using the existing low fidelity molybdenum covariance data and the newly generated high fidelity covariance data, and finally chapter 6 presents conclusions to this work.

## Chapter 2: Literature Review and Theory

### NUCLEAR DATA

#### Interaction Cross Section Data

Nuclear interaction cross section data is fundamental to all nuclear engineering and design. This data describes the probability of interactions occurring between the nuclei of atoms and neutrons incident on those nuclei, in terms of the relative energy between the nuclei and neutrons.

Cross section data is typically derived from a combination of experimental measurements and interaction models.




Figure 1) Generalized cross-section regions

Nuclear cross-section data is customarily organized into general regions based on the behavior of the cross-section in those regions, i.e. thermal, resolved resonance, unresolved resonance, and high energy regions, as shown above in figure 1.

Of particular interest to this work is the resolved resonance region. Within this energy domain the cross-section can vary dramatically with respect to incident neutron energy. These sudden spikes in the cross-section are due to the formation of a relatively stable compound nucleus of the target nucleus and incident neutron of a specific energy. A real world example of the  $^{238}\text{U}$  total cross section is given below in figure 2.




Figure 2)  $^{238}\text{U}$  total cross section resolved resonance region

Such rapidly varying cross-sections would be difficult and unwieldy to describe adequately with point-wise data. R-matrix theory was developed to address the need for a compact and accurate means of describing the resolved resonance region [9].

While R-matrix theory is a complicated generalized interaction theory, a summary will be provided here. A simplified case neglecting spin dependence will be used, which will condense the mathematics considerably while containing the essential elements of the theory. R-matrix theory treats the interior potential of a nuclear interaction as a black box; therefore the wave function behavior of the compound nucleus cannot be calculated directly from Schrödinger's equation. The following derivation is taken from reference [10]. The inner wave function of the angular momentum is expanded in a linear combination of the eigenfunctions of the energy levels of the compound nucleus:

$$\phi_l(E, r) = \sum_{\lambda} A_{l\lambda} \phi_l(E_{\lambda}, r) \quad (1)$$

Where  $\phi_l(E, r)$  is the inner wave function at any energy  $E$ , and  $\phi_l(E_{\lambda}, r)$  is the eigenfunction at the energy eigenvalue  $E_{\lambda}$ . Both  $\phi_l(E, r)$  and  $\phi_l(E_{\lambda}, r)$  are solutions of the radial Schrödinger's equations in the inner nucleus region given by

$$\left\{ \frac{d^2}{dr^2} + \frac{2m}{\hbar^2} \left[ E - V(r) - \frac{l(l+1)\hbar^2}{2mr^2} \right] \right\} \phi_l(E, r) = 0 \quad (2)$$

And

$$\left\{ \frac{d^2}{dr^2} + \frac{2m}{\hbar^2} \left[ E_{\lambda} - V(r) - \frac{l(l+1)\hbar^2}{2mr^2} \right] \right\} \phi_l(E_{\lambda}, r) = 0 \quad (3)$$

The above expressions are required to be finite at  $r = 0$ , therefore both functions vanish at that point, providing one boundary condition. The second boundary condition is provided by the requirement that the logarithmic derivative of the eigenfunction at the surface of the nucleus, defined as  $r=a$ , must be constant:



$$\left[ \frac{d\phi_l(E_\lambda, r)}{dr} \right]_{r=a} = a^{-1} B_l \phi_l(E_\lambda, a) \quad (4)$$

$B_l$  is an arbitrary boundary constant. Additionally, as eigenfunctions of a real Hamiltonian, the functions  $\phi_l(E_\lambda, r)$  are orthogonal. Assuming they are also normalized gives

$$\int_0^a \phi_l(E_\lambda, r) \phi_l(E_{\lambda'}, r) dr = \delta_{\lambda\lambda'} \quad (5)$$

Using equation 1 and the above orthogonality condition a solution for the coefficients  $A_{l\lambda}$  can be found

$$A_{l\lambda} = \int_0^a \phi_l(E_\lambda, r) \phi_l(E_{\lambda'}, r) dr \quad (6)$$

Solving the above requires multiplying equations 2 and 3 by  $\phi_l(E_\lambda, r)$  and  $\phi(E_\lambda, r)$  respectively, subtracting, and then integrating from 0 to  $a$ , resulting in

$$A_{l\lambda} = \frac{\hbar^2}{2ma} (E_\lambda - E)^{-1} \left[ \phi_l(E_\lambda, r) \frac{d\phi_l(E, r)}{dr} - \phi_l(E, r) \frac{d\phi_l(E_\lambda, r)}{dr} \right]_{r=a} \quad (7)$$

Inserting the above coefficient values into equation 1 at the nuclear surface, and using the derivative boundary condition results in the following form for the wave function:

$$\phi_l(E, a) = \frac{\hbar^2}{2ma} \sum_\lambda \left[ \frac{\phi_l(E_\lambda, a) \phi_l(E_\lambda, a)}{E_\lambda - E} \right] \left[ r \frac{d\phi_l(E, a)}{dr} - B_l \phi_l(E, r) \right]_{r=a} \quad (8)$$

Through equation 8 the value of the wave function in the inner region is related to the value of its derivative at the surface. The R-matrix can then be defined as:

$$R_l = \frac{\hbar^2}{2ma} \sum_{\lambda} \left[ \frac{\phi_l(E_{\lambda}, a) \phi_l(E_{\lambda}, a)}{E_{\lambda} - E} \right] \quad (9)$$

Or more compactly as:

$$R_l = \sum_{\lambda} \frac{\gamma_{\lambda l} \gamma_{\lambda l}}{E_{\lambda} - E} \quad (10)$$

Where  $\gamma_{\lambda l}$  is the reduced width amplitude for the level  $\lambda$  and angular momentum  $l$ , and is defined by

$$\gamma_{\lambda l} = \sqrt{\frac{\hbar^2}{2ma}} \phi_l(E_{\lambda}, a) \quad (11)$$

Therefore the reduced width amplitude depends on the wave function value at the nuclear surface, but not within the nucleus interior.  $E_{\lambda}$  and  $\gamma_{\lambda l}$ , the resonance energy and width respectively, are the unknown parameters of the R-matrix, values for which can be found by fitting to experimental cross-section data. The SAMMY R-matrix code can be used to fit experimentally measured cross-section data to  $E_{\lambda}$  and  $\gamma_{\lambda l}$  values utilizing a generalized least-squares approach.

Equation 10 above relies on several simplifications, including neglecting the neutron-nucleus spin dependence and the several possible reaction processes which can occur. Generalizing equation 10 requires inclusion of these factors through the concept of “channels,” each possible pair of nucleus and particle and the spin of such a pair is designated by its own channel. The initial particle-nucleus pair is referred to as the entrance channel ( $c$ ), while the state of the final particle-nucleus pair is the exit channel ( $c'$ ).




Figure 3) Channel interaction visualization [11]

The generalized R-matrix is given by:

$$R_{cc'} = \sum_{\lambda} \frac{\gamma_{\lambda c} \gamma_{\lambda c'}}{E_{\lambda} - E} \quad (12)$$

The generalized reduced width amplitude is given by:

$$\gamma_{\lambda c} = \sqrt{\frac{\hbar^2}{2m_c a_c}} \phi_l(E_{\lambda}, a_c) \quad (13)$$

It is not possible to express interaction cross-sections using solely the R-matrix. Doing so requires a means of relating the R-matrix to the chosen cross-section formalism through the collision matrix, also known as the U-matrix. The derivation of this

relationship of R-matrix to U-matrix to cross-section formalism is not required for this work; however its final matrix form will be given here:

$$U = \rho^{1/2} \phi_{out}^{-1} [I - R(L - B)]^{-1} [I - R(\bar{L} - B)] \phi_{inc} \rho^{-1/2} \quad (14)$$

where  $U$  is the collision matrix, the matrix elements of  $\rho^{1/2}$  are given by  $(k_c a_c)^{1/2}$  for the interaction channel and  $k_c$  is the wave number of the incident neutron,  $\phi_{inc}$  and  $\phi_{out}$  are the incoming and outgoing wave form for the incident and resultant free particles of the interaction channels,  $I$  is the identity matrix,  $R$  is the R-matrix as previously defined, and  $L$  and  $\bar{L}$  are the logarithmic derivative vectors whose elements are given by

$$L = \left( \frac{r}{\phi_l^{inc}} \frac{d\phi_l^{inc}}{dr} \right)_{r=a} \quad (15)$$

and

$$\bar{L} = \left( \frac{r}{\phi_l^{out}} \frac{d\phi_l^{out}}{dr} \right)_{r=a} \quad (16)$$

respectively. Interaction cross-sections are calculated as functions of the U-matrix. Therefore the generalized path from experimental data to cross-section data is:

- Experimental data (with uncertainties) is collected.
- An initial set of resonance parameters ( $E_\lambda$  and  $\gamma_{\lambda c}$ ) are constructed, typically through inspection of the experimental data, or from a prior evaluation of experimental data for the isotope of interest.
- Using the initial set of resonance parameters, and a code such as SAMMY, a theoretical cross-section is generated using the chosen R-matrix formalism.

- Through iterative SAMMY runs the theoretical cross-section generated from the set of resonance parameters is fitted to the experimental data. Eventually a final best fit set of resonance parameters is found.
- These final resonance parameters, through the R-matrix and then the U-matrix can be used to generate interaction cross-sections through codes such as NJOY or AMPX.

The pertinent information above is  $E_\lambda$  and  $\gamma_{\lambda c}$ , the resonance energy and width, and their associated uncertainties. The workflow described below leads to derivation of covariance data for the resolved resonance region from those uncertainties.

### **Cross Section Covariance Data**

As stated above, ENDF/B cross section data in the resolved resonance region is stored as R-matrix parameters. Cross-section processing codes such as NJOY or AMPX can interpret the stored parameters into usable working libraries of interaction cross-sections. In order to produce those parameters, processing codes such as SAMMY are used to fit experimental data to a chosen R-matrix formalism. Such an evaluation must also take into account sources of uncertainty in the experimental data.

There are many potential sources of experimental uncertainty, both statistical uncertainty associated with the measured values, as well as systematic uncertainty associated with the experimental set up. Sources of systematic uncertainty include normalization and background measurements, neutron time-of-flight and flight path measurements, measurements of sample thicknesses and composition, etc. These

uncertainties must be taken into account through the evaluation process to produce the resonance-parameter covariance matrix. This matrix records the uncertainty for each resonance parameter (energy, widths), as well as correlation between the parameters.

Modern cross-section measurements are typically made using the time-of-flight method. A simplified diagram of a time-of-flight system is shown below in figure 4.




Figure 4) Example Time-of-Flight System

Accelerated electrons strike a high-Z target resulting in a flux of emitted neutrons. These neutrons can be collimated and moderated depending on experimental needs. The beam of emitted neutrons interacts with the sample to be studied. Detectors situated around the sample record the particles that reach them as a function of the time required for the particles to travel from the target to the detector, producing the “raw”

experimental count data. This data is therefore counts vs. time of flight, which is further divided into bins or channels resulting in counts per time channel.

This raw data must next be converted to reduced data by correcting for detector dead time, subtracting background measurements, and normalizing with respect to the experiment duration. The following derivation is taken from reference [12]. The neutron time of flight can then be converted to neutron incident energy by:

$$E_i = mL^2/2t_i^2 \quad (17)$$

Where  $m$  is the neutron mass and  $L$  is the length of the flight path.

The collected raw data will obey Poisson statistics, meaning the uncertainty on the count measurement for a given channel will be the square root of that measurement. Generally, the counts per channel will be a very large number. In this case, it is acceptable to treat the Poisson distribution of the raw data as a normal distribution. Therefore the raw data count in each channel will be treated as independent and uncorrelated with all other channels.

The assumption of no correlation does not hold for reduced data. This can be demonstrated through the relatively simple processes of normalization and background subtraction. Normalization constants and background,  $a$  and  $b$  respectively, are measured by their own experiments, and each have associated uncertainty,  $\Delta a$  and  $\Delta b$ , which will be assumed constant with respect to energy for the sake of this example. The uncertainty on normalization and background derive from their own independent measurements, which also obey Poisson statistics. Therefore,  $\Delta a$  and  $\Delta b$  are the standard deviation of those measurements. These uncertainties are propagated to the reduced data,  $d$ . Therefore, the reduced data at energy  $E_1$ ,  $d_1$ , is related to the reduced data  $d_2$  at energy  $E_2$

through the uncertainty propagation. This relationship can be described using the experimental data covariance matrix,  $V$ .

If  $r_i$  is the raw data point at time  $t_i$ , and  $d_i$  is the corresponding reduced data point at energy  $E_i$  as defined previously, then  $E_i$  is related to  $t_i$  by equation 14, and  $d_i$  is related to  $r_i$  by

$$d_i = (r_i - b)/a \quad (18)$$

Uncertainties are known for each value on the right hand side of equation 18, therefore the covariance matrix for the experimental data can be determined as follows. First small increments are taken of each side of the equation:

$$\delta d_i = \frac{(\delta r_i - \delta b)}{a} - \frac{(r_i - b)\delta a}{a^2} = [\delta r_i - \delta b - d_i \delta a]/a \quad (19)$$

Multiply each side by another small increment,  $\delta d_j$ , and take expectation values.

$$\langle \delta d_i \delta d_j \rangle = \frac{\langle [\delta r_i - \delta b - d_i \delta a][\delta r_j - \delta b - d_j \delta a] \rangle}{a^2} = \{ \langle \delta r_i \delta r_j \rangle + \langle \delta^2 b \rangle + d_i d_j \langle \delta^2 a \rangle \} / a^2 \quad (20)$$

All off diagonal terms have been eliminated from equation 20, based on the assumption that the different quantities were measured separately and are therefore uncorrelated. The experimental data covariance matrix can therefore be written

$$V_{ij} = \langle \delta d_i \delta d_j \rangle = \{ \Delta^2 r_i \delta_{ij} + \Delta^2 b + d_i d_j \Delta^2 a \} / a^2 \quad (21)$$



Now with properly reduced experimental data and its covariance matrix, it is possible to move forward with the evaluation process with the final goal of producing evaluated nuclear data.

This evaluated data combines the best reduced cross-section measurements with the best theoretical knowledge of the cross-section shape, via R-matrix theory formalism, along with adjustments of the “true” cross-section due to real-world effects such as resolution or Doppler broadening, or finite sample size effects. Accomplishing this type of evaluation requires codes such as SAMMY, to determine the set of resonance parameters the best fit the reduced experimental data and the real world considerations. SAMMY will also produce the associated covariance matrix for the resonance parameter set, including both the statistical uncertainties introduced through the data reduction process, as well as systematic uncertainties introduced through the real world corrections. [13][14]

As stated previously, SAMMY utilizes a generalized least-squares method to fit its parameter set and covariance matrix. This Bayesian method for fitting the resonance parameters results in an updated resonance parameter set  $P$  as

$$P = P_0 + M' Y, \quad (22)$$

where  $M'$  is the associated resonance parameter covariance matrix, and is found by

$$M' = (M_0^{-1} + W)^{-1} \quad (23)$$

with  $W$  defined as

$$W = G^t V^{-1} G, \quad (24)$$

and  $Y$  is defined as an auxiliary matrix given by,

$$Y = G^t V^{-1} (D - T) \quad (25)$$

Above,  $P_0$  is the initial parameter set with associated resonance parameter covariance matrix  $M$ , which is unknown initially and therefore assumed to be diagonal and infinite, meaning  $M^{-1} = 0$ . [15]  $V$  is the data covariance matrix as defined previously,  $T$  is the theoretical value corresponding to the experimental data  $D$ , and  $G$  is the sensitivity matrix of the theoretical values with respect to the parameters given by

$$G = \frac{\partial T}{\partial P} \quad (26)$$

SAMMY can and should utilize all available experimental data of all types in this fitting procedure, as well as the full covariance matrix for each data set. Integral constraints such as resonance integrals and thermal cross sections can also be included. Upon completion, the final parameter set  $P$  can be written in ENDF File 2 format for inclusion in evaluated nuclear data files, while the covariance matrix  $M$  can be stored in ENDF File 32 format.

## CURRENT MOLYBDENUM CROSS SECTION AND COVARIANCE DATA

As an initial investigation into molybdenum cross-section uncertainty, existing cross-section data from differing libraries was compared. Three existing data libraries were chosen: ENDF, maintained by Brookhaven National Laboratory in the US, JEFF maintained by the OECD Nuclear Energy Agency, and JENDL, maintained by the Japan Atomic Energy Agency. The most recent versions of these libraries (ENDF/B-VII.1, JEFF-3.1.1, JENDL-4.0) were obtained from the National Nuclear Data Center for the naturally occurring molybdenum isotopes:

$^{92}\text{Mo}$  ( 14.84% )  $^{94}\text{Mo}$  ( 9.25% )  $^{95}\text{Mo}$  ( 15.92% )  $^{96}\text{Mo}$  ( 16.68% )

$^{97}\text{Mo}$  ( 9.55% )  $^{98}\text{Mo}$  ( 24.13% )  $^{100}\text{Mo}$  ( 9.63% , 1.2E19 Y )

The processing code NJOY was used to produce 238-group libraries for the molybdenum isotopes, shown below for  $^{97}\text{Mo}$  total cross-section as an example in figure 5 [16].




Figure 5)  $^{97}\text{Mo}$  238-group library comparison (total cross section)

Significant differences between libraries are evident, particularly in the resolved resonance and high energy regions.

The energy region limits imposed by the different libraries was determined for the isotopes, shown below in tables 1 through 7.

Table 1)  $^{92}\text{Mo}$  Energy Region Limits

$^{92}\text{Mo}$	ENDF/B-VII.1	JEFF-3.1.1	JENDL-4.0
Resolved Resonance	$10^{-5}$ eV – 40 KeV	$10^{-5}$ eV – 50 KeV	$10^{-5}$ eV – 50 KeV
Unresolved Resonance	40 KeV – 100 KeV	50 KeV - 100 KeV	50 KeV – 1 MeV
High Energy	100 KeV – 20 MeV	100 KeV – 20 MeV	1 MeV – 20 MeV

Table 2)  $^{94}\text{Mo}$  Energy Region Limits

$^{94}\text{Mo}$	ENDF/B-VII.1	JEFF-3.1.1	JENDL-4.0
Resolved Resonance	10e-5 eV – 20 KeV	10e-5 eV – 20 KeV	10e-5 eV – 20 KeV
Unresolved Resonance	20 KeV – 100 KeV	20 KeV – 100 KeV	20 KeV – 1 MeV
High Energy	100 KeV – 20 MeV	100 KeV – 20 MeV	1 MeV – 20 MeV

Table 3)  $^{95}\text{Mo}$  Energy Region Limits

$^{95}\text{Mo}$	ENDF/B-VII.1	JEFF-3.1.1	JENDL-4.0
Resolved Resonance	10e-5 eV – 2.1412 KeV	10e-5 eV – 2.1412 KeV	10e-5 eV – 2 KeV
Unresolved Resonance	2.1412 KeV – 206.2685 KeV	2.1412 KeV – 206.2685 KeV	2 KeV – 400 KeV
High Energy	206.2685 KeV – 20 MeV	206.2685 KeV – 20 MeV	400 KeV – 20 MeV

Table 4)  $^{96}\text{Mo}$  Energy Region Limits

$^{96}\text{Mo}$	ENDF/B-VII.1	JEFF-3.1.1	JENDL-4.0
Resolved Resonance	10e-5 eV – 19 KeV	10e-5 eV – 19 KeV	10e-5 eV – 19 KeV
Unresolved Resonance	19 KeV – 100 KeV	19 KeV – 100 KeV	19 KeV – 1 MeV
High Energy	100 KeV – 20 MeV	100 KeV – 20 MeV	1 MeV – 20 MeV

Table 5)  $^{97}\text{Mo}$  Energy Region Limits

$^{97}\text{Mo}$	ENDF/B-VII.1	JEFF-3.1.1	JENDL-4.0
Resolved Resonance	10e-5 eV – 2 KeV	10e-5 eV – 1.8 KeV	10e-5 eV – 1.8 KeV
Unresolved Resonance	2 KeV – 100 KeV	1.8 KeV – 100 KeV	1.8 KeV – 300 KeV
High Energy	100 KeV – 20 MeV	100 KeV – 2 MeV	300 KeV – 2 MeV

Table 6)  $^{98}\text{Mo}$  Energy Region Limits

$^{98}\text{Mo}$	ENDF/B-VII.1	JEFF-3.1.1	JENDL-4.0
Resolved Resonance	10e-5 eV – 32 KeV	10e-5 eV – 32 KeV	10e-5 eV – 32 Kev
Unresolved Resonance	32 KeV – 100 KeV	32 KeV – 100 KeV	32 KeV – 1 MeV
High Energy	100 KeV – 20 MeV	100 KeV – 20 MeV	1 MeV – 20 MeV

Table 7)  $^{100}\text{Mo}$  Energy Region Limits

$^{100}\text{Mo}$	ENDF/B-VII.1	JEFF-3.1.1	JENDL-4.0
Resolved Resonance	10e-5 eV – 26 KeV	10e-5 eV – 26 KeV	10e-5 eV -26 KeV
Unresolved Resonance	26 KeV – 100 KeV	26 KeV – 100 KeV	26 KeV – 1 MeV
High Energy	100 KeV – 20 MeV	100 KeV – 20 MeV	1 MeV – 20 MeV

In general, the ENDF and JEFF libraries used similar energy region structure. The JENDL library however consistently featured a broader unresolved resonance region than either the ENDF or JEFF libraries, appearing to not account for cross-section features that the ENDF and JEFF libraries used to define their energy regions.

The next comparison utilized the PREPRO cross-section processing code to compare the resolved resonance region structure of the three libraries [17]. Resolved resonance cross-sections are typically generated through interaction models defined by resonance parameters. These parameters are fit empirically to experimental data; however nuclear data libraries do not necessarily use the same resonance models or parameters.

Using the PREPRO summary output, the first noticeable difference between the JEFF and ENDF data is the number of resonances: for example, for  $^{94}\text{Mo}$ , the ENDF data identifies 55 resonances while the JEFF data has 58. The JENDL data includes 59 resonances. In fact, for 3 out of 7 isotopes, there was not agreement between data libraries on how many resonances were present, as seen in table 8.

Table 8) Comparison of number of resonances for ENDF, JEFF, and JENDL libraries

	ENDF	JEFF	JENDL
<sup>92</sup> Mo*	60	77	78
<sup>94</sup> Mo*	55	58	59
<sup>95</sup> Mo*	57	56	56
<sup>96</sup> Mo	75	75	75
<sup>97</sup> Mo*	66	66	66
<sup>98</sup> Mo	158	158	158
<sup>100</sup> Mo	124	124	124

Further differences between libraries are found upon closer inspection. Returning to <sup>95</sup>Mo, we can compare the number of resonances in each library for each combination of  $L$  and  $J$  quantum numbers, shown in table 9:

Table 9) <sup>95</sup>Mo resonances sorted by quantum numbers for ENDF, JEFF, and JENDL

	ENDF	JEFF	JENDL
L=0, J=2	9	10	10
L=0, J=3	14	11	11
L=1, J=1	2	4	5
L=1, J=2	12	7	10
L=1, J=3	14	13	10
L=1, J=4	6	11	10

Returning to table 8, all isotope libraries with asterisks had additional differences when sorted by quantum numbers. The number of resonances per set of quantum numbers differed more dramatically for even-odd isotopes. Furthermore, even when libraries shared the same resonances, the partial widths of the resonances could differ by as much as 30-40% in some cases.

In short, it would be difficult to trace back differences in group cross-sections or system parameters such as multiplication factor to individual resonance parameters as

there are significantly more differences between the ENDF, JEFF and JENDL libraries than previously thought.

Clearly there is some uncertainty regarding the true values of molybdenum isotope cross sections. Such uncertainty is typically tabulated in covariance data files, the production of which is a key goal of this research work.

Currently, only the ENDF/B-VII.1 cross-section library includes covariance data for the molybdenum isotopes. However, this covariance data is low fidelity. It was generated as part of the Low Fidelity Covariance Project, a joint undertaking between Oak Ridge National Laboratory, Brookhaven National Laboratory, and Los Alamos National Laboratory. The goal of that project was to quickly and transparently produce modeling usable uncertainty estimates for all isotopes in ENDF. In order to accomplish this, the process for producing covariance data had to be extremely streamlined. For structural materials and fission products, integral uncertainty measurements (2200 m/s cross section, thermal capture, resonance integral) were assigned as the uncertainty values for whole energy regions (thermal, resonance) and were coupled with high energy covariance data generated at BNL. Complete correlation was assigned throughout the energy domain.

As an example, figures 6 and 7 below show the current low fidelity elastic scattering and capture covariance data for  $^{97}\text{Mo}$  as is available in ENDF/B-VII.1. As a comparison, figures 8 and 9 show high fidelity elastic scattering and capture covariance data for  $^{235}\text{U}$ .






Figure 6)  $^{97}\text{Mo}$  Low Fidelity Elastic Scattering Covariance Data




Figure 7)  $^{97}\text{Mo}$  Low Fidelity Capture Covariance Data




Figure 8)  $^{235}\text{U}$  High Fidelity Elastic Scattering Covariance Data




Figure 9)  $^{235}\text{U}$  High Fidelity Capture Covariance Data

There are clear differences between the low and high fidelity covariance data. The molybdenum uncertainty data follows a very coarse stair-step as compared to the uranium uncertainty data. Additionally the correlation matrix for the uranium shows significant structure, whereas the low fidelity molybdenum data assigns blanket full correlation throughout all energy regions. However, the high uncertainty of the  $^{235}\text{U}$  capture cross section should be noted.

Improvement to molybdenum covariance data should include increased resolution of correlations, as well as improved estimates of uncertainty.

#### **EXISTING MOLYBDENUM SENSITIVE CRITICAL EXPERIMENTS**

There are few critical experiments in existence which exhibit sensitivity to the molybdenum isotopes. In particular, very few critical experiments feature molybdenum as an integral component of the fuel material. Uranium-molybdenum alloy fuels were researched during the 1950s and 1960s, with little interest in the technology until recently.

Most of the criticality benchmark experiments catalogued by the International Criticality Safety Benchmark Evaluation Project which include molybdenum isotopes feature them as structural material, as molybdenum is used in some alloys of stainless steel, or as reflectors.

However, there are technical reports from a series of critical experiments completed in the early 1960s with the ORNL Fast Burst Reactor, later renamed the Health Physics Research Reactor, as well as critical experiments dating to the design phase for that reactor [18] [19].

The FBR was a Godiva type assembly, differing from the original Godiva reactors in that the constituent fuel was U(93.2%)-10Mo metal. A diagram of the reactor core is shown below in figure 10. Key reactor dimensions are given in the technical reports.

The critical experiments associated with the design of the FBR are likely to be more relevant for the purposes of this research. In these experiments a series of five critical assemblies of differing cylindrical and annular geometries were studied. One such assembly is shown below in figure 11. The technical reports for these experiments include material compositions and experimentally verified critical dimensions, generally cylinder or annulus heights, as well as critical masses.




Figure 10) ORNL FBR Core Diagram




Figure 11) U-Mo cylindrical critical assembly experiment

The fuel for the FBR critical experiments was 93% enriched uranium metal, alloyed with 10 w/o natural molybdenum. While this fuel is of significantly higher enrichment than the U(19.5%)-10Mo fuel foils to be produced by Y-12, these critical experiments offer the only set of experimental data for systems in which molybdenum makes up a key component of the fuel itself.

The five FBR design critical experiments modeled are as follows:

ORNL FBR Crit. Exp. #1: Bare U-Mo metal cylinder, 20.32 cm diameter, 14.78 cm in height, 68.6 kg of  $^{235}\text{U}$ .

ORNL FBR Crit. Exp. #2: Bare U-Mo metal annulus, 20.32 cm outer diameter, 5.08 cm diameter axial hole, 19.74 cm in height, 85.9 kg of  $^{235}\text{U}$ .

ORNL FBR Crit. Exp. #3: U-Mo metal annulus, 20.32 cm outer diameter, 5.08 cm diameter steel core, 82.4 kg of  $^{235}\text{U}$ .

ORNL FBR Crit. Exp. #4: U-Mo metal annulus, 20.32 cm outer diameter, 5.08 cm inner diameter, 5.08 cm thick Plexiglas on all sides, void in center, 12.57 cm in height, 47.2 kg of  $^{235}\text{U}$ .

ORNL FBR Crit. Exp. #5: U-Mo metal annulus, 20.32 cm outer diameter, lower 12.7 cm of assembly has 8.89 cm inner diameter, remainder has 5.08 cm inner diameter, 2.54 cm thick Plexiglas on all sides, void in center, 13.86 cm in height, 52.8 kg of  $^{235}\text{U}$ .

As mentioned previously, the ICSBEP does include some critical experiments which feature molybdenum as structural materials or reflectors. These experiments are described in table 10.

Table 10) ICSBEP Molybdenum Sensitive Critical Experiments [20]

<i><b>ICSBEP Identifier</b></i>	<i><b>Title</b></i>	<i><b>Role of Molybdenum</b></i>
HEU-MET-FAST-005-001 through 006	“Beryllium and Molybdenum Reflected Cylinders of Highly Enriched Uranium”	Reflector
HEU-SOL-THERM-001-001 through 002	“Minimally Reflected Cylinders of Highly Enriched Solutions of Uranyl Nitrate”	Stainless steel tank
LEU-COMP-THERM-042-001 through 007	“Water-Moderated Rectangular Clusters of U(2.35)O <sub>2</sub> Fuel Rods (1.684 Cm Pitch) Separated by Steel, Boral, Boroflex, Cadmium, or Copper Plates, with Steel Reflecting Walls”	Steel reflecting walls and steel absorber plates
MIX-COMP-FAST-001-001	“ZPR-6 Assembly 7: A Cylindrical Assembly with Mixed (Pu,U)-Oxide Fuel and Sodium with a Thick Depleted-Uranium Reflector”	Pu-U-Mo fuel plates
U233-SOL-THERM-003-002 through 010	“Paraffin-Reflected 5-, 5.4-, 6-, 6.6-, 7.5-, 8-, 8.5-, 9-, and 12-Inch Diameter Cylinders of <sup>233</sup> U Uranyl Fluoride Solutions”	Impurities in solution
U233-SOL-THERM-009-001 through 004	“Unreflected Large-Diameter Cylinders of <sup>233</sup> U Uranyl Nitrate Solutions”	Stainless steel tank



The above critical experiments, along with the ORNL FBR critical experiments, comprise the set of critical experiment sensitivity responses which will be utilized in the sensitivity and uncertainty analysis for this work using the SCALE modules TSUNAMI and TSURFER. Additionally, they will reveal the deficiencies in existing molybdenum sensitive critical experiments, so as to inform the design process of new critical experiments to address those deficiencies.

## **SENSITIVITY AND UNCERTAINTY ANALYSIS**

As interest in sensitivity and uncertainty analysis has increased over the past decade, S/U modules and capabilities have been incorporated into industry standard general analysis codes. One such code package is SCALE, a modular general purpose nuclear analysis code maintained at Oak Ridge National Laboratory. Several modules of SCALE have been developed for sensitivity and uncertainty analysis tasks, two of which will be used for this project: TSUNAMI and TSURFER.

### **SCALE: TSUNAMI**

TSUNAMI (Tools for Sensitivity and Uncertainty Analysis Methodology Implementation) is a SCALE control module for the application of sensitivity and uncertainty theory to criticality safety analysis [21]. TSUNAMI computes the sensitivity of the system multiplication factor to the evaluated nuclear cross section data used to model the system. This sensitivity data is coupled with cross section covariance data to produce an uncertainty in the multiplication factor due to the underlying cross section

data uncertainty. TSUNAMI is a multi-group code, and the group-wise sensitivity data it generates is stored in sensitivity data files for use with other SCALE sensitivity and uncertainty modules.

TSUNAMI features automated, problem-dependent cross section processing utilizing sensitivity versions of the standard processing codes used in SCALE. These sensitivity processing codes compute resonance-shielded cross sections and their sensitivities to the input data, which are stored as “implicit sensitivities.” After cross section processing, TSUNAMI utilizes either KENO V.a or KENO-VI as Monte Carlo transport calculators to perform two criticality calculations, one forward and one adjoint. Finally, the SCALE module SAMS calculates the sensitivity coefficients that indicate the sensitivity of the calculated value of  $k_{\text{eff}}$  to changes in the cross section data as well as the uncertainty in the calculated  $k_{\text{eff}}$  due to the uncertainties in the cross section data. These sensitivity coefficients are then stored for later use.

A generalized flow diagram for TSUNAMI is given below in figure 12, outlining the various SCALE modules called and their ordering.




Figure 12) General Flow Diagram for TSUNAMI

## SCALE: TSURFER

TSURFER (Tool for Sensitivity/Uncertainty analysis of Response Functionals using Experimental Results) is a module of SCALE responsible for computing uncertainties in integral system parameters, primarily multiplication factor, due to uncertainties in the cross section data used to model the system [22]. Additionally, TSURFER can be used to reduce discrepancies between experimentally measured integral system parameters and calculated system parameters by adjusting the nuclear data such that the overall consistency is maximized. Finally, TSURFER can analyze measured responses from benchmark experiments and establish bias and associated uncertainty in calculated application responses.

TSURFER utilizes a generalized linear least-squares (GLLS) methodology. GLLS is an application of Bayes Theorem from probability theory: if the original sets of calculated and experimental responses are consistently consolidated, taking uncertainties into account, then the “adjusted” results should be a better estimate for the true response, as the revised response is based on more information than either the original calculation or original measurement.

At the core of any nuclear system modeling is cross section data derived from fundamentally evaluated nuclear data files such as ENDF, JEFF, or JENDL. However, the “true” values of this cross section data is unknown, therefore it is reasonable to view this evaluated data as being drawn from a probability distribution of allowable values. This distribution is defined by the cross section uncertainty, as recorded in covariance data. GLLS methodology considers potential variations in cross section data and experimentally measured system parameters which minimize the differences between measured and calculated integral responses, such as  $k_{\text{eff}}$ . Such a problem is significantly

underdetermined, as there exist far more cross section values than integral responses; data variations must be constrained to avoid unphysical results. TSURFER accomplishes this by constraining data adjustments in the GLLS methodology by the cross section covariance data. The result is a “best estimate” within the limits of GLLS approximations for reasonable data adjustments which improve the computed integral responses.

TSURFER defines two types of responses: experiment responses and application responses. An experiment response has both a calculated and measured integral value associated with it. An example would be a critical experiment with both a reported experimental multiplication factor, as well as a calculated multiplication factor from a modeling simulation. An application response has only a calculated integral value. Applications typically correspond to hypothetical or proposed systems considered in the context of a design study for which the computational bias and uncertainty associated with cross section uncertainty is desired. An application plays a passive role in the GLLS methodology, as it has no experimental results it does not impact the active experiment responses included the consolidation process. However, if the application response shares nuclear cross section data sensitivities with the experimental responses, it will be affected by the same data adjustments that impact the experiment responses. This provides a systematic, well defined method for utilizing benchmark measurements to establish bias and uncertainty estimates arising from nuclear data uncertainty in the calculation of system parameters in proposed nuclear system designs.

Using TSUNAMI, sensitivity profiles will be generated for both the existing molybdenum sensitive critical experiments and the proposed U(19.5%)-10Mo critical experiment designs. Using these sensitivity profiles, TSURFER will the establish bias and uncertainty estimates for the proposed critical experiment designs using both the current low fidelity molybdenum covariance data and the newly produced high fidelity

molybdenum covariance data. The resulting bias estimates from the two covariance data libraries will provide a means of comparing their impact.

### **Chapter 3: Critical Experiment Designs**

Currently few critical experiments sensitive to molybdenum exist. In particular there is a lack of thermal spectrum critical experiments. The majority of the current critical experiment library sensitive to molybdenum features either high enriched uranium molybdenum alloy fuel in a fast spectrum, or molybdenum only as structural or reflector material. As the research and test reactors which will utilize the new low enriched U-Moly foil fuel form feature thermal spectra, such as the ATR at Idaho National Lab, experiments addressing this lack of thermal spectrum data are necessary. This chapter presents two fast spectrum experiment concepts as well as two thermal spectrum experiment concepts to be carried out at the National Criticality Experiments Research Center. The two fast spectrum experiment designs are referred to as the Fast Bare Critical Experiment and Fast Reflected Critical Experiment, while the two thermal spectrum experiment designs are referred to as the Thermal Standard Molybdenum Critical Experiment and the Thermal Maximum Molybdenum Critical Experiment.

Comparisons of the fast and thermal spectra critical experiments should provide additional insight into uncertainty in the molybdenum isotope cross-sections data. In particular, while the thermal spectrum experiment may exhibit greater overall sensitivity to the molybdenum cross-sections due to the higher neutron populations at low energies, the molybdenum cross-sections themselves are presently more uncertain in the resolved and unresolved resonance energy regions. This series of critical experiments would establish critical masses of the low enriched U-Moly foil fuel form, both in highly thermalized and fast neutron spectra. Comparisons of the experimental critical mass to

computational models may indicate needed corrections to molybdenum cross-section data.

Of the experimental machines available for criticality experimentation at the National Criticality Experiments Research Center (NCERC) in Nevada, the most useful for this type of experiment will be the large capacity vertical lift table known as Comet, shown below in figure 13 [23].




Figure 13) Comet Vertical Split Table Test Device

The substantially increased capacity of Comet as compared to the other vertical lift table available will be required as moderating and reflecting material will be included in the some of the experimental designs. [24]



The general initial experimental set up is as follows: two subcritical assemblies would be constructed from either thick layers of U-Mo fuel foils and HEU in the case of the fast spectrum designs, or from interlayered fuel foils and moderating material in the case of the thermal spectrum designs. [25] A graphite reflector would surround the two subcritical assemblies on five sides in the case of the Fast Reflected experiment and both thermal spectrum experiments. These two assemblies would then be brought together using the Comet lifting table as shown below in figure 14.




Figure 14) Proposed Experimental Set Up

## INITIAL SCOPING STUDIES AND EXISTING CRITICAL EXPERIMENTS

Prior to beginning the critical experiment design process, it was desired to determine the effects molybdenum isotope cross section differences could have on integral system parameters, such as multiplication factor. As a first look, an infinite media case of a U(19.5%)-10Mo metal fuel was modeled using MCNP5 [26]. The simulation was repeated with the molybdenum isotope cross section data provided by three different data libraries: ENDF-B/VII.1, JEFF 3.1.1, and JENDL 4.0, results shown in table 11.

Table 11) Multiplication Factors for Infinite Metal

Library	$k_{\text{eff}}$	MCNP Standard Deviation
ENDF-B/VII.1	1.56929	0.00023
JEFF3.1.1	1.56997	0.00023
JENDL4.0	1.57279	0.00024

The differences in  $k_{\text{eff}}$  is equivalent to a change of 43.313 pcm when comparing ENDF to JEFF data, 222.535 pcm when comparing ENDF to JENDL data, and 179.299 pcm when comparing JENDL to JEFF data. These differences are not insignificant, particularly in the case of JENDL data.

The hypothetical infinite homogenous metal case modeled above would result in a fast neutron spectrum, as no moderator is present. As high energy neutrons dominate the response of this system, the multiplication factor will be sensitive to differences in the high energy cross-section of the molybdenum isotopes between libraries, while differences at lower energies in the resonance region and below will likely be of minimal effect. Therefore the above process was repeated for an infinite repeating square lattice of

cylindrical metal fuel pins, surrounded by light water moderator. The fuel pin radius was 0.6 cm, with a pitch of 5.65 cm, as shown in figure 15. The resulting calculated multiplication factors are given in table 12.




Figure 15) Infinite Lattice of Cylindrical U(19.5%)-10Mo Fuel Elements

Table 12) Multiplication Factors for Infinite Square Lattice

Library	$k_{\text{eff}}$	MCNP Standard Deviation
ENDF-B/VII.1	1.00338	0.00031
JEFF3.1.1	1.00350	0.00031
JENDL4.0	1.00417	0.00030

The differences in  $k_{\text{eff}}$  is equivalent to a change of 11.958 pcm when comparing ENDF to JEFF data, 78.672 pcm when comparing ENDF to JENDL data, and 66.722 pcm when comparing JENDL to JEFF data. These results show significantly less difference than in the infinite unmoderated case. This indicates that differences in the low

energy and resonance regions of the molybdenum cross-sections between the three libraries may be less pronounced than those in the high energy region, or that the system is less sensitive to those changes.




Figure 16) Spectra for Infinite Metal and Infinite Moderated Lattice of U-10Moly Fuel

Figure 16 above shows the calculated flux spectra for the infinite homogenous U-Moly metal and an infinite lattice of U-Moly fuel pins surrounded by light water, normalized by the peak channel for each. For the infinite homogeneous metal case, there is no appreciable thermal flux, as expected. The critical infinite lattice of U-Moly fuel pins exhibits a well moderated spectrum.

In order to determine the fuel/moderator volume ratio that would result in the largest difference in multiplication factor between data libraries, the infinite lattice model used previously was used again, varying the ratio of fuel area to moderator area in the lattice unit cell. Figure 17 below shows the absolute value of the difference in multiplication factor, in pcm, between data libraries, versus the fuel/moderator ratio over a range of 0.05 to 0.60.




Figure 17) Delta K/K vs. Fuel/Moderator Ratio

No clear pattern emerged over this range of ratio values. This suggests that cross section differences across a wide range of energies are contributing to the disagreement in multiplication factor. The ratio with the greatest average difference in multiplication factor was around 0.05.

## **ORNL Fast Burst Reactor Critical Experiments**

Critical experiment benchmarks are required in order to compare the computational results associated with each library to a known experimental result. Molybdenum can often be found in structural materials, and reflectors; but experimental data of uranium-molybdenum alloy fuels are rare.

However, there are technical reports from a series of critical experiments completed in the early 1960s with the ORNL Fast Burst Reactor, later renamed the Health Physics Research Reactor, as well as critical experiments dating to the design phase for that reactor.

The critical experiments associated with the design of the HPRR are likely to be more relevant for the purposes of this research. In these experiments a series of four critical assemblies of differing cylindrical and annular geometries were studied. The technical reports for these experiments include material compositions and experimentally verified critical dimensions, generally cylinder or annulus heights. However, some aspects of the experiment were approximated. These critical experiments will serve as a basis for cross section and covariance data comparison [27].




Figure 18) Spectra of three bare unmoderated FBR critical experiments

Three unreflected criticality experiments were modeled as follows: (1) a solid cylinder 14.78 cm high of U(93%)-10Mo alloy, 20.38 cm diameter; (2) an annulus 19.74 cm high with a 5.08 cm inner diameter, and (3) an annulus 18.92 cm high with a 5.08 cm diameter 304 steel core. Each experiment was modeled in MCNP with ENDF/B-VII.1, JEFF3.1.1, and JENDL4.0 cross-section data. Figure 18 above gives the calculated neutron spectra for these three experiments compared to the spectra of the homogeneous infinite metal modeled before. For each case in figure 18 the spectrum is normalized by the maximum channel value.

The experiments have an even faster spectrum than the infinite metal due to neutron leakage. Change in multiplication factor due to the different libraries was calculated in pcm. These results are given in table 13.

Table 13) FBR Crit. Experiment #1, #2, and #3

	ORNL FBR Crit. Exp. #1		ORNL FBR Crit. Exp. #2		ORNL FBR Crit. Exp. #3	
	<i>K-eff</i>		<i>K-eff</i>		<i>K-eff</i>	
ENDF	0.9961		0.99391		0.99670	
JEFF	0.9966		0.99422		0.99653	
JENDL	0.9972		0.99481		0.99703	
	<i>del K/K</i>	<i>pcm</i>	<i>del K/K</i>	<i>pcm</i>	<i>del K/K</i>	<i>pcm</i>
ENDF vs JEFF	0.000512	51.17399	0.000312	31.18022	-0.00017	-17.059
ENDF vs JENDL	0.001113	111.3117	0.000905	90.46954	0.000331	33.098
JENDL vs JEFF	0.000602	60.16847	0.000593	59.30781	0.000501	50.149

On average the disagreement between molybdenum libraries was between 50 and 60 pcm. Changes to the molybdenum cross-sections therefore have substantial impacts on the multiplication factor of systems using uranium-molybdenum fuel. The next step would be to determine more specifically which cross-sections and energy regions are responsible for those impacts.

The TSUNAMI module of the SCALE code package calculates sensitivity of multiplication factor to material cross-section data. TSUNAMI is a neutron transport eigenvalue sensitivity analysis sequence using adjoint based first order perturbation



theory [27]. The geometries for the three fast critical experiments were very simple, and they were modeled using the 3-D version of the TSUNAMI code.

Figure 19 below show the total sensitivity for each isotope for critical experiment #1, obtained by varying the total cross-section in each lethargy bin and then dividing the resulting change in multiplication factor by the width of the bin in lethargy. This total sensitivity is analogous to sensitivity of the system to the atomic density of each isotope, and in turn the cross-section data of that isotope. Sensitivity for critical experiments 2 and 3 are very similar to figure 19.




Figure 19) Total Sensitivity vs. Energy for Molybdenum Isotopes in ORNL FBR Crit. Experiment #1

As expected, due to the spectra of these experiments, the sensitivity is entirely in the high energy region, as this is the only energy region populated by neutrons in these experiments. In particular, the systems are most sensitive to  $^{92}\text{Mo}$ ,  $^{95}\text{Mo}$ ,  $^{96}\text{Mo}$ , and  $^{98}\text{Mo}$ . However, these experiments may miss sensitivities arising from differences in the

resonance region, where significant discrepancies between cross-section libraries have already been seen. Therefore it is necessary to model systems having a more thermalized spectrum, with neutron population in the resonance energy region.

In addition to the experimental systems detailed thus far, several critical experiments were also conducted which included plexiglass reflectors. Plexiglass has a high atomic density of hydrogen and carbon, and serves as moderator in addition to reflecting neutrons [28]. ORNL FBR Critical Experiment #4 was an annulus of high enriched U-Mo which was reflected by 5.08 cm of plexiglass on external surfaces, but void in the central region. ORNL FBR Critical Experiment # 5 was a similar annulus, reflected by 2.54 cm of plexiglass on external surfaces, but with additional plexiglass filling the inner void as well.




Figure 20) Flux Spectra for ORNL FBR Crit. Exps. #1, #4, and #5

The above figure 20 shows the MCNP calculated flux spectra for three of the FBR critical experiments, normalized by peak channel value. FBR Crit. Exp. #1 was a bare cylinder of high enriched U-Mo metal, as has been shown previously. For the bare homogeneous metal case, there is no appreciable thermal flux, as expected. The two reflected critical experiments demonstrate moderated spectra. In particular, ORNL FBR Crit. Exp. #4 exhibits the most thermalized neutron spectrum of all the U-Mo alloy fueled critical experiments to date.

The two reflected criticality experiments were modeled as follows: (1) an annulus 12.57 cm high, 20.38 cm diameter with an 8.89 cm inner diameter, reflected on all external surfaces by 5.08 cm of plexiglass; (2) an annulus 13.86 cm high with a 8.89 cm

inner diameter for the lower 12.7 cm height, and 5.08 cm inner diameter for the remainder, with 2.54 cm of plexiglass on all external surfaces, and plexiglass in the central void as well. Each experiment was modeled in MCNP with ENDF/B-VII.1, JEFF3.1.1, and JENDL4.0 cross-section data for the molybdenum isotopes. Change in  $k$ -eff due to the different libraries was calculated in pcm. These results are given in table 14.

Table 14) FBR Crit. Experiment #4 and #5

	ORNL FBR Crit. Exp. #4			ORNL FBR Crit. Exp #5		
	<i>K-eff</i>			<i>K-eff</i>		
ENDF	1.00999			1.00928		
JEFF	1.00987			1.01020		
JENDL	1.01076			1.00935		
	<i>del K/K</i>	<i>pcm</i>		<i>del K/K</i>	<i>pcm</i>	
ENDF vs JEFF	-0.00012	-11.8827		0.000911	91.07108	
ENDF vs JENDL	0.000762	76.1803		6.94E-05	6.935156	
JENDL vs JEFF	0.000881	88.05255		-0.00084	-84.2126	

The thermal spectrum experiments exhibit increased reactivity changes as compared to the fast spectrum experiments described previously, on average there is 70-80 pcm difference between libraries.

TSUNAMI was again used to compute sensitivities for the molybdenum isotopes in the more thermalized spectra of FBR critical experiment #4 and #5. Plots of the total sensitivities of the molybdenum isotopes are given below in figures 21 and 22. Again the majority of sensitivity is in the high energy region. However, unlike the sensitivity plots for the bare critical experiments, sensitivity responses in the resonance region are present;

including large responses due to resonances of  $^{95}\text{Mo}$  and  $^{97}\text{Mo}$ . The effects of these resonances may account for the previous computational results in which no clear pattern of change in  $k_{\text{eff}}$  was found in relation to fuel to moderator ratio.




Figure 21) Total Sensitivity vs. Energy for Molybdenum Isotopes in ORNL FBR Crit. Experiment #4




Figure 22) Total Sensitivity vs. Energy for Molybdenum Isotopes in ORNL FBR Crit. Experiment #5

Breaking down the total uncertainty per isotope, TSUNAMI also demonstrates which reaction cross-sections the system multiplication factor is most sensitive to. In the case of molybdenum in these criticality experiments, the high energy sensitivity is due to the neutron scattering cross-sections of the molybdenum isotopes at those energies, while the large spikes in sensitivity in the resonance regions are due to the neutron capture cross-section of specific isotopes,  $^{95}\text{Mo}$  and  $^{97}\text{Mo}$ . Conceivably, if these cross-sections were altered based on the sensitivity of the experimental systems to these cross-sections, the computed system parameters, such as multiplication factor, could be made to conform more closely to the reported experimental system parameters. This would again verify the effect on the system due to molybdenum cross-section uncertainty. A module exists in the SCALE code package to calculate just such cross-section changes.

The TSURFER module of SCALE allows for the calculation of computational biases, deriving largely from cross-section data uncertainty, using a generalized linear

least squares approach. TSURFER identifies a single set of adjustments to nuclear data that will result in the computational models all producing  $k_{\text{eff}}$  values close to their experimental  $k_{\text{eff}}$  value. The difference between the originally calculated  $k_{\text{eff}}$  value and the new post-adjustment  $k_{\text{eff}}$  value represents the bias in the original calculation, and the uncertainty in the adjusted value represents the uncertainty in this bias [29]. Sensitivity profiles generated by the TSUNAMI module of SCALE for the systems in question are used, while the provided covariance library determines the boundaries for changes to the cross-section data. The sensitivity profiles used were generated using ENDF/B-VII.0 cross section data for all isotopes. The currently available low fidelity molybdenum covariance library was used.

Two sets of critical experiments were utilized:

- 1) The five critical experiments using high enriched U-Mo fuel performed at ORNL and previously discussed at length.
- 2) The above, as well as all other experiments from the ICSBEP which include molybdenum, typically as either a reflector or structural material.

For consistency, chi squared values of 0.8-1.2 are recommended. In the context of TSURFER, chi squared is the standard deviation of the nuclear data and measured integral responses. In order to ensure the target chi-square value, TSURFER eliminates experiments from the set of considered experiments until the value of chi-squared per degree of freedom is below the desired threshold.

Set 1: ORNL FBR critical experiments

### *1.2 Chi-squared*

With the recommended constraint on chi-squared three of the five FBR criticality experiments were eliminated from consideration, leaving the two plexiglass moderated experiments. The multiplication factor of these experiments was most sensitive to  $^{92}\text{Mo}$

and  $^{98}\text{Mo}$ , plots of the TSURFER calculated cross-section adjustments for these isotopes are given below in figure 23 and 24.




Figure 23)  $^{92}\text{Mo}$  Cross Section Adjustments for Set 1, 1.2 Chi-squared






Figure 24)  $^{98}\text{Mo}$  Cross Section Adjustments for Set 1, 1.2 Chi-squared

The largest cross-sections changes are for high energy elastic scattering. Figure 25 below shows the elastic cross-section changes for all molybdenum isotopes, all of which follow a similar pattern to each other.




Figure 25) Molybdenum Elastic Scattering Cross Section Adjustments for Set 1, 1.2 Chi-squared

However, these changes are dwarfed by the changes in  $^{235}\text{U}(\text{n},\gamma)$  cross section, shown in figure 26.




Figure 26)  $^{235}\text{U}$  Cross Section Adjustments for Set 1, 1.2 Chi-squared

The two moderated experimental systems considered by this TSURFER run have calculated multiplication factors of around 1.007 and experimental multiplication factors of 1.000. Increased parasitic absorption by  $^{235}\text{U}$  will therefore strongly push the calculated value closer to the experimental value. This illustrates an issue which affects nearly all sensitivity and uncertainty analysis. As seen in figure 9, currently there is extremely high uncertainty regarding the high energy neutron capture cross section of  $^{235}\text{U}$ , uncertainty in excess of 50% throughout the high energy region. Any system using  $^{235}\text{U}$  as the multiplying material will be extremely sensitive to this capture cross section with respect to multiplication factor. Therefore analysis such as is possible with TSURFER, featuring a consolidation of cross section adjustments to secure the best fit between experimental and computational results, will frequently produce large scale

adjustments to the  $^{235}\text{U}$  capture cross section which may “wash out” adjustments to other isotopes which this system is less sensitive too. Therefore a reduction in the uncertainty of the  $^{235}\text{U}$  capture cross section could provide a substantial improvement in the value of such sensitivity and uncertainty analysis work.

Below are the cross-section adjustments for  $^{238}\text{U}$ , the other primary component of the U-Mo fuel, which demonstrates relatively insignificant changes, shown in figure 27.




Figure 27)  $^{238}\text{U}$  Cross Section Adjustments for Set 1, 1.2 Chi-squared

It is difficult to draw conclusions from the cross-section adjustments in figures 23 through 27, as they rely on only two experimental responses. In order to include more experimental systems sensitive to molybdenum, attention was turned to the International

Handbook of Evaluated Criticality Safety Benchmark Experiments, maintained by the International Criticality Safety Benchmark Program (ICSBEP).

Set 2: FBR critical experiments and all experiments from the ICSBEP which include molybdenum

In addition to the ORNL FBR critical experiments included for the previous set of TSURFER runs, the ICSBEP contains a further 29 experiments which include molybdenum. The molybdenum in these experiments is primarily found in reflectors or structural components.

### *1.2 Chi-squared*

In order to achieve the desired degree of consistency, 19 of the 34 experiments were eliminated including one of the FBR critical experiments. However, the resulting cross-section adjustments, seen below in figures 28, 29 and 30, followed the same pattern of altering the high energy cross sections as for the previous experiment sets, but are roughly an order of magnitude larger than the previous set of cross section adjustments.




Figure 28)  $^{98}\text{Mo}$  Cross Section Adjustments for Set 2, 1.2 Chi-squared




Figure 29)  $^{92}\text{Mo}$  Cross Section Adjustments for Set 2, 1.2 Chi-squared




Figure 30) Molybdenum Elastic Scattering Cross Section Adjustments for Set 2, 1.2 Chi-squared

Additionally, non-negligible adjustments to the molybdenum capture cross sections are also suggested, as seen in figure 31 below. Adjustments in the resonance region are seen for  $^{97}\text{Mo}$ , a strong resonance absorber.




Figure 31) Molybdenum Capture Cross Section Adjustments for Set 2, 1.2 Chi-squared

Cross section adjustments for  $^{235}\text{U}$  and  $^{238}\text{U}$  are similar, though somewhat greater in magnitude, for the set of all molybdenum sensitive critical experiments as compared to the case of only the ORNL FBR critical experiments. They are seen below in figures 32 and 33.






Figure 32)  $^{235}\text{U}$  Cross Section Adjustments for Set 2, 1.2 Chi-squared




Figure 33)  $^{238}\text{U}$  Cross Section Adjustments for Set 2, 1.2 Chi-squared

The modeling study of existing molybdenum sensitive critical experiments detailed above informed the design process of a new series of critical experiments to feature the new Y-12 U-Moly foil fuel form. Key deficiencies in the critical experiment library include most notably a lack of U-Moly fueled critical experiments with a thermal neutron spectrum.

Therefore, the series of critical experiments proposed shall include both fast and thermal spectra experiments, to fully explore uncertainty in the molybdenum cross sections throughout the energy region; while also providing valuable characterization of the new fuel form.

## **PROPOSED CRITICAL EXPERIMENT DESIGNS**

### **Fast Spectra Experiment Designs**

#### ***Fast Bare Critical Experiment***

The U(19.5%)-10Mo fuel form is designed for use in a thermalized spectrum, complicating attempts to use the fuel in a fast neutron spectrum critical experiment. The initial design for the fast spectra critical experiment sought to use solely the U(19.5%)-10Mo fuel foils. However, due to the low enrichment, a fuel mass of nearly 920 kg was required to achieve criticality even when reflected by graphite. A pragmatic approach was taken, and only the 195 U-Moly foils from the thermal critical experiment were assumed to be available for the fast spectrum experiment.

To overcome the relatively low enrichment of the U-Moly alloy foils, two layers of HEU were added to the system, equal in length and width to the central layer of U-Moly. Essentially, fast spectrum fuel is added to drive the critical reaction. To ensure the fastest possible spectrum, no reflector was added. Therefore the design consists of layers

of U-Moly foils sandwiched between two layers of HEU. A diagram of this design is shown below in figure 34.




Figure 34) Fast Bare Critical Experiment MCNP Model

The above experimental design results in the fastest possible spectrum in the central U-Moly foil region, however it also requires approximately 319.5 kg of HEU. Figure 35 below compares the spectra, normalized by peak channel, of two fast critical experiments. The proposed bare fast critical experiment, shown in green, has little to no appreciable neutron population in the thermal to resonance energy regimes. The resulting spectrum is close to that of the bare ORNL FBR critical experiments.

An experimental plan and MCNP input listing for the Fast Bare Critical Experiment design can be found in appendices A and B respectively.




Figure 35) Fast Bare Critical Experiment Spectra

### ***Fast Reflected Critical Experiment***

In the event that the quantity of HEU required for the Fast Bare Critical Experiment would be prohibitive, a second critical experiment was designed. The second fast critical experiment design sacrifices some spectrum hardness in order to reduce the required HEU for criticality. A graphite reflector is utilized, as shown below in figure 36. For this configuration, approximately 49.6 kg of HEU is required for criticality.




Figure 36) Fast Reflected Critical Experiment MCNP Model

Figure 37 below compares the spectra, normalized by peak channel, of two fast critical experiments. The proposed reflected fast critical experiment, shown in red, has substantially increased neutron population in the resonance and thermal energy regions. The resulting spectrum is approaching that of the reflected ORNL FBR Critical Experiment #4.

An experimental plan and MCNP input listing for the Fast Reflected Critical Experiment design can be found in appendices A and B respectively.




Figure 37) Fast Reflected Critical Experiment Spectra

SCALE's TSUNAMI module was used to calculate sensitivity of system multiplication factor to changes in molybdenum isotope cross-section for all of the proposed critical experiments. Figures 38 through 44 below give the sensitivity per unit lethargy for each of the natural molybdenum isotopes for both fast spectrum critical experiment designs as well as the ORNL FBR Critical Experiment #1.




Figure 38)  $^{92}\text{Mo}$  Sensitivity for Fast Spectra Critical Experiment Designs




Figure 39)  $^{94}\text{Mo}$  Sensitivity for Fast Spectra Critical Experiment Designs




Figure 40)  $^{95}\text{Mo}$  Sensitivity for Fast Spectra Critical Experiment Designs




Figure 41)  $^{96}\text{Mo}$  Sensitivity for Fast Spectra Critical Experiment Designs






Figure 42)  $^{97}\text{Mo}$  Sensitivity for Fast Spectra Critical Experiment Designs




Figure 43)  $^{98}\text{Mo}$  Sensitivity for Fast Spectra Critical Experiment Designs




Figure 44)  $^{100}\text{Mo}$  Sensitivity for Fast Spectra Critical Experiment Designs

A clear pattern is seen in the above figures. Sensitivity for the three critical experiments is concentrated in the high energy region, though the Fast Reflected experiment design does show some sensitivity in the resonance energy region. However, the ORNL FBR critical experiment exhibits significantly more sensitivity to the molybdenum isotopes than the proposed U-Moly critical experiment designs. This derives from the issue described previously in designing a fast spectrum critical system using low density fuel intended for a thermal spectrum. Fast spectrum fuel must be included as a driver to achieve criticality while avoiding neutron moderation. Therefore the overall sensitivity of  $k_{\text{eff}}$  of the system to the molybdenum fuel is reduced: the HEU drives the reaction so the system sensitivity is concentrated in a region lacking molybdenum. However, given the low  $^{235}\text{U}$  density of the U-Moly fuel as compared to the HEU, the two proposed critical experiment designs offer the most fast spectrum molybdenum sensitivity achievable with the U-Moly fuel.

Figures 45 and 46 below show the sensitivity of  $k_{\text{eff}}$  to the group-wise total cross-sections for the molybdenum isotopes and for  $^{235}\text{U}$  and  $^{238}\text{U}$  respectively for the fast spectra critical experiment designs.




Figure 45)  $^{235}\text{U}$  Sensitivity for Fast Spectra Critical Experiment Designs




Figure 46)  $^{238}\text{U}$  Sensitivity for Fast Spectra Critical Experiment Designs

As compared to the unreflected case, figures 40 and 42 shows increased sensitivity in the resonance region, particularly large resonance responses are seen for  $^{95}\text{Mo}$  and  $^{97}\text{Mo}$ . In addition to high sensitivity to  $^{235}\text{U}$ , the proposed system would also be highly sensitive to cross-section changes in the graphite of the reflector.

Table 15) Differences in Modeled Fast Critical Experiment  $k_{\text{eff}}$  Due to Cross Section Library

	Fast Bare Exp.		Fast Reflected Exp.		ORNL FBR #1	
	$k_{\text{eff}}$		$k_{\text{eff}}$		$k_{\text{eff}}$	
ENDF	0.99960		0.99927		0.99609	
JEFF	0.99984		0.99873		0.99660	
JENDL	0.99961		0.99913		0.99720	
	$\text{del K/K}$	$\text{pcm}$	$\text{del K/K}$	$\text{pcm}$	$\text{del K/K}$	$\text{pcm}$
ENDF vs JEFF	0.00024	24.00384	-0.00054	-54.0687	0.000512	51.17399
ENDF vs JENDL	1.00E-05	1.00039	-0.00014	-14.0122	0.001113	111.3117
JENDL vs JEFF	-0.00023	-23.009	0.00040	40.03483	0.000602	60.16847

A numerical quantification of the integral system response to molybdenum cross-section uncertainty is given above in table 15, which shows the difference in multiplication factor of the experimental system modeled using molybdenum cross-section data from three different libraries: ENDF/B VII.1, JEFF3.3, and JENDL3.0. These results are somewhat surprising. As could be expected due to its higher molybdenum sensitivity, the ORNL FBR critical experiment exhibits the greatest deviation in multiplication factor across cross-section libraries. However, the proposed fast U-Moly critical experiments still exhibit significant differences in  $k_{\text{eff}}$ , despite significantly less sensitivity to the molybdenum isotopes. In particular, the Fast Reflected design exhibits over twice the deviation in  $k_{\text{eff}}$  as compared to the Fast Bare design, likely due to the increased neutron flux in the resonance region owing to moderation from the graphite reflector.

### **Thermal Spectra Experiment Designs**

The U-Moly fuel foils are designed for a thermal spectrum. However, to date, there are no thermal spectrum critical experiments containing uranium-molybdenum alloy fuels. The following details two proposed thermal spectrum critical experiments featuring the U-Moly fuel foils: one comprised of the uranium molybdenum foils interleaved with moderator and surrounded by a reflector, referred to as the Thermal Standard Molybdenum Critical Experiment, and one composed similarly to the Thermal Standard experiment, but with additional molybdenum metal only layers between the fuel foils and moderator. The purpose of this design is to achieve the maximum sensitivity

possible to the molybdenum cross-section in a thermal neutron spectrum, and is referred to as the Thermal Maximum Molybdenum Critical Experiment.

### ***Thermal Standard Molybdenum Critical Experiment***

For both of the thermal spectrum experiment designs, plexiglass or Lucite was chosen as the moderator, as it has a high hydrogen density while also being easy to handle, and can be inexpensively procured in the necessary geometries for the experimental set up.

In order to obtain a first order estimate of the amount of fuel material required a regular parallelepiped, 20" x 19.5" x 19.685", made up of a homogeneous mix of U(19.5%)-10Moly fuel and plexiglass was modeled using MCNPX. The dimensions of the parallelepiped were chosen as the foils produced by Y-12 are 20" long and 1.5" wide; using 13 foils side-by-side per "sheet" would most closely approximate a right cube, which would have the lowest neutron leakage of the geometries possible with the foils.

When modeled as described above, the minimum critical mass of fuel was just less than 17 kilograms. Including a 25 cm thick graphite reflector on all sides reduced the minimum critical mass to just over 12 kilograms. [30] Below in figure 47 is a plot of MCNPX calculated spectra for the bare and reflected cases, along with the spectra for the most thermalized ORNL FBR design critical experiment, all normalized by peak channel value. The proposed experimental design would offer a thermal-to-fast flux ratio orders of magnitude higher thermalized than any of the experiments currently in existence.




Figure 47) Calculated Spectra of Homogenized U-Moly Fuel and Lucite Moderator

Given that the scoping calculations were promising, to support a precise design a more realistic computational model was needed, specifically one with heterogeneous layers of fuel and moderator to account for the effects of  $^{238}\text{U}$ . The MCNP calculations were repeated with such a heterogeneous system: layers of fuel interlaced with layers of moderator. Example input decks are presented in Appendix C. The minimum critical system in this configuration had 15 fuel layers of 13 foils each, for a total of 195 required fuel foils, with a ~25 cm thick graphite reflector. This loading of fuel foils will contain 14.67 kg of uranium metal, and 2.86 kg of  $^{235}\text{U}$ . As the number of fuel layers will not be easily alterable, the thickness of the graphite reflector could serve as a criticality control for the experiment, along with the separation distance between the subcritical systems.

Shown below in figure 48 is the final thermal experiment model. The figure is not necessarily drawn to scale, but rather to clearly show geometry details.

This model is simplified, not taking into account geometric variation or material impurities in fuel foils or moderator as well as neglecting the effects of the room surrounding the critical experiment as well as the Comet experimental machine itself. These simplifications would be resolved if the design process continued. In particular, the precise composition of the actual physical experimental elements (fuel foils, Lucite and graphite blocks) would need to be finalized. But for a reflected experiment, high-fidelity modeling of room and experimental apparatus was found in other similar critical experiment models to have minimal effects, generally within calculation uncertainty.

[31][32][33]






Figure 48) Thermal Standard Molybdenum Critical Experiment MCNP Model

Below, in figure 49, is a plot of MCNPX calculated spectra of the proposed thermal standard molybdenum critical experiment. This spectrum is not as thermalized as the hypothetical homogenized spectra shown previously; however it is significantly more thermalized than any existing uranium-molybdenum alloy fueled critical experiment.




Figure 49) Thermal Standard Molybdenum Critical Experiment Spectra

### ***Thermal Maximum Molybdenum Critical Experiment***

In order to maximize the system sensitivity with respect to molybdenum, an additional critical experiment was designed, based on the initial thermal critical experiment design. Additional layers of pure molybdenum foil were added for each fuel foil, and the thickness of the molybdenum only foils and the Lucite moderating layers were iterated upon until a critical system with the maximum amount of molybdenum metal was achieved. Additionally the thickness of the graphite reflector was doubled. This design includes approximately 7 times the molybdenum as the initial thermal critical experiment design, while maintaining a highly thermalized neutron spectrum. Figures 50

and 51 below give the model design and calculated neutron spectrum as compared to the standard thermal critical experiment design respectively.




Figure 50) Thermal Maximum Molybdenum Critical Experiment MCNP Model




Figure 51) Spectra for Standard and Maximum Molybdenum Thermal Critical Experiments

As expected, dips in the neutron spectra due to resonance effects from molybdenum isotopes are more pronounced in the design with maximum molybdenum content. Additionally, the spectrum is more thermalized for the Maximum Molybdenum design as compared to the Standard Molybdenum design, which is to be expected as additional hydrogenous moderating material was required to achieve criticality. The spectrum of the Maximum Molybdenum Thermal Critical Experiment is orders of magnitude more thermalized than existing critical experiments utilizing U-Mo fuel.

As with the fast spectrum designs, the thermal critical experiment systems were modeled in SCALE to take advantage of its TSUNAMI sensitivity and uncertainty package. Figures 52 through 58 below give the sensitivity per unit lethargy for each of the natural molybdenum isotopes for both thermal spectrum critical experiment designs

as well as the most thermalized ORNL FBR critical experiment, ORNL FBR Critical Experiment #4.




Figure 52)  $^{92}\text{Mo}$  Sensitivity for Thermal Spectra Critical Experiment Designs




Figure 53)  $^{94}\text{Mo}$  Sensitivity for Thermal Spectra Critical Experiment Designs




Figure 54)  $^{95}\text{Mo}$  Sensitivity for Thermal Spectra Critical Experiment Designs




Figure 55)  $^{96}\text{Mo}$  Sensitivity for Thermal Spectra Critical Experiment Designs




Figure 56)  $^{97}\text{Mo}$  Sensitivity for Thermal Spectra Critical Experiment Designs




Figure 57)  $^{98}\text{Mo}$  Sensitivity for Thermal Spectra Critical Experiment Designs




Figure 58)  $^{100}\text{Mo}$  Sensitivity for Thermal Spectra Critical Experiment Designs

Similar to the fast spectra designs, the existing ORNL FBR critical experiment shows greater sensitivity to molybdenum in the fast energy region. This is to be expected, as the spectrum of the ORNL experiment is still orders of magnitude faster than either of the proposed thermal designs. The Thermal Standard Molybdenum Critical Experiment design overall demonstrates low sensitivity to the molybdenum isotopes. This is primarily due to the overriding sensitivity effects of hydrogen in the heavily moderated system, as seen below in figure 59. Additionally, there are simply few molybdenum atoms in the system as compared to the two other thermal critical experiments.






Figure 59) <sup>1</sup>H Sensitivity for Thermal Spectra Critical Experiment Designs

However, the Thermal Maximum Molybdenum Critical Experiment demonstrates high levels of sensitivity to the molybdenum isotopes, especially throughout the resonance region. The influence of large individual resonances can be clearly seen for most of the molybdenum isotopes. Table 16 below gives integral sensitivity values for the Standard and Maximum Molybdenum critical experiment designs. Sensitivity to molybdenum increased by nearly two orders of magnitude for some isotopes in the Maximum Molybdenum critical experiment design.

Table 16) Integral Molybdenum Isotope Sensitivity for Standard and Maximum Molybdenum Critical Experiment Designs

<b>Isotope</b>	<b>Standard Molybdenum Design</b>	<b>Maximum Molybdenum Design</b>
<sup>92</sup> Mo	2.745E-05	-7.029E-05
<sup>94</sup> Mo	-6.435E-05	-1.695E-03
<sup>95</sup> Mo	-8.040E-03	-1.317E-01
<sup>96</sup> Mo	-7.686E-04	-6.348E-03
<sup>97</sup> Mo	-1.108E-03	-1.546E-02
<sup>98</sup> Mo	-5.632E-04	-3.272E-03
<sup>100</sup> Mo	-1.190E-04	-1.127E-03

A numerical quantification of the proposed critical experiment system response to molybdenum cross-section uncertainty is given below in table 17, which shows the difference in multiplication factor of the experimental system modeled using molybdenum cross-section data from three different libraries: ENDF/B VII.1, JEFF3.3, and JENDL3.0.

Table 17) Differences in Modeled Thermal Critical Experiment  $K_{eff}$  Due to Cross Section Library

	<b>Thermal Standard</b>		<b>Thermal Max</b>		<b>ORNL FBR #4</b>	
	$K_{eff}$		$K_{eff}$		$K_{eff}$	
ENDF	0.99801		1.00026		1.00999	
JEFF	0.99795		1.00115		1.00987	
JENDL	0.99830		0.99984		1.01076	
	<i>del K/K</i>	<i>pcm</i>	<i>del K/K</i>	<i>pcm</i>	<i>del K/K</i>	<i>pcm</i>
ENDF vs JEFF	-0.00006	-6.41316	0.00089	88.89777	-0.00012	-11.88270
ENDF vs JENDL	0.00029	29.04933	-0.00042	-42.00672	0.00076	76.18030
JENDL vs JEFF	0.00035	35.46021	-0.00131	-131.02096	0.00088	88.05255

Despite its low sensitivity to the molybdenum isotopes, the Thermal Standard Molybdenum critical experiment design exhibits deviation in multiplication factor of roughly the same order of magnitude as the fast spectrum critical experiment designs. However, the Thermal Maximum Molybdenum critical experiment design exhibits the largest deviation in multiplication factor of any critical experiment design, either existing or proposed.

## **CONCLUDING REMARKS**

A series of critical experiments is proposed to address deficiencies in the current library of evaluated criticality benchmarks with regards to sensitivity to molybdenum isotopes, especially in thermal neutron spectra, as constituent fuel material, as in the new U(19.5%)-10Moly alloy foil fuel form. Four experiments are proposed:

- 1) A fast spectrum system comprised of U-Moly foils and HEU.
- 2) An intermediate-to-fast spectrum system comprised of U-Moly foils and HEU, reflected by graphite.
- 3) A thermalized spectrum experiment interleaving U-Moly foils with Lucite moderator layers, all reflected by graphite.
- 4) A highly thermalized spectrum experiment interleaving U-Moly foils with Lucite moderator layers and layers of molybdenum metal, all reflected by graphite.




Figure 60) Calculated Spectra for Proposed Critical Experiment Designs

Figure 60 above compares the MCNPX calculated spectra for the proposed critical experiments, normalized by peak channel. The proposed thermal spectrum systems exhibits sensitivity to molybdenum cross-section changes at low neutron energies which no experiment currently in the ICSBEP includes. Additionally, comparison between the four critical experiments may help determine energy regions of high molybdenum cross-section uncertainty. Such improved uncertainty data should aid modeling efforts of nuclear systems utilizing uranium-molybdenum alloy fuels in the future such as the Advanced Test Reactor at Idaho National Laboratory and the High Flux Isotope Reactor at Oak Ridge National Laboratory.

## **Chapter 4: Covariance Data Generation**

To go from raw experimental data, with its inherent uncertainty, to evaluated nuclear data usable in system modeling requires many steps, through which the data uncertainties must be propagated. This associated uncertainty must be retained as covariance data within the ENDF files. The current ENDF data format includes two means of recording cross section covariance data: parameter-wise covariance data in file 32 and group-wise covariance data in file 33 [2][3]. Both of these file formats have advantages, and both must often be used in tandem to fully describe an isotope's cross-section uncertainty data.

In this section, a method is demonstrated for generating complete covariance data sets, including both files 32 and file 33 formatted data, for the natural isotopes of molybdenum. The retroactive covariance method of the SAMMY R-matrix analysis code is used to generate the resonance parameter-wise uncertainty and correlations found in file 32 from experimental data. A combination of integral measurement uncertainty, a dispersion method, and high energy covariances produced with the Empire-KALMAN code is used to generate the group-wise file 33 covariance data.

### **FILE 32 FORMAT COVARIANCE DATA**

#### **RPI Experimental Data**

A series of transmission and capture yield experiments were completed at the RPI LINAC facility using a natural molybdenum target. The primary purpose of that work was to generate an improved set of resonance parameters for the molybdenum isotopes.

A majority of current experimental cross-section evaluations, including the RPI natural molybdenum measurements, do not retain their resonance parameter covariance matrix. However, the functionality exists in SAMMY to retroactively generate these missing covariance matrices. The first step in generating covariance data for experimental data is to generate a fit to the experimental data using SAMMY. In general, this process can be lengthy, as an initial “guess” of resonance parameters must be obtained, either through a parameter estimation code such as RSAP, or by using a parameter set from a prior evaluation. Manual adjustment of parameters and addition of parameters for resonances that were not included previously must then be undertaken over the course of many SAMMY runs to generate the final best fit set of resonance parameters. However, this process was significantly shortened for this work, as a set of resonance parameters for the experimental data had already been produced and published in Ref. [34].

The initial goal was therefore to duplicate the SAMMY results of Ref. [34], including effects of experimental resolution and Doppler broadening, self-shielding, and multiple-scattering events. Doing so required knowledge of the experimental conditions, which are detailed in tables 18 and 19.

Table 18) Molybdenum Experimental Details

Experiment	Overlap Filter	Neutron Producing Target	Electron Pulse Width (ns)	Average Beam Current ( $\mu$ A)	Beam Energy (MeV)	Energy Region	Channel Width ( $\mu$ S)	Pulse Repetition Rate	Flight Length Path (m)
Epithermal Transmission 2004	Boron Carbide	Bare Bounce	47	23	52	E < 38 eV 38 eV <E<148eV E>148 eV	0.5 0.125 0.03125	225	25.596
Epithermal Transmission 1995	Boron Carbide	Old Bounce	47	26	50	E<28 eV E>148 eV	0.5 0.03125	250	25.53
Epithermal Capture 1995	Boron Carbide	Old Bounce	100	36	50 - 60	E<28 eV E>148 eV	0.5 0.03125	200	25.567

Table 19) Elemental Metal Molybdenum Samples

Nominal Thickness (mm)	Atom Density (atoms/b)	Uncertainty (atoms/b)	Measurements
0.051	3.088E-04	1E-07	Capture 10 to 600 eV
0.127	7.897E-04	1.6E-06	1995 transmission 10 to 200 ev, capture 10 to 600 eV
0.254	1.642E-03	2E-06	1995 transmission 10 to 200 ev, capture 10 to 600 eV
0.508	3.259E-03	4E-06	Capture 10 to 600 eV
0.635	4.077E-03	4E-06	1995 transmission 10 to 200 ev
1.27	8.160E-03	8E-06	1995 transmission 10 to 200 ev
2.54	1.649E-02	2E-05	1995 transmission 10 to 200 ev, 2004 transmission 10 to 2000 eV
5.08	3.142E-02	3E-05	1995 transmission 10 to 200 ev
6.35	3.958E-02	3E-05	2004 transmission 10 to 2000 eV

### Analysis with SAMMY

The initial step to generating resonance wise covariance data was to reproduce the resonance parameter fit to the experimental data as reported by the RPI experimentalists. This was accomplished for the 2004 0-2000 eV transmission data and the 1995 0-600 eV capture data, shown below in figures 61 and 62 respectively.




Figure 61) SAMMY fit to 2004 Natural Molybdenum Transmission Data




Figure 62) SAMMY fit to 1995 Natural Molybdenum Capture Data



Once this SAMMY fit was optimized to match the RPI experimentalists resonance parameter set, subsequent SAMMY runs were completed for each isotope of interest in which the resonance parameters in the energy region covered by both transmission and capture data are allowed to vary, i.e. 0-600 eV. This generates the experimental data covariance matrix  $V$ . Additionally, other sources of uncertainty, such as normalization, background, and resolution function are propagated using SAMMY's PUP (Propagated Uncertainty Parameter) feature. Finally, the experimental covariance matrix and PUP'ed uncertainty information is saved as the  $Y$  and  $W$  matrices detailed earlier in the description of SAMMY's Bayesian fitting scheme

Using the generated  $Y$  and  $W$  matrices, a final SAMMY run is completed with the option of generating ENDF formatted File 32 covariance data. This is resonance parameter-wise covariance data for the resonances varied in the 0-600 eV energy range. This energy range does not cover the entire resolved resonance region for any of the natural molybdenum isotopes. However, for most isotopes, it does capture the effects of the large low lying resonances. While this does not result in a perfect representation of the resonance-wise covariance data, it does produce the best possible set of covariance data given the experimental data available. An example is given below in figure 63 for  $^{97}\text{Mo}$ .




Figure 63) ENDF/B-VII.1  $^{97}\text{Mo}$  Total Cross Section, 0-600 eV highlighted

In order to visualize the resonance parameter covariance data produced by the retroactive method of SAMMY, it is helpful to convert it to group-wise covariance data. Flux weighted group cross-sections are defined as:

$$\bar{\sigma}_{xg} \Phi_g = \int_{E_g}^{E_{g+1}} \sigma_x(E) \Phi(E) dx \quad (28)$$

Where

$$\Phi_g = \int_{E_g}^{E_{g+1}} \Phi(E) dx \quad (29)$$

$\Phi_g$  is the neutron flux in group  $g$ , and  $\bar{\sigma}_{xg}$  is the flux weighted group cross section for reaction  $x$  and group  $g$ . The corresponding group covariance matrix is calculated by taking the expectation value of the product of small increments in the group cross-section with respect to resonance parameters.

$$\overline{\delta\sigma_{xg}} = \sum_j \frac{\partial \sigma_{xj}}{\partial p_j} \delta p_j \quad (30)$$

$$\langle \overline{\delta\sigma_{xg}} \overline{\delta\sigma_{xg'}} \rangle = \sum_{jk} \frac{\partial \sigma_{xj}}{\partial p_j} \langle \delta p_j \delta p_k \rangle \frac{\partial \sigma_{xk}}{\partial p_k} \quad (31)$$

In which

$$\langle \delta p_j \delta p_k \rangle = M'_{jk}$$

is the retroactive resonance parameter covariance matrix element for parameters  $j$  and  $k$ . [35]

Such a group-wise covariance matrix for the total cross-section in the resonance region of  $^{97}\text{Mo}$  is plotted below in the SCALE 44 group structure as an example. It is compared with the covariance data currently available in ENDF/B-VII.1. Current covariance data assumes complete correlation between all energy regions, whereas the retroactively generated covariance data exhibits a much more detailed correlation structure. This is seen in the central images of figures 64 and 65. These correlation matrices contains values that can vary between -1 and 1, and record the degree to which the uncertainty in a given energy group is correlated with the uncertainty in all other energy groups. The uncertainty in each energy group is plotted above the correlation matrix in figures 64 and 65. The vector product of the uncertainty values and the correlation matrix yields the covariance matrix. Similar plots for total, capture, and elastic scattering for the natural isotopes of molybdenum are included in appendix A.




Figure 64)  $^{97}\text{Mo}$  Total Retroactive Resolved Resonance Covariance




Figure 65)  $^{97}\text{Mo}$  Total Current ENDF/B-VII.1 Covariance

### **FILE 33 FORMAT COVARIANCE DATA**

Retroactively generated resonance parameter covariance matrices show significant improvement in correlation fidelity as compared to current covariance libraries which assume total correlation across all energy ranges. However, this covariance data often has low uncertainties, uncertainties that are often too low to be considered physical by end users, and are in fact below the minimum reasonable uncertainty values defined by the Cross Section Evaluation Working Group. [36] This low uncertainty can result from missing or unknown sources of uncertainty in the retroactive covariance generation process.

Additionally, by definition the resonance parameter covariance matrix only applies to the resolved resonance region as defined by its parameters. Other covariance data will be needed in the high energy region. The end goal then is to couple the high fidelity correlations of the retroactive resonance parameter covariance matrix with reasonable uncertainty values that will be accepted by end users, and to provide covariance data throughout all energy regions of interest.

To accomplish this, uncertainty data from three additional sources was incorporated: integral measurements at thermal and resonance energies, a dispersion analysis of select general use nuclear data libraries in the resonance region, and high energy covariances generated at Brookhaven National Laboratory using the Empire-KALMAN code.

## Integral Measurement Uncertainty

Integral measurements' uncertainties are tabulated in the Atlas of Neutron Resonance Parameters and provide an additional connection with uncertainty data from experimental sources. The Atlas of Neutron Resonances Parameters is compiled by researchers at Brookhaven National Laboratory, and contains recommended cross-section resonance parameters drawn from all pertinent and available experimental sources. Evaluated neutron interaction data for all elements is included, along with uncertainties. The most important quantities included in the Atlas for this work are:

- Thermal cross-sections (total, capture) with uncertainties
- Scattering radii, with uncertainties
- Resonance integrals (capture), with uncertainties

These values can serve as a check of the reasonableness of calculated uncertainty data, as well as providing direct cross-section uncertainty data in the thermal energy region for evaluations with unreasonably low uncertainty.

Table 20 below summarizes key integral uncertainty values for the natural molybdenum isotopes.

Table 20) Integral Uncertainties for Natural Molybdenum Isotopes [37]

	<b>2200 m/s Cross Section</b>	<b>Thermal Capture</b>	<b>Scattering Radius</b>	<b>Resonance Integral</b>
<sup>92</sup> Mo	2.33%	25.00%	2.86%	N/A
<sup>94</sup> Mo	2.06%	17.65%	2.90%	N/A
<sup>95</sup> Mo	5.70%	2.24%	2.86%	5.93%
<sup>96</sup> Mo	1.86%	40.00%	2.88%	17.65%
<sup>97</sup> Mo	2.12%	9.09%	2.90%	20.83%
<sup>98</sup> Mo	2.20%	4.62%	2.90%	4.48%
<sup>100</sup> Mo	2.11%	1.51%	2.90%	3.99%

In constructing file 33, values from the first three columns of table 1 were used as the diagonal values of the covariance matrix in the thermal energy region, from  $10^{-5}$  eV to 0.05 eV, for total, capture, and scattering interaction cross-sections respectively for energy groups where the file 32 covariance data reported an uncertainty below the acceptable limits as defined by the Cross Section Evaluation Working Group.

### **Dispersion Method**

The method described previously to generate the file 32 format covariances is based on a rigorous analytical fitting to the RPI experimental data. Such a fitting procedure produces improved cross-section values, but can frequently also produce low uncertainties and covariances. Such low covariances are often subject to questioning by end users. To address this issue, the National Nuclear Data Center has taken to considering the dispersion between evaluations when generating covariance libraries.

Dispersion methods consider the dispersion between evaluations as a further basis for uncertainty estimation. The concept is that the spread between independently evaluated cross-sections from the major data libraries reflect the true opinion of the international community of evaluators with respect to the cross-section precision. Low uncertainties are therefore expanded to reflect the spread between the major data libraries. [38][39][40] Advantages of this process include relative simplicity and ease of use, as well as considerable transparency. Practically, dispersion methods produce uncertainty estimates in line with the expectations of end users.

In order to complete a dispersion method analysis for the natural molybdenum isotopes, the 6 modern general use cross-section libraries available through the Nuclear

Energy Agency's online data bank were selected. Those libraries were ENDF/B-VII.1, JEFF-3.1.2, JENDL-4.0, RUSFOND-2010, CENDL-3.1, and TENDL2012.

Total, capture, and elastic scattering cross-sections for all natural isotopes of molybdenum from each of the above libraries were collapsed to the SCALE 44-group structure. The group-wise relative standard deviation across the independent evaluations was then calculated and were assigned as the diagonal values of the covariance matrix in the resonance energy region, from 0.05 eV to 25 keV, for their respective interactions where the file 32 covariance data reported an uncertainty below the acceptable limits as defined by the Cross Section Evaluation Working Group.

### **Empire-KALMAN High Energy Covariances**

In the high energy region, model based covariances have been generated using the coupled Empire-KALMAN codes at Brookhaven National Laboratory. This code operates similarly to SAMMY, and generates covariance data based on parameters of high energy region interaction models. [41] EMPIRE includes a range of nuclear reaction models, such as the s the spherical optical model, Coupled Channels, Distorted Wave Born Approximation, Multi-step Direct, Multi-step Compound, the exciton model with preequilibrium emission of clusters and gamma rays, and the full featured Hauser-Feshbach(HF) model with multi-particle emission and detailed  $\gamma$ -cascade. KALMAN is a Bayesian code based on the theory of the Kalman filter, which can estimate covariances by combining experimental uncertainties and correlations with theory predictions. KALMAN calculates cross section covariances  $P$  in two steps: (i) the model parameter covariance matrix  $X$  is calculated from the experimental covariances  $V$ , and (ii) the error



propagation is used to calculate cross section covariances  $P$  from the model parameter covariances  $X$ :

$$P = (X^{-1} + C^t V^{-1} C)^{-1} = X - X C^t (C X C^t + V)^{-1} C X \quad (32)$$

where  $C$  is the sensitivity matrix describing response of the model to the perturbation of its parameters. To obtain the sensitivity matrix  $C$  EMPIRE is used to perturb 10-15 of the most relevant model parameters, such as optical model, level density, or preequilibrium strength, by roughly  $\pm 5\%$  to determine their effect on the cross-sections for total, elastic, capture, etc. Sensitivity matrix elements are calculated from the change in a given cross section due to the change in a given model parameter. Model parameter uncertainties are adjusted to reproduce experimental cross-section uncertainties and covariance data.

This set of covariance data is the highest fidelity uncertainty data available for the high energy region of the molybdenum isotopes, and is currently included in ENDF/B-VII.1. The uncertainty values reported by BNL were assigned as the diagonal values of the covariance matrix in the high energy region, from 25 keV to 20 MeV.

Through combination of integral measurement uncertainty, dispersion method analysis, and the high energy covariances of the Empire-KALMAN code, a complete set of covariance data of reasonable magnitude spanning  $10^{-5}$  eV to 20 MeV was generated for the natural molybdenum isotopes. Shown below in figure 66 and 67 as an example is the total cross-section for  $^{97}\text{Mo}$ , again compared to the current ENDF/B-VII.1 covariance data. Correlation throughout the resonance region is strictly along the diagonal, as compared to the complete correlation assigned currently in ENDF/B-VII.1. Off diagonal correlation will be regained by combining the retroactively generated file 32 data with the diagonal file 33 data. Apparent correlation at thermal energies is due to round off error

from NJOY processing. Similar plots for total, capture, and elastic scattering for the natural isotopes of molybdenum are included in appendix A.




Figure 66)  $^{97}\text{Mo}$  Total File 33 Covariance




Figure 67)  $^{97}\text{Mo}$  Total Current ENDF/B-VII.1 Covariance

## Concluding Remarks

Currently only the ENDF/B-VII.1 nuclear data library includes cross-section covariance data for the natural molybdenum isotopes. However, this covariance data lacks meaningful correlation information as well as granularity in its diagonal uncertainty values. Using the retroactive method of SAMMY with experimental transmission and capture data for natural molybdenum, correlation in the resonance region between resonance parameters was regained, and this information was stored in ENDF File 32 format. Additionally, using a combination of integral measurement uncertainty, dispersion calculations between major library evaluation, and high energy covariances produced with the Empire-KALMAN code, a complete set of reasonable magnitude molybdenum isotope covariance data was produced for the energy range  $10^{-5}$  eV to 20 MeV and was stored in ENDF File 33 format.

Figure 68 and 69 below compare the complete high fidelity covariance library (file 32 and file 33 combined) for  $^{97}\text{Mo}$  to the current low fidelity covariance library available in ENDF/B-VII.1.

The combined file 32 and file 33 formatted covariance library for the molybdenum isotopes can now be used in sensitivity and uncertainty studies of the designed U-Moly foil fuel form critical experiments.




Figure 68)  $^{97}\text{Mo}$  Total Cross Section CVDH Covariance Data




Figure 69)  $^{97}\text{Mo}$  Total Cross Section LOFI Covariance Data

## **ANALYTICAL COMPARISON OF LOW FIDELITY AND HIGH FIDELITY MOLYBDENUM COVARIANCE DATA**

Having constructed the improved fidelity molybdenum isotope covariance library, the final step is now to compare the accuracy of this covariance library to the existing low-fidelity library currently available. The designed U-Moly critical experiments offer a means to make such a comparison, using the TSURFER module of SCALE.

As before, the TSURFER module makes use of sensitivity profiles for modeled critical experiments generated by the TSUNAMI module of SCALE. These sensitivity profiles store the sensitivity of integral measurements, in this case multiplication factor, to changes in the group-wise cross-sections of the materials making up the critical experiment. TSURFER then calculates the set of cross-section changes, bounded by covariance data, which minimizes the difference between calculated and experimental reported multiplication factors across the critical experiments of interest.

However, in order to make a comparison between covariance libraries an additional capability of TSURFER is required. TSURFER makes a distinction between “experiments”, for which both a calculated and experimental multiplication factor are known, and “applications” for which only calculated multiplication factor is known. The set of cross-section changes TSURFER calculates from the set of experiments can be applied to the set of applications, resulting in an updated multiplication factor, as well as a reported “bias,” the change in  $k_{\text{eff}}$  due to the cross-section changes which ultimately stem from the cross-section uncertainty reported in the covariance data. More accurate cross-section data and cross-section covariance data will result in an improved fit to experimental results as well as influencing the reported bias. Therefore covariance

libraries can be compared based on the goodness-of-fit to experimental results as well as the bias reported by TSURFER.

### **Cross-section and Covariance Processing**

The high fidelity molybdenum covariance library generated is tied to the set of resonance parameters reported by the RPI experimentalists through the file 32 covariances. The first step was to incorporate those resonance parameters and covariance information into an ENDF file.

As before, ENDF/B-VII.1, JEFF 3.1.1, and JENDL 4.0 evaluated nuclear data files were selected as the basis for the molybdenum nuclear data. The RPI experimental resonance parameters, file 32 and file 33 covariance data for total, elastic scattering, and capture reactions were inserted into the appropriate data files. Additionally, the low fidelity covariance data for the threshold reactions of inelastic scattering and (n,2n) was inserted into the JEFF 3.1.1 and JENDL 4.0 nuclear data files in order to ensure a one-to-one comparison with the ENDF/B-VII.1 nuclear data files, which already included this covariance data.

After combining the nuclear data files with the RPI resonance parameters and high fidelity covariance data, the cross-section data processing code AMPX was used to generate cross-section and covariance libraries for the SCALE analysis code. The SCALE module TSUNAMI was then used to regenerate the sensitivity profiles for the molybdenum sensitive critical experiments from the ICSBEP and the ORNL FBR program for each of the evaluated nuclear data libraries. The SCALE module TSURFER was then used with the regenerated sensitivity profiles and ENDF, JEFF, and JENDL

based covariance libraries to calculate the goodness-of-fit between the calculated results using the cross-section data and the reported experimental results.

TSURFER reports its goodness-of-fit metric in terms of the value of chi squared per degree of freedom. In order to maintain consistency across the set of experimental data, the SCALE manual recommends a maximum chi squared value per degree of freedom of 1.2. This sets the bounds of possible cross-section adjustment in terms of the cross-section covariance data. In order to achieve this maximum chi squared value, TSURFER eliminates experimental responses until chi squared per degree of freedom is less than 1.2. The individual experimental responses make up the degrees of freedom.

In order to ensure a one to one comparison between the three sets of cross-section and covariance data three initial TSURFER runs were completed with the respective data sets and the recommended chi squared limit of 1.2. Using the JENDL based data resulted in the most degrees of freedom (experimental responses considered) while not exceeding the limit on chi squared. The limit on chi squared was then relaxed for the ENDF and JEFF data sets until all three data sets utilized the same set of experimental responses. Table 21 below compiles the goodness-of-fit results of the described TSURFER runs.

Table 21)  $\chi^2$  for ENDF, JEFF, and JENDL

	ENDF	JEFF	JENDL
$\chi^2$ per degree of freedom	2.336E+00	2.707E+00	1.195E+00

Based on its closest fit to the experimental data, JENDL 4.0 was selected as the basis for the cross-section and covariance data moving forward.



## Goodness-of-Fit and Bias Comparison

Making comparisons of covariance data sets can be challenging, especially in cases where differences in cross-section data are also present. In the case at hand, cross-section differences in the form of the RPI resonance parameters play a role. If the RPI resonance parameters are assumed to be superior to the current set of resonance parameters in ENDF/B-VII.1 (unchanged from ENDF/B-VII.0, and used in the default SCALE 238 group library), then calculated multiplication factors should better match reported experimental values, and TSURFER should report a reduced bias, regardless of covariance data used. Similarly, if the high-fidelity covariance data is a more accurate reflection of the general uncertainty associated with molybdenum cross-section data then TSURFER should report a reduced bias when the high-fidelity covariance data is used, regardless of cross-section data. However, this assumption may be complicated by the fact that the high-fidelity covariance data is tied to the RPI resonance parameters through the file 32 covariance data. Finally, when both the superior cross-section data (RPI resonance parameters) and high fidelity covariance data is used, the reported bias should be the least as compared to all other combinations of cross-section and covariance data. Tables 22 through 25 below summarize the TSURFER bias results for the possible combinations discussed above.

Table 22) TSURFER bias: ENDF/B-VII.1 cross-sections and low fidelity covariance data

<b>NAME</b>	<b><i>CALCULATED k<sub>eff</sub> VALUE</i></b>	<b><i>INITIAL STANDARD DEVIATION</i></b>	<b><i>ADJUSTED k<sub>eff</sub> VALUE</i></b>	<b><i>ADJUSTED STANDARD DEVIATION</i></b>	<b><i>EFFECTIVE BIAS</i></b>	<b><i>ABSOLUTE BIAS</i></b>
Fast Bare	9.9779E-01	1.07E-02	9.9953E-01	2.77E-03	-1.74E-03	1.20E-02
Fast Reflected	9.9870E-01	2.04E-02	1.0121E+00	5.09E-03	-1.34E-02	1.75E-02
Thermal Standard	9.9871E-01	4.89E-03	9.9874E-01	2.12E-03	-3.48E-05	8.03E-03
Thermal Max	9.9687E-01	5.96E-03	9.9632E-01	4.17E-03	5.50E-04	5.65E-03

Table 23) TSURFER bias: ENDF/B-VII.1 cross-sections and high fidelity covariance data

<b>NAME</b>	<b><i>CALCULATED k<sub>eff</sub> VALUE</i></b>	<b><i>INITIAL STANDARD DEVIATION</i></b>	<b><i>ADJUSTED k<sub>eff</sub> VALUE</i></b>	<b><i>ADJUSTED STANDARD DEVIATION</i></b>	<b><i>EFFECTIVE BIAS</i></b>	<b><i>ABSOLUTE BIAS</i></b>
Fast Bare	9.9779E-01	1.07E-02	9.9967E-01	2.77E-03	-1.88E-03	1.28E-02
Fast Reflected	9.9870E-01	2.04E-02	1.0133E+00	4.98E-03	-1.46E-02	1.89E-02
Thermal Standard	9.9871E-01	4.89E-03	9.9878E-01	2.12E-03	-7.00E-05	7.94E-03
Thermal Max	9.9687E-01	5.96E-03	9.9654E-01	2.75E-03	3.36E-04	5.32E-03

Table 24) TSURFER bias: RPI resonance parameters and low fidelity covariance data

<b>NAME</b>	<b><i>CALCULATED k<sub>eff</sub> VALUE</i></b>	<b><i>INITIAL STANDARD DEVIATION</i></b>	<b><i>ADJUSTED k<sub>eff</sub> VALUE</i></b>	<b><i>ADJUSTED STANDARD DEVIATION</i></b>	<b><i>EFFECTIVE BIAS</i></b>	<b><i>ABSOLUTE BIAS</i></b>
Fast Bare	9.9795E-01	1.07E-02	1.0001E+00	2.80E-03	-2.13E-03	3.64E-03
Fast Reflected	9.9860E-01	2.03E-02	9.9805E-01	4.88E-03	5.57E-04	3.72E-03
Thermal Standard	9.9828E-01	4.91E-03	1.0029E+00	2.13E-03	-4.66E-03	4.07E-03
Thermal Max	9.9765E-01	5.11E-03	1.0014E+00	4.22E-03	-3.76E-03	4.63E-03

Table 25) TSURFER bias: RPI resonance parameters and high fidelity covariance data

<b>NAME</b>	<b><i>CALCULATED k<sub>eff</sub> VALUE</i></b>	<b><i>INITIAL STANDARD DEVIATION</i></b>	<b><i>ADJUSTED k<sub>eff</sub> VALUE</i></b>	<b><i>ADJUSTED STANDARD DEVIATION</i></b>	<b><i>EFFECTIVE BIAS</i></b>	<b><i>ABSOLUTE BIAS</i></b>
Fast Bare	9.9795E-01	1.07E-02	1.0001E+00	2.80E-03	-2.17E-03	3.71E-03
Fast Reflected	9.9860E-01	2.03E-02	9.9803E-01	4.75E-03	5.77E-04	3.74E-03
Thermal Standard	9.9828E-01	4.91E-03	1.0029E+00	2.13E-03	-4.65E-03	3.98E-03
Thermal Max	9.9765E-01	5.11E-03	1.0015E+00	2.78E-03	-3.82E-03	4.59E-03

Tables 22 through 25 list effective and absolute bias values for each proposed critical experiment design. The effective bias is the sum of all the biases from the individual isotope, reaction pairs possible in the experiment. The signs for these biases can be positive or negative, and can therefore cancel each other out in the effective bias. The absolute bias is the sum of the absolute values of the individual biases. For ease of comparison, figure 70 below compiles the last column of tables 22 through 25.




Figure 70) Absolute Bias Comparison across Experiment Designs and Nuclear Data Sets

As can be seen in figure 70, there is generally a reduction in bias when the JENDL based cross section data is used, indicating that the combination of RPI resonance parameters and JENDL cross-section data is an improvement on the ENDF/B-VII.1 data. The comparison of covariance libraries is less clear cut, for the fast spectrum results the bias is slightly greater for the low fidelity covariance data set, while for the thermal spectrum cases bias is reduced for the high fidelity covariance case. To reiterate: only the initial molybdenum isotope cross-section data and covariance data varies among the above cases, all other cross-section and covariance data is constant.

To gain a clearer understanding of the effects of the high fidelity covariance data on molybdenum associated biases, tables 26 through 29 and figures 71 through 74 below

compile the total absolute bias for each molybdenum isotope for each combination of cross-section and covariance data for each proposed critical experiment design. In all cases and for all the molybdenum isotopes the absolute bias is reduced when the high fidelity covariance data is used in conjunction with the RPI resonance parameters as compared to the current cross-section data and covariance data. Additionally, for a clear majority of the molybdenum isotopes across the four experiment designs the absolute bias is reduced when the RPI resonance parameters are used in conjunction with the high fidelity covariance data as compared to the current low fidelity data.

Table 26) Total Bias for Molybdenum Isotopes for Fast Bare Critical Experiment Design

	RPI XS & CVDH COV	RPI XS & LOFI COV	ENDF/B-VII.1 & CVDH COV	ENDF/B-VII.1 & LOFI COV
<sup>92</sup> Mo	7.47E-06	8.23E-06	8.79E-06	9.64E-06
<sup>94</sup> Mo	2.45E-06	3.01E-06	6.39E-06	4.65E-06
<sup>95</sup> Mo	2.15E-05	5.27E-05	3.68E-05	3.40E-05
<sup>96</sup> Mo	1.07E-05	1.07E-05	2.10E-05	1.57E-05
<sup>97</sup> Mo	2.45E-05	4.01E-05	2.36E-05	2.38E-05
<sup>98</sup> Mo	1.31E-05	1.27E-05	3.01E-05	2.24E-05
<sup>100</sup> Mo	2.96E-06	2.79E-06	4.28E-06	3.51E-06
All Mo	8.26E-05	1.30E-04	1.31E-04	1.14E-04




Figure 71) Molybdenum Isotope Bias Comparison across Nuclear Data Sets for Fast Bare Critical Experiment Design

Table 27) Total Bias for Molybdenum Isotopes for Fast Reflected Critical Experiment

	RPI XS & CVDH COV	RPI XS & LOFI COV	ENDF/B-VII.1 & CVDH COV	ENDF/B-VII.1 & LOFI COV
<sup>92</sup> Mo	4.34E-06	4.40E-06	1.38E-05	1.71E-05
<sup>94</sup> Mo	1.50E-06	1.75E-06	1.15E-05	7.41E-06
<sup>95</sup> Mo	8.87E-06	1.48E-05	9.55E-05	1.17E-04
<sup>96</sup> Mo	6.12E-06	6.73E-06	3.40E-05	3.06E-05
<sup>97</sup> Mo	7.03E-06	1.11E-05	9.11E-05	1.06E-04
<sup>98</sup> Mo	9.29E-06	9.83E-06	3.10E-05	2.68E-05
<sup>100</sup> Mo	2.30E-06	2.39E-06	2.16E-06	2.38E-06
All Mo	3.95E-05	5.10E-05	2.79E-04	3.08E-04




Figure 72) Molybdenum Isotope Bias Comparison across Nuclear Data Sets for Fast Reflected Critical Experiment Design

Table 28) Total Bias for Molybdenum Isotopes for Thermal Standard Critical Experiment

	RPI XS & CVDH COV	RPI XS & LOFI COV	ENDF/B-VII.1 & CVDH COV	ENDF/B-VII.1 & LOFI COV
<sup>92</sup> Mo	1.06E-06	1.34E-06	2.24E-06	3.89E-06
<sup>94</sup> Mo	3.42E-07	3.21E-07	2.74E-06	1.78E-06
<sup>95</sup> Mo	3.19E-06	1.11E-05	4.24E-05	6.97E-05
<sup>96</sup> Mo	4.55E-06	5.67E-06	2.74E-05	3.35E-05
<sup>97</sup> Mo	6.05E-07	8.43E-06	2.64E-05	4.77E-05
<sup>98</sup> Mo	2.36E-06	1.61E-06	1.27E-05	1.02E-05
<sup>100</sup> Mo	5.98E-07	1.17E-07	2.72E-06	2.41E-06
All Mo	1.27E-05	2.86E-05	1.16E-04	1.69E-04




Figure 73) Molybdenum Isotope Bias Comparison across Nuclear Data Sets for Thermal Standard Critical Experiment Design



Table 29) Total Bias for Molybdenum Isotopes for Thermal Max Critical Experiment

	RPI XS & CVDH COV	RPI XS & LOFI COV	ENDF/B-VII.1 & CVDH COV	ENDF/B-VII.1 & LOFI COV
<sup>92</sup> Mo	2.97E-05	2.56E-05	2.27E-05	3.19E-05
<sup>94</sup> Mo	7.46E-06	8.10E-06	2.97E-05	1.44E-05
<sup>95</sup> Mo	1.77E-05	5.35E-05	2.16E-04	3.47E-04
<sup>96</sup> Mo	3.23E-05	3.44E-05	1.03E-04	1.45E-04
<sup>97</sup> Mo	1.51E-05	2.28E-05	1.87E-04	3.08E-04
<sup>98</sup> Mo	4.62E-05	4.70E-05	1.10E-04	7.54E-05
<sup>100</sup> Mo	1.02E-05	1.05E-05	2.08E-05	1.45E-05
All Mo	1.59E-04	2.02E-04	6.89E-04	9.36E-04




Figure 74) Molybdenum Isotope Bias Comparison across Nuclear Data Sets for Thermal Max Critical Experiment Design




Figure 75) Total Molybdenum Bias

Finally, figure 75 above displays the total absolute bias for elemental molybdenum across the four proposed critical experiment designs and four combinations of cross-section and covariance data. The clear trend is a reduction in bias associated with molybdenum due to the use of improved cross-section and covariance data.

While the above discussion of absolute biases is indeed indicative of improved covariance data, it would still be possible for reduced absolute biases to appear with poorer covariance data if the goodness of fit of the calculated to experimental results due to the cross-section changes generated by TSURFER was also degraded. Table 30 below gives the  $\chi^2$  per degree of freedom measure of goodness of fit as reported by TSURFER for the four possible combinations of cross-section data and covariance data. As seen

with the absolute bias data, a significant improvement in goodness of fit is achieved through the improved cross section data, and another slight improvement to the goodness of fit is observed when both the improved cross-section data and high fidelity covariance data are used in conjunction.

Table 30) Goodness of Fit for Combinations of Cross-Section and Covariance Data

	JENDL/RPI XS & CVDH COV	JENDL/RPI XS & LOFI COV	ENDF/B- VII.1 & CVDH COV	ENDF/B-VII.1 & LOFI COV
$\chi^2$ per degree of freedom	1.195E+00	1.197E+00	1.428E+00	1.379E+00

### Cross Section Adjustment Comparisons

As discussed previously, the bias reported by TSURFER as being associated with a particular isotope and reaction derives from adjustments TSURFER makes to the cross-section for that isotope and reaction, constrained by the covariance data for that isotope.

Comparisons of the cross section adjustments TSURFER makes when using different cross section and covariance libraries, in the context of the reported overall goodness-of-fit, can help to distinguish advantages and disadvantages between the differing libraries.

Below are plots of TSURFER's cross section adjustments for each of the four combinations of cross section data and covariance data explored earlier in this chapter. Included isotopes and reactions are elastic scattering and neutron capture for the molybdenum isotopes, as well as all reported reactions for hydrogen,  $^{235}\text{U}$  and  $^{238}\text{U}$ .

# *Molybdenum Elastic Scattering*




Figure 76) Cross Section Adjustment to Elastic Scattering of Molybdenum Isotopes for ENDF/B-VII.1 & LOFI Covariance




Figure 77) Cross Section Adjustment to Elastic Scattering of Molybdenum Isotopes for ENDF/B-VII.1 & CVDH Covariance




Figure 78) Cross Section Adjustment to Elastic Scattering of Molybdenum Isotopes for JENDL4.0 with RPI resonance parameters & LOFI Covariance




Figure 79) Cross Section Adjustment to Elastic Scattering of Molybdenum Isotopes for JENDL4.0 with RPI resonance parameters & CVDH Covariance

Comparing the cases in which the molybdenum isotope cross section data is pulled from ENDF/B-VII.1 (Figure 76 and 77) to the cases in which JENDL4.0 is used with the RPI resonance parameters (Figures 78 and 79), it appears less dramatic adjustments to the resonance region cross sections are required with latter set of data, potentially indicating the superiority of JENDL and the RPI resonance parameters in this energy region. All four cases seem to indicate that the high energy scattering cross sections may be high, with the most dramatic adjustment occurring when the JENDL and RPI cross section data is used with the new CVDH covariance library.

### *Molybdenum Capture*




Figure 80) Cross Section Adjustment to Capture of Molybdenum Isotopes for ENDF/B-VII.1 & LOFI Covariance




Figure 81) Cross Section Adjustment to Capture of Molybdenum Isotopes for ENDF/B-VII.1 & CVDH Covariance




Figure 82) Cross Section Adjustment to Capture of Molybdenum Isotopes for JENDL4.0 with RPI resonance parameters & LOFI Covariance




Figure 83) Cross Section Adjustment to Capture of Molybdenum Isotopes for JENDL4.0 with RPI resonance parameters & CVDH Covariance

Three of the four cases (figures 80, 81, and 83) indicate the high energy capture cross section may be low, though the use of ENDF/B-VII.1 molybdenum cross section data results in significantly larger cross section adjustments. Use of the current low fidelity covariance data (figures 80 and 82) also results in cross section adjustments in the resonance region that are not seen when using the new CVDH covariance library.



## Hydrogen




Figure 84) Cross Section Adjustment to Hydrogen for Molybdenum Cross Sections from ENDF/B-VII.1




Figure 85) Cross Section Adjustment to Hydrogen for Molybdenum Cross Sections from JENDL4.0 with RPI Resonance Parameters

For isotopes other than molybdenum all cross section and covariance data is the same across all cases. Therefore differences between cases for isotopes other than molybdenum result from the system wide effects of the molybdenum cross sections changing from ENDF/B-VII.1 to JENDL 4.0 and RPI resonance parameters.

Some adjustment is recommended for the high energy hydrogen scattering cross section when molybdenum cross sections are drawn from ENDF/B-VII.1, however there are negligible adjustments to the hydrogen cross-section when molybdenum cross sections are provided by JENDL 4.0 and RPI resonance parameters. In each case bias due to hydrogen remains high.




Figure 86) Cross Section Adjustment to  $^{238}\text{U}$  for Molybdenum Cross Sections from ENDF/B-VII.1




Figure 87) Cross Section Adjustment to  $^{238}\text{U}$  for Molybdenum Cross Sections from JENDL4.0 with RPI resonance parameters

Significantly more cross section adjustment is seen for  $^{238}\text{U}$  in the resonance region when molybdenum cross section data come from ENDF/B-VII.1, as well as significantly more attributed bias.




Figure 88) Cross Section Adjustment to  $^{235}\text{U}$  for Molybdenum Cross Sections from ENDF/B-VII.1




Figure 89) Cross Section Adjustment to  $^{235}\text{U}$  for Molybdenum Cross Sections from JENDL4.0 with RPI resonance parameters

All of the modeled systems are by far most sensitive to the  $^{235}\text{U}$  cross sections. Somewhat less dramatic adjustments are suggested for the  $^{235}\text{U}$  cross sections when JENDL 4.0 and RPI cross-section data is used for the molybdenum isotopes, however the suggested adjustments to the  $^{235}\text{U}$  capture cross section still dwarf all other adjustment suggested for the cross sections of other isotopes. Again, this is due to the high level of uncertainty of the  $^{235}\text{U}$  capture cross section coupled with the high sensitivity of the system to that cross section.

### **Concluding Remarks**

An improved set of high fidelity covariance data was developed for the natural isotopes of molybdenum. The series of proposed U-Moly fuel foil critical experiments were used as a basis to test the performance of the new molybdenum covariance data against the low fidelity set of molybdenum covariance data currently available. In order to isolate the effects of the new covariance data from the effect of the new molybdenum cross-section data, all permutations of old and new cross-section data and covariance data were explored. Significant improvements in bias reduction and slight improvement goodness-of-fit were observed when the new high fidelity covariance data and new molybdenum cross-section data were used in tandem.

Appendix D contains the RPI and JENDL 4.0 resolved resonance parameters, CVDH COV file 32 covariance, and CVDH COV file 33 covariance data for total, scattering, and capture reactions for the natural molybdenum isotopes.

## Chapter 5: Conclusions

The primary objectives of this work were twofold: to demonstrate a novel means to generate a new high fidelity set of cross section covariance data for the natural molybdenum isotopes utilizing an elemental cross section evaluation, and design a series of molybdenum sensitive critical experiments that address deficiencies in the current critical experiment database with regards to the molybdenum isotopes. Both of these objectives were in support of the development of a new uranium molybdenum alloy fuel form for use in research and test reactors.

Incorporating data from multiple sources, a new high fidelity set of molybdenum isotope cross section covariance data was generated. The Bayesian analysis code SAMMY was used to generate uncertainty correlation data throughout the resolved resonance region for each of the molybdenum isotopes. This data was stored using the ENDF File 32 covariance data format. Additionally, integral uncertainty measurements, a dispersion method analysis, and high energy covariances generated at Brookhaven National Laboratory were incorporated to ensure the new covariance data satisfied the requirements set forth by the Cross Section Evaluation Working Group. This data was stored using the ENDF File 33 covariance data format.

A series of critical experiments was proposed to address deficiencies in molybdenum sensitivity in the currently available library of critical experiments. These critical experiments will feature the new intermediate enrichment U-Moly alloy fuel form, and will provide characterization of the fuel in both fast and thermal spectra. In particular, the thermal spectra critical experiments will be valuable, as there is a lack of U-Moly fueled critical experiments with a high thermal spectrum component.

Furthermore, the “Thermal Maximum Molybdenum Critical Experiment” will feature sensitivity to the molybdenum isotopes several orders of magnitude higher than any existing critical experiment, and should provide further insight into molybdenum isotope cross section uncertainty.

Finally, the newly generated high fidelity molybdenum covariance data library was used in a sensitivity and uncertainty study of the existing molybdenum sensitive critical experiments and the new proposed critical experiment series. When coupled with JENDL 4.0 cross section data, the high fidelity covariance data provided the best goodness-of-fit to the existing critical experiment data while simultaneously dramatically reducing the computational bias associated with the molybdenum isotopes as compared to the existing low fidelity covariance data.

The most immediate future work for this project would be the completion of the proposed critical experiments at the National Criticality Experiments Research Center. Completion of these critical experiments could serve as further validation of the high fidelity covariance library through more accurate and detailed computational modeling of the critical systems, and comparison of computational results to experimental results.

Secondly, while the resonance region uncertainty correlation produced for the new high fidelity covariance data was a significant improvement on the existing low fidelity library which assigns complete correlation throughout all energy regions, the correlation data could be improved further through the analysis of experimental molybdenum transmission and capture results for a larger segment of the resolved resonance region. The RPI experimental data extended to 2 keV for transmission measurements and to 600 eV for neutron capture measurements. This was sufficient to capture the effects of the large low lying resonances for all but one of the molybdenum isotopes, but to have complete knowledge of the correlation between the uncertainties for

all of the resolved resonances experimental transmission and capture data throughout the entire resolved resonance region would be required. If this data was to become available, the program of work outlined in chapter 4 of this text could be repeated to produce a further improvement to the File 32 resonance-wise covariance data for the molybdenum isotopes.

Finally, while not directly within the scope of this project, the impact of high uncertainty in the  $^{235}\text{U}$  capture cross section should be addressed, as it affects all attempts at the sort of sensitivity and uncertainty analysis possible through code packages such as TSUNAMI and TSURFER.



## **Appendices**

## Appendix A: Experimental Plans

The following were written in accordance with references [7], [11], and [12].

### EXPERIMENTAL PLAN #1

#### STATIC CRITICAL EXPERIMENT FOR U(19.5%)-10Mo FUEL FOILS

OPERATIONAL LIMIT: Stage 1: multiplication  $\leq 100$ .

Stage 2: delayed critical operation with positive periods  $\geq 10$  seconds.

ASSEMBLY MACHINE: Comet

REQUIRED PERSONELL: n/a

EXPECTED STARTING DATE: n/a

#### Purpose

To establish delayed critical conditions for U(19.5%)-10Mo fuel foils supplemented with HEU.

#### Active Material

Fuel will be 195 U(19.5%)-10Mo metal alloy foils with dimensions of 20" x 1.5" x 0.01". Additionally, 319.5 kg of HEU elements will be required to achieve criticality due to the intentional lack of moderation and resulting fast spectrum. Total uranium mass will be 334.17 kg, with 300.6 kg of  $^{235}\text{U}$ .

#### Assembly Description

Two subcritical assemblies will be initially constructed by hand. Each of the subcritical assemblies will contain half of the U-Mo foils and HEU elements predicted for criticality. The U-Mo foils will be stacked closest to the centerline of the final experimental configuration, followed by the HEU elements. Two hand stacking rules will

be observed during this phase. The first rule, the 75% rule, states that hand stacking will continue until the next additional fuel layer would exceed 75% of the extrapolated critical number of fuel foils. The second rule, the halfway rule, states that hand stacking can continue as long as the individual steps taken do not double the multiplication of the system or the count rate.

Once the two subcritical assembly halves have been completed, one will be placed on the top platform of the Comet machine, while the other will be placed on the lower movable platen of Comet. Comet will then be operated remotely observing the halfway rule described above.

#### Procedure

Stage 1: A neutron source will be located with the lower part of the critical assembly. BF3 counters placed around the assembly will monitor neutron multiplication. Neutron multiplication will be determined prior to experimentation from the same geometry, but without fuel material present. The lower part of the assembly will be remotely raised, following the halfway rule, and monitored by neutron multiplication. The lower platform will be raised incrementally to ascertain the behavior of the system until multiplication >100 is approached.

Stage 2: Following the successful completion of stage 1, a 1/M approach to critical procedure will be completed and a reactor period will be established. Reactivity effectiveness of various components will be measured, including fuel foils at multiple positions in the assembly.

#### Safety Precautions

Manual scram off the assembly will be available via the release of the movable platen of Comet. Computational modeling of the scram event indicates gravity driven drop of the lower platen represents an insertion of approximately -21500 pcm of

reactivity. This will provide an adequate safety margin for the critical experiment. Additionally, all requirements of ANS N405 SAFETY GUIDE FOR THE PERFORMANCE OF CRITICAL EXPERIMENTS will be satisfied.

## EXPERIMENTAL PLAN #2

### STATIC CRITICAL EXPERIMENT FOR U(19.5%)-10Mo FUEL FOILS

OPERATIONAL LIMIT: Stage 1: multiplication  $\leq 100$ .

Stage 2: delayed critical operation with positive periods  $\geq 10$  seconds.

ASSEMBLY MACHINE: Comet

REQUIRED PERSONELL: n/a

EXPECTED STARTING DATE: n/a

#### Purpose

To establish delayed critical conditions for U(19.5%)-10Mo fuel foils supplemented with HEU and reflected by graphite blocks.

#### Active Material

Fuel will be 195 U(19.5%)-10Mo metal alloy foils with dimensions of 20" x 1.5" x 0.01". Additionally, 49.60 kg of HEU elements will be required to achieve criticality due to the intentional lack of moderation and resulting fast spectrum. Total uranium mass will be 64.27 kg, with 48.99 kg of  $^{235}\text{U}$ .

#### Assembly Description

Two subcritical assemblies will be initially constructed by hand. Each of the subcritical assemblies will contain half of the U-Mo foils and HEU elements predicted for criticality. The U-Mo foils will be stacked closest to the centerline of the final experimental configuration, followed by the HEU elements. These fuel elements will be then surrounded by the graphite reflector elements. Two hand stacking rules will be observed during this phase. The first rule, the 75% rule, states that hand stacking will continue until the next additional fuel layer would exceed 75% of the extrapolated critical

number of fuel foils. The second rule, the halfway rule, states that hand stacking can continue as long as the individual steps taken do not double the multiplication of the system or the count rate.

Once the two subcritical assembly halves have been completed, one will be placed on the top platform of the Comet machine, while the other will be placed on the lower movable platen of Comet. Comet will then be operated remotely observing the halfway rule described above.

#### Procedure

Stage 1: A neutron source will be located with the lower part of the critical assembly. BF3 counters placed around the assembly will monitor neutron multiplication. Neutron multiplication will be determined prior to experimentation from the same geometry, with the graphite reflector, but without fuel material present. The lower part of the assembly will be remotely raised, following the halfway rule, and monitored by neutron multiplication. The lower platform will be raised incrementally to ascertain the behavior of the system until multiplication  $>100$  is approached.

Stage 2: Following the successful completion of stage 1, a 1/M approach to critical procedure will be completed and a reactor period will be established. Reactivity effectiveness of various components will be measured, including fuel foils at multiple positions in the assembly, as well as reflector and moderator layers.

#### Safety Precautions

Manual scram off the assembly will be available via the release of the movable platen of Comet. Computational modeling of the scram event indicates gravity driven drop of the lower platen represents an insertion of approximately -19500 pcm of reactivity. This will provide an adequate safety margin for the critical experiment.

Additionally, all requirements of ANS N405 SAFETY GUIDE FOR THE PERFORMANCE OF CRITICAL EXPERIMENTS will be satisfied.

### EXPERIMENTAL PLAN #3

#### STATIC CRITICAL EXPERIMENT FOR U(19.5%)-10Mo FUEL FOILS

OPERATIONAL LIMIT: Stage 1: multiplication  $\leq 100$ .

Stage 2: delayed critical operation with positive periods  $\geq 10$  seconds.

ASSEMBLY MACHINE: Comet

REQUIRED PERSONELL: n/a

EXPECTED STARTING DATE: n/a

#### Purpose

To establish delayed critical conditions for U(19.5%)-10Mo fuel foils moderated with Lucite and reflected by graphite blocks.

#### Active Material

Fuel will be 195 U(19.5%)-10Mo metal alloy foils with dimensions of 20" x 1.5" x 0.01". Total uranium mass will be 14.67 kg, with 2.86 kg of  $^{235}\text{U}$ .

#### Assembly Description

Assembly of the experimental setup will initially require hand stacking of alternating levels of Lucite plates and fuel foils. These layers will be stacked within a graphite reflector as calculated for the final critical state. Two hand stacking rules will be observed during this phase. The first rule, the 75% rule, states that hand stacking will continue until the next additional fuel layer would exceed 75% of the extrapolated critical number of fuel foils. The second rule, the halfway rule, states that hand stacking can continue as long as the individual steps taken do not double the multiplication of the system or the count rate. Assuming a linear relationship between multiplication and the



number of foils in the assembly, if an addition step was to double the count rate, the next step of equal size would result in a system multiplication beyond delayed critical.

When the limit of one of the above hand stacking rules is reached, the assembly will be split into two parts. The bottom part containing approximately 80% of the fuel foils along with the neutron source is to be placed on the movable platen of Comet. The top part containing the remainder of the fuel foil and moderator layers will be placed on the top platform. Comet will then be operated remotely observing the halfway rule.

#### Procedure

Stage 1: A neutron source will be located with the lower part of the critical assembly. BF3 counters placed around the assembly will monitor neutron multiplication. Neutron multiplication will be determined prior to experimentation from the same geometry, with graphite reflector and Lucite moderator in place, but without fuel foils present. The lower part of the assembly will be remotely raised, following the halfway rule, and monitored by neutron multiplication. The lower platform will be raised incrementally to ascertain the behavior of the system until multiplication  $>100$  is approached.

Stage 2: Following the successful completion of stage 1, a 1/M approach to critical procedure will be completed and a reactor period will be established. Reactivity effectiveness of various components will be measured, including fuel foils at multiple positions in the assembly, as well as reflector and moderator layers.

#### Safety Precautions

Manual scram off the assembly will be available via the release of the movable platen of Comet. Computational modeling of the scram event indicates gravity driven drop of the lower platen represents an insertion of approximately -3500 pcm of reactivity. This will provide an adequate safety margin for the critical experiment. Additionally, all

requirements of ANS N405 SAFETY GUIDE FOR THE PERFORMANCE OF CRITICAL EXPERIMENTS will be satisfied.

#### EXPERIMENTAL PLAN #4

#### STATIC CRITICAL EXPERIMENT FOR U(19.5%)-10Mo FUEL FOILS

OPERATIONAL LIMIT: Stage 1: multiplication  $\leq 100$ .

Stage 2: delayed critical operation with positive periods  $\geq 10$  seconds.

ASSEMBLY MACHINE: Comet

REQUIRED PERSONELL: n/a

EXPECTED STARTING DATE: n/a

#### Purpose

To establish delayed critical conditions for U(19.5%)-10Mo fuel foils moderated with Lucite and molybdenum metal and reflected by graphite blocks.

#### Active Material

Fuel will be 195 U(19.5%)-10Mo metal alloy foils with dimensions of 20" x 1.5" x 0.01". Total uranium mass will be 14.67 kg, with 2.86 kg of  $^{235}\text{U}$ .

#### Assembly Description

Assembly of the experimental setup will initially require hand stacking of alternating levels of Lucite plates, molybdenum metal plates, and fuel foils. These layers will be stacked within a graphite reflector as calculated for the final critical state. Two hand stacking rules will be observed during this phase. The first rule, the 75% rule, states that hand stacking will continue until the next additional fuel layer would exceed 75% of the extrapolated critical number of fuel foils. The second rule, the halfway rule, states that hand stacking can continue as long as the individual steps taken do not double the multiplication of the system or the count rate. Assuming a linear relationship between multiplication and the number of foils in the assembly, if an addition step was to double

the count rate, the next step of equal size would result in a system multiplication beyond delayed critical.

When the limit of one of the above hand stacking rules is reached, the assembly will be split into two parts. The bottom part containing approximately 80% of the fuel foils along with the neutron source is to be placed on the movable platen of Comet. The top part containing the remainder of the fuel foil and moderator layers will be placed on the top platform. Comet will then be operated remotely observing the halfway rule.

#### Procedure

Stage 1: A neutron source will be located with the lower part of the critical assembly. BF3 counters placed around the assembly will monitor neutron multiplication. Neutron multiplication will be determined prior to experimentation from the same geometry, with graphite reflector, Lucite moderator, and molybdenum metal moderator in place, but without fuel foils present. The lower part of the assembly will be remotely raised, following the halfway rule, and monitored by neutron multiplication. The lower platform will be raised incrementally to ascertain the behavior of the system until multiplication  $>100$  is approached.

Stage 2: Following the successful completion of stage 1, a 1/M approach to critical procedure will be completed and a reactor period will be established. Reactivity effectiveness of various components will be measured, including fuel foils at multiple positions in the assembly, as well as reflector and moderator layers.

#### Safety Precautions

Manual scram off the assembly will be available via the release of the movable platen of Comet. Computational modeling of the scram event indicates gravity driven drop of the lower platen represents an insertion of approximately -3800 pcm of reactivity. This will provide an adequate safety margin for the critical experiment. Additionally, all

requirements of ANS N405 SAFETY GUIDE FOR THE PERFORMANCE OF CRITICAL EXPERIMENTS will be satisfied.

## Appendix B: MCNP Materials and Inputs

Material compositions were derived as follows from references [13] and [14].

*U(19.5%)-10Mo*

Density: 15.3 g/cm<sup>3</sup>

Atom fraction:

<sup>235</sup> U	0.158805
<sup>238</sup> U	0.625053
<sup>92</sup> Mo	0.032075
<sup>94</sup> Mo	0.019993
<sup>95</sup> Mo	0.03441
<sup>96</sup> Mo	0.036052
<sup>97</sup> Mo	0.020641
<sup>98</sup> Mo	0.052155
<sup>100</sup> Mo	0.020814

*Lucite*

Density: 1.19 g/cm<sup>3</sup>

Atom Fraction:

H	0.533320
C	0.333345
O	0.133335

*HEU*

Density: 18.95 g/cm<sup>3</sup>

Atom Fraction:

<sup>234</sup> U	0.009849
<sup>235</sup> U	0.932166
<sup>236</sup> U	0.004484
<sup>238</sup> U	0.053501

*Graphite*

Density: 1.70 g/cm<sup>3</sup>

Atom Fraction:

C	1.0
---	-----

*Molybdenum Metal*

Density: 10.28 g/cm<sup>3</sup>

Atom Fraction:

<sup>92</sup> Mo	0.1484
<sup>94</sup> Mo	0.0925
<sup>95</sup> Mo	0.1592
<sup>96</sup> Mo	0.1668
<sup>97</sup> Mo	0.0955
<sup>98</sup> Mo	0.2413
<sup>100</sup> Mo	0.0963



## Fast Bare Critical Experiment Design

Fast Critical Experiment U(19.5%)-10Mo and HEU

C

C 10" x 9" x Z pile of U-Mo and plexiglass

C

C Cell Cards

```
1 1 0.049079 -1 imp:n=1 $U-Mo
2 3 -18.95 -2 imp:n=1 $HEU
3 3 -18.95 -3 imp:n=1 $HEU
4 4 0.001205 -5 #1 #2 #3 imp:n=1 $Reflector
5 0 5 imp:n=0 $Exterior
```

C Surface Cards

C Fuel Region Surfaces

```
1 rpp -25.4 25.4 -24.765 24.765 -1.905 1.905
2 rpp -25.4 25.4 -24.765 24.765 1.905 5.255
3 rpp -25.4 25.4 -24.765 24.765 -5.255 -1.905
5 rpp -50 50 -50 50 -10 10
```

C Data Cards

kcode 10000 1.0 50 500

ksrc 0.0 0.0 0.0

C Material Cards

```
  m1 92235 0.007794
      92238 0.030677
      42092.52c 0.001574227
      42094.52c 0.00098124
      42095.52c 0.001688794
      42096.52c 0.001769414
      42097.52c 0.001013064
      42098.52c 0.00255971
      42100.52c 0.00102155
  m3 92234 0.009849
      92235 0.932166
      92236 0.004484
      92238 0.053501
  m4 6000 0.000151 $ C
      7014 0.784437 $ N
      8016 0.210750 $ O
      18000 0.004671 $ Ar
```

## Fast Reflected Critical Experiment Design

Fast Critical Experiment U(19.5%)-10Mo and HEU. Graphite reflected.

C

C 10" x 9" x Z pile of U-Mo and HEU

C

C Cell Cards

```
1 1 0.049079 -1 imp:n=1 $U-Mo
2 3 -18.95 -2 imp:n=1 $HEU
3 3 -18.95 -3 imp:n=1 $HEU
4 2 8.523800E-02 -5 #1 #2 #3 imp:n=1 $Reflector
5 0 5 imp:n=0 $Exterior
```

C Surface Cards

C Fuel Region Surfaces

```
1 rpp -25.4 25.4 -24.765 24.765 -1.905 1.905
2 rpp -25.4 25.4 -24.765 24.765 1.905 2.425
3 rpp -25.4 25.4 -24.765 24.765 -2.425 -1.905
5 rpp -50 50 -50 50 -27.425 -27.425
```

C Data Cards

kcode 10000 1.0 50 500

ksrc 0.0 0.0 0.0

C Material Cards

```
m1 92235 0.007794
    92238 0.030677
    42092 0.001574227
    42094 0.00098124
    42095 0.001688794
    42096 0.001769414
    42097 0.001013064
    42098 0.00255971
    42100 0.00102155
m2 6012 1
m3 92234 0.009849
    92235 0.932166
    92236 0.004484
    92238 0.053501
```

## Thermal Standard Molybdenum Critical Experiment Design

Critical Experiment U-Mo and Lucite

C

C 10" x 9" x Z pile of U-Mo and plexiglass reflected with graphite

C

C Cell Cards

C Fuel Foils

1 2 0.049079 -1 -3 4 imp:n=1  
2 2 0.049079 -1 -5 6 imp:n=1  
3 2 0.049079 -1 -7 8 imp:n=1  
4 2 0.049079 -1 -9 10 imp:n=1  
5 2 0.049079 -1 -11 12 imp:n=1  
6 2 0.049079 -1 -13 14 imp:n=1  
7 2 0.049079 -1 -15 16 imp:n=1  
8 2 0.049079 -1 -17 18 imp:n=1  
9 2 0.049079 -1 -19 20 imp:n=1  
10 2 0.049079 -1 -21 22 imp:n=1  
11 2 0.049079 -1 -23 24 imp:n=1  
12 2 0.049079 -1 -25 26 imp:n=1  
13 2 0.049079 -1 -27 28 imp:n=1  
14 2 0.049079 -1 -29 30 imp:n=1  
15 2 0.049079 -1 -31 32 imp:n=1

C Moderator Plates

20 1 0.107369 -1 -2 3 imp:n=1  
21 1 0.107369 -1 -4 5 imp:n=1  
22 1 0.107369 -1 -6 7 imp:n=1  
23 1 0.107369 -1 -8 9 imp:n=1  
24 1 0.107369 -1 -10 11 imp:n=1  
25 1 0.107369 -1 -12 13 imp:n=1  
26 1 0.107369 -1 -14 15 imp:n=1  
27 1 0.107369 -1 -16 17 imp:n=1  
28 1 0.107369 -1 -18 19 imp:n=1  
29 1 0.107369 -1 -20 21 imp:n=1  
30 1 0.107369 -1 -22 23 imp:n=1  
31 1 0.107369 -1 -24 25 imp:n=1  
32 1 0.107369 -1 -26 27 imp:n=1  
33 1 0.107369 -1 -28 29 imp:n=1  
34 1 0.107369 -1 -30 31 imp:n=1  
35 1 0.107369 -1 -32 33 imp:n=1

C Graphite Reflector

50 3 8.523800E-02 -50 1 imp:n=1  
100 0 50 imp:n=0 \$Exterior

C Surface Cards

C Fuel Region Surfaces

1 rpp -25.4 25.4 -24.765 24.765 -26.65397 26.65397

2 pz 26.65397  
 3 pz 23.34603  
 4 pz 23.32063  
 5 pz 20.01270  
 6 pz 19.98730  
 7 pz 16.67937  
 8 pz 16.65397  
 9 pz 13.34603  
 10 pz 13.32063  
 11 pz 10.01270  
 12 pz 9.98730  
 13 pz 6.67937  
 14 pz 6.65397  
 15 pz 3.34603  
 16 pz 3.32063  
 17 pz 0.01270  
 18 pz -0.01270  
 19 pz -3.32063  
 20 pz -3.34603  
 21 pz -6.65397  
 22 pz -6.67937  
 23 pz -9.98730  
 24 pz -10.01270  
 25 pz -13.32063  
 26 pz -13.34603  
 27 pz -16.65397  
 28 pz -16.67937  
 29 pz -19.98730  
 30 pz -20.01270  
 31 pz -23.32063  
 32 pz -23.34603  
 33 pz -26.65397  
 C Reflector Region Surface  
 50 rpp -50 50 -50 50 -50 50

#### C Data Cards

kcode 10000 1.0 50 500  
 ksrc 0 0 0

#### C Material Cards

m1 1001 0.057262  
     6012 0.035791  
     8016 0.014316  
 mt1 poly.11t  
 m2 92235 0.007794  
     92238 0.030677  
     42092 0.001574227  
     42094 0.00098124  
     42095 0.001688794

	42096	0.001769414
	42097	0.001013064
	42098	0.00255971
	42100	0.00102155
m3	6012	1

## Thermal Maximum Molybdenum Critical Experiment Design

C Critical Experiment U-Mo, Molybdenum Metal, and Lucite.  
Graphite

C Reflector

C 10" x 9" x Z pile of U-Mo and plexiglass

C

C Cell Cards

C Fuel Foils

1 2 0.049079 -1 -4 5 imp:n=1  
2 2 0.049079 -1 -7 8 imp:n=1  
3 2 0.049079 -1 -10 11 imp:n=1  
4 2 0.049079 -1 -13 14 imp:n=1  
5 2 0.049079 -1 -16 17 imp:n=1  
6 2 0.049079 -1 -19 20 imp:n=1  
7 2 0.049079 -1 -22 23 imp:n=1  
8 2 0.049079 -1 -25 26 imp:n=1  
9 2 0.049079 -1 -28 29 imp:n=1  
10 2 0.049079 -1 -31 32 imp:n=1  
11 2 0.049079 -1 -34 35 imp:n=1  
12 2 0.049079 -1 -37 38 imp:n=1  
13 2 0.049079 -1 -40 41 imp:n=1  
14 2 0.049079 -1 -43 44 imp:n=1  
15 2 0.049079 -1 -46 47 imp:n=1

C Lucite Moderator Plates

20 1 0.107369 -1 -2 3 imp:n=1  
21 1 0.107369 -1 -5 6 imp:n=1  
22 1 0.107369 -1 -8 9 imp:n=1  
23 1 0.107369 -1 -11 12 imp:n=1  
24 1 0.107369 -1 -14 15 imp:n=1  
25 1 0.107369 -1 -17 18 imp:n=1  
26 1 0.107369 -1 -20 21 imp:n=1  
27 1 0.107369 -1 -23 24 imp:n=1  
28 1 0.107369 -1 -27 28 imp:n=1  
29 1 0.107369 -1 -30 31 imp:n=1  
30 1 0.107369 -1 -33 34 imp:n=1  
31 1 0.107369 -1 -36 37 imp:n=1  
32 1 0.107369 -1 -39 40 imp:n=1  
33 1 0.107369 -1 -42 43 imp:n=1  
34 1 0.107369 -1 -45 46 imp:n=1  
35 1 0.107369 -1 -48 49 imp:n=1

C Molybdenum Metal Layers

40 4 -10.28 -1 -3 4 imp:n=1  
41 4 -10.28 -1 -6 7 imp:n=1  
42 4 -10.28 -1 -9 10 imp:n=1  
43 4 -10.28 -1 -12 13 imp:n=1

```

44 4 -10.28 -1 -15 16 imp:n=1
45 4 -10.28 -1 -18 19 imp:n=1
46 4 -10.28 -1 -21 22 imp:n=1
47 4 -10.28 -1 -24 25 imp:n=1
48 4 -10.28 -1 -26 27 imp:n=1
49 4 -10.28 -1 -29 30 imp:n=1
50 4 -10.28 -1 -32 33 imp:n=1
51 4 -10.28 -1 -35 36 imp:n=1
52 4 -10.28 -1 -38 39 imp:n=1
53 4 -10.28 -1 -41 42 imp:n=1
54 4 -10.28 -1 -44 45 imp:n=1
55 4 -10.28 -1 -47 48 imp:n=1
C Graphite Reflector
60 3 8.523800E-02 -50 1 imp:n=1
100 0 50 imp:n=0 $Exterior

```

#### C Surface Cards

##### C Fuel Region Surfaces

```

1 rpp -25.4 25.4 -24.765 24.765 -14.20970 14.20970
2 pz 14.20970 $Top of Moderator
3 pz 12.60970 $Top of Moly
4 pz 12.45730 $Top of Fuel
5 pz 12.43190 $Top of Moderator
6 pz 10.83190 $Top of Moly
7 pz 10.67950 $Top of Fuel
8 pz 10.65410 $Top of Moderator
9 pz 9.05410 $Top of Moly
10 pz 8.90170 $Top of Fuel
11 pz 8.87630 $Top of Moderator
12 pz 7.27630 $Top of Moly
13 pz 7.12390 $Top of Fuel
14 pz 7.09850 $Top of Moderator
15 pz 5.49850 $Top of Moly
16 pz 5.34610 $Top of Fuel
17 pz 5.32070 $Top of Moderator
18 pz 3.72070 $Top of Moly
19 pz 3.56830 $Top of Fuel
20 pz 3.54290 $Top of Moderator
21 pz 1.94290 $Top of Moly
22 pz 1.79050 $Top of Fuel
23 pz 1.76510 $Top of Moderator
24 pz 0.16510 $Top of Moly
25 pz 0.01270 $Top of Fuel
26 pz -0.01270 $Top of Moly
27 pz -0.16510 $Top of Moderator
28 pz -1.76510 $Top of Fuel
29 pz -1.79050 $Top of Moly
30 pz -1.94290 $Top of Moderator

```

31	pz	-3.54290	\$Top of Fuel
32	pz	-3.56830	\$Top of Moly
33	pz	-3.72070	\$Top of Moderator
34	pz	-5.32070	\$Top of Fuel
35	pz	-5.34610	\$Top of Moly
36	pz	-5.49850	\$Top of Moderator
37	pz	-7.09850	\$Top of Fuel
38	pz	-7.12390	\$Top of Moly
39	pz	-7.27630	\$Top of Moderator
40	pz	-8.87630	\$Top of Fuel
41	pz	-8.90170	\$Top of Moly
42	pz	-9.05410	\$Top of Moderator
43	pz	-10.65410	\$Top of Fuel
44	pz	-10.67950	\$Top of Moly
45	pz	-10.83190	\$Top of Moderator
46	pz	-12.43190	\$Top of Fuel
47	pz	-12.45730	\$Top of Moly
48	pz	-12.60970	\$Top of Moderator
49	pz	-14.20970	\$Bottom of Moderator

C Reflector Region Surface  
50 rpp -75 75 -75 75 -75 75

#### C Data Cards

kcode 2000 1.0 20 200  
ksrc 0 0 0

#### C Material Cards

m1	1001	0.057262
	6012	0.035791
	8016	0.014316
mt1	poly.11t	
m2	92235	0.007794
	92238	0.030677
	42092.50c	0.001574227
	42094.50c	0.00098124
	42095.50c	0.001688794
	42096.50c	0.001769414
	42097.50c	0.001013064
	42098.50c	0.00255971
	42100.50c	0.00102155
m3	6012	1
mt3	grph.10t	
m4	42092.50c	0.1484
	42094.50c	0.0925
	42095.50c	0.1592
	42096.50c	0.1668
	42097.50c	0.0955
	42098.50c	0.2413
	42100.50c	0.0963



## Appendix C: File 32 and File 33 Covariance Plots

$^{92}\text{Mo}$




Figure C.1) ENDF/B-VII.1  $^{92}\text{Mo}$  Total Cross Section, 0-600 eV highlighted

## Total Covariance Data




Figure C.2)  $^{92}\text{Mo}$  Total File 32 Covariance




Figure C.3)  $^{92}\text{Mo}$  Total File 33 Covariance




Figure C.4)  $^{92}\text{Mo}$  CVDHCOV Total Covariance Data




Figure C.5)  $^{92}\text{Mo}$  LOFI Total Covariance Data

## Elastic Scattering Covariance Data




Figure C.6)  $^{92}\text{Mo}$  Elastic Scattering File 32 Covariance




Figure C.7)  $^{92}\text{Mo}$  Elastic Scattering File 33 Covariance




Figure C.8)  $^{92}\text{Mo}$  CVDHCOV Elastic Scattering Covariance Data




Figure C.9)  $^{92}\text{Mo}$  LOFI Elastic Scattering Covariance Data

## Capture Covariance Data




Figure C.10)  $^{92}\text{Mo}$  Capture File 32 Covariance




Figure C.11)  $^{92}\text{Mo}$  Capture File 33 Covariance




Figure C.12)  $^{92}\text{Mo}$  CVDHCOV Capture Covariance Data




Figure C.13)  $^{92}\text{Mo}$  LOFI Capture Covariance Data

$^{94}\text{Mo}$




Figure C.14) ENDF/B-VII.1  $^{94}\text{Mo}$  Total Cross Section, 0-600 eV highlighted




Figure C.15) ENDF/B-VII.1  $^{94}\text{Mo}$  Total Cross Section, 0-2000 eV highlighted



## Total Covariance Data




Figure C.16)  $^{94}\text{Mo}$  Total File 32 Covariance Data




Figure C.17)  $^{94}\text{Mo}$  Total File 33 Covariance Data




Figure C.18)  $^{94}\text{Mo}$  CVDHCOV Total Covariance Data




Figure C.19)  $^{94}\text{Mo}$  LOFI Total Covariance Data

## Elastic Scattering Covariance Data




Figure C.20)  $^{94}\text{Mo}$  Elastic Scattering File 32 Covariance Data




Figure C.21)  $^{94}\text{Mo}$  Elastic Scattering File 33 Covariance Data




Figure C.22)  $^{94}\text{Mo}$  CVDHCOV Elastic Scattering Covariance Data




Figure C.23)  $^{94}\text{Mo}$  LOFI Elastic Scattering Covariance Data

## Capture Covariance Data




Figure C.24)  $^{94}\text{Mo}$  Capture File 32 Covariance Data




Figure C.25)  $^{94}\text{Mo}$  Capture File 33 Covariance Data




Figure C.26)  $^{94}\text{Mo}$  CVDHCOV Capture Covariance Data




Figure C.27)  $^{94}\text{Mo}$  LOFI Capture Covariance Data

<sup>95</sup>Mo




Figure C.28) ENDF/B-VII.1 <sup>95</sup>Mo Total Cross Section, 0-600 eV highlighted

## Total Covariance Data




Figure C.29)  $^{95}\text{Mo}$  Total File 32 Covariance Data




Figure C.30)  $^{95}\text{Mo}$  Total File 33 Covariance Data






Figure C.31)  $^{95}\text{Mo}$  CVDHCOV Total Covariance Data




Figure C.32)  $^{95}\text{Mo}$  LOFI Total Covariance Data

## Elastic Scattering Covariance Data




Figure C.33)  $^{95}\text{Mo}$  Elastic Scattering File 32 Covariance Data




Figure C.34)  $^{95}\text{Mo}$  Elastic Scattering File 33 Covariance Data




Figure C.35)  $^{95}\text{Mo}$  CVDHCOV Elastic Scattering Covariance Data




Figure C.36)  $^{95}\text{Mo}$  LOFI Elastic Scattering Covariance Data

## Capture Covariance Data




Figure C.37)  $^{95}\text{Mo}$  Capture File 32 Covariance Data




Figure C.38)  $^{95}\text{Mo}$  Capture File 33 Covariance Data




Figure C.39)  $^{95}\text{Mo}$  CVDHCOV Capture Covariance Data




Figure C.40)  $^{95}\text{Mo}$  LOFI Capture Covariance Data

$^{96}\text{Mo}$




Figure C.41) ENDF/B-VII.1  $^{96}\text{Mo}$  Total Cross Section, 0-600 eV highlighted

## Total Covariance Data




Figure C.42)  $^{96}\text{Mo}$  Total File 32 Covariance Data




Figure C.43)  $^{96}\text{Mo}$  Total File 33 Covariance Data




Figure C.44)  $^{96}\text{Mo}$  CVDHCOV Total Covariance Data




Figure C.45)  $^{96}\text{Mo}$  LOFI Total Covariance Data



## Elastic Scattering Covariance Data




Figure C.46)  $^{96}\text{Mo}$  Elastic Scattering File 32 Covariance Data




Figure C.47)  $^{96}\text{Mo}$  Elastic Scattering File 33 Covariance Data




Figure C.48)  $^{96}\text{Mo}$  CVDHCOV Elastic Scattering Covariance Data




Figure C.49)  $^{96}\text{Mo}$  LOFI Elastic Scattering Covariance Data

## Capture Covariance Data




Figure C.50)  $^{96}\text{Mo}$  Capture File 32 Covariance Data




Figure C.51)  $^{96}\text{Mo}$  Capture File 33 Covariance Data




Figure C.52)  $^{96}\text{Mo}$  CVDHCOV Capture Covariance Data




Figure C.53)  $^{96}\text{Mo}$  LOFI Capture Covariance Data

<sup>97</sup>Mo




Figure C.54) ENDF/B-VII.1 <sup>97</sup>Mo Total Cross Section, 0-600 eV highlighted

## Total Covariance Data




Figure C.55)  $^{97}\text{Mo}$  Total File 32 Covariance Data




Figure C.56)  $^{97}\text{Mo}$  Total File 33 Covariance Data




Figure C.57)  $^{97}\text{Mo}$  CVDHCOV Total Covariance Data




Figure C.58)  $^{97}\text{Mo}$  LOFI Total Covariance Data

## Elastic Scattering Covariance Data




Figure C.59)  $^{97}\text{Mo}$  Elastic Scattering File 32 Covariance Data




Figure C.60)  $^{97}\text{Mo}$  Elastic Scattering File 33 Covariance Data






Figure C.61)  $^{97}\text{Mo}$  CVDHCOV Elastic Scattering Covariance Data




Figure C.62)  $^{97}\text{Mo}$  LOFI Elastic Scattering Covariance Data

## Capture Covariance Data




Figure C.63)  $^{97}\text{Mo}$  Capture File 32 Covariance Data




Figure C.64)  $^{97}\text{Mo}$  Capture File 33 Covariance Data




Figure C.65)  $^{97}\text{Mo}$  CVDHCOV Capture Covariance Data




Figure C.66)  $^{97}\text{Mo}$  LOFI Capture Covariance Data

<sup>98</sup>Mo




Figure C.67) ENDF/B-VII.1 <sup>98</sup>Mo Total Cross Section, 0-600 eV highlighted

## Total Covariance Data




Figure C.68)  $^{98}\text{Mo}$  Total File 32 Covariance Data




Figure C.69)  $^{98}\text{Mo}$  Total File 33 Covariance Data




Figure C.70)  $^{98}\text{Mo}$  CVDHCOV Total Covariance Data




Figure C.71)  $^{98}\text{Mo}$  LOFI Total Covariance Data

## Elastic Scattering Covariance Data




Figure C.72)  $^{98}\text{Mo}$  Elastic Scattering File 32 Covariance Data




Figure C.73)  $^{98}\text{Mo}$  Elastic Scattering File 33 Covariance Data




Figure C.74)  $^{98}\text{Mo}$  CVDHCOV Elastic Scattering Covariance Data




Figure C.75)  $^{98}\text{Mo}$  LOFI Elastic Scattering Covariance Data



## Capture Covariance Data




Figure C.76)  $^{98}\text{Mo}$  Capture File 32 Covariance Data




Figure C.77)  $^{98}\text{Mo}$  Capture File 33 Covariance Data




Figure C.78)  $^{98}\text{Mo}$  CVDHCOV Capture Covariance Data




Figure C.79)  $^{98}\text{Mo}$  LOFI Capture Covariance Data

$^{100}\text{Mo}$




Figure C.80) ENDF/B-VII.1  $^{100}\text{Mo}$  Total Cross Section, 0-600 eV highlighted

## Total Covariance Data




Figure C.81)  $^{100}\text{Mo}$  Total File 32 Covariance Data




Figure C.82)  $^{100}\text{Mo}$  Total File 33 Covariance Data




Figure C.83)  $^{100}\text{Mo}$  CVDHCOV Total Covariance Data




Figure C.84)  $^{100}\text{Mo}$  LOFI Total Covariance Data

## Elastic Scattering Covariance Data




Figure C.85)  $^{100}\text{Mo}$  Elastic Scattering File 32 Covariance Data




Figure C.86)  $^{100}\text{Mo}$  Elastic Scattering File 33 Covariance Data




Figure C.87)  $^{100}\text{Mo}$  CVDHCOV Elastic Scattering Covariance Data




Figure C.88)  $^{100}\text{Mo}$  LOFI Elastic Scattering Covariance Data

## Capture Covariance Data




Figure C.89)  $^{100}\text{Mo}$  Capture File 32 Covariance Data




Figure C.90)  $^{100}\text{Mo}$  Capture File 33 Covariance Data






Figure C.91)  $^{100}\text{Mo}$  CVDHCOV Capture Covariance Data




Figure C.92)  $^{100}\text{Mo}$  LOFI Capture Covariance Data

## Appendix D: ENDF Listing for JENDL 4.0 with RPI Resonance Parameters and High Fidelity Covariance Data

<sup>92</sup>Mo

### Resonance Parameters

						4225 0 0	0
4.209200+4	9.111729+1	0	0	1	04225	2151	1
4.209200+4	1.000000+0	0	0	2	04225	2151	2
1.000000-5	5.000000+4	1	2	0	04225	2151	3
0.000000+0	7.000000-1	0	0	2	04225	2151	4
9.111729+1	0.000000+0	0	0	120	204225	2151	5
-2.450000+3	5.000000-1	1.332000+1	1.310000+1	2.200000-1	0.000000+04225	2151	6
346.870000	0.5	3.116000-1	7.600000-3	3.040000-1	0.000000+04225	2151	7
3.175000+3	5.000000-1	8.016000+0	7.800000+0	2.160000-1	0.000000+04225	2151	8
6.817000+3	5.000000-1	7.580000-1	5.800000-1	1.780000-1	0.000000+04225	2151	9
7.135000+3	5.000000-1	7.010000-1	5.200000-1	1.810000-1	0.000000+04225	2151	10
1.154300+4	5.000000-1	1.115700+1	1.100000+1	1.570000-1	0.000000+04225	2151	11
1.376000+4	5.000000-1	3.211600+1	3.200000+1	1.160000-1	0.000000+04225	2151	12
1.655000+4	5.000000-1	6.265100+1	6.250000+1	1.510000-1	0.000000+04225	2151	13
2.034500+4	5.000000-1	6.760000-1	4.900000-1	1.860000-1	0.000000+04225	2151	14
2.109000+4	5.000000-1	3.116800+1	3.100000+1	1.680000-1	0.000000+04225	2151	15
2.583000+4	5.000000-1	3.667500+1	3.650000+1	1.750000-1	0.000000+04225	2151	16
2.855000+4	5.000000-1	5.050000-1	4.500000-1	5.500000-2	0.000000+04225	2151	17
2.984000+4	5.000000-1	3.717400+1	3.700000+1	1.740000-1	0.000000+04225	2151	18
3.113000+4	5.000000-1	5.727100+1	5.700000+1	2.710000-1	0.000000+04225	2151	19
3.122000+4	5.000000-1	2.010550+1	2.000000+1	1.055000-1	0.000000+04225	2151	20
3.349000+4	5.000000-1	5.910000-1	5.000000-1	9.100000-2	0.000000+04225	2151	21
3.467000+4	5.000000-1	5.158000+0	5.000000+0	1.580000-1	0.000000+04225	2151	22
3.574000+4	5.000000-1	2.670000+0	2.470000+0	2.000000-1	0.000000+04225	2151	23
3.771000+4	5.000000-1	3.014900+1	3.000000+1	1.490000-1	0.000000+04225	2151	24
4.793000+4	5.000000-1	5.011300+1	5.000000+1	1.130000-1	0.000000+04225	2151	25
9.111729+1	0.000000+0	1	0	348	584225	2151	26
1864.80000	1.5	4.470000-1	2.200000-2	4.250000-1	0.000000+04225	2151	27
2.320000+3	1.500000+0	4.544000-1	2.940000-2	4.250000-1	0.000000+04225	2151	28
3.061000+3	5.000000-1	2.900000-1	6.800000-2	2.220000-1	0.000000+04225	2151	29
4.294000+3	1.500000+0	7.560000-1	5.250000-1	2.310000-1	0.000000+04225	2151	30
5.579000+3	1.500000+0	5.810000-1	2.500000-1	3.310000-1	0.000000+04225	2151	31
6.032000+3	1.500000+0	6.260000-1	2.900000-1	3.360000-1	0.000000+04225	2151	32
6.484000+3	5.000000-1	1.212000+0	1.100000+0	1.120000-1	0.000000+04225	2151	33
8.806000+3	1.500000+0	1.434000+0	1.250000+0	1.840000-1	0.000000+04225	2151	34
8.918000+3	5.000000-1	3.740000+0	3.500000+0	2.400000-1	0.000000+04225	2151	35
9.140000+3	5.000000-1	1.830000+0	1.600000+0	2.300000-1	0.000000+04225	2151	36
1.059000+4	1.500000+0	6.060000-1	2.300000-1	3.760000-1	0.000000+04225	2151	37
1.111800+4	1.500000+0	3.830000-1	1.800000-1	2.030000-1	0.000000+04225	2151	38
1.285500+4	1.500000+0	8.720000-1	1.100000-1	7.620000-1	0.000000+04225	2151	39
1.414500+4	5.000000-1	5.367000+0	5.200000+0	1.670000-1	0.000000+04225	2151	40
1.446000+4	1.500000+0	3.430000-1	1.100000-1	2.330000-1	0.000000+04225	2151	41
1.568000+4	5.000000-1	6.186000+0	6.000000+0	1.860000-1	0.000000+04225	2151	42
1.571500+4	1.500000+0	1.135000+0	9.500000-1	1.850000-1	0.000000+04225	2151	43
1.729500+4	1.500000+0	3.760000-1	1.250000-1	2.510000-1	0.000000+04225	2151	44
1.803000+4	1.500000+0	5.680000-1	4.000000-1	1.680000-1	0.000000+04225	2151	45
1.815500+4	5.000000-1	4.216000+0	4.000000+0	2.160000-1	0.000000+04225	2151	46
1.919500+4	1.500000+0	3.195000+0	3.000000+0	1.950000-1	0.000000+04225	2151	47
2.057000+4	5.000000-1	6.540000-1	5.000000-1	1.540000-1	0.000000+04225	2151	48
2.065500+4	1.500000+0	5.680000-1	7.000000-2	4.980000-1	0.000000+04225	2151	49
2.120000+4	5.000000-1	4.527000-1	2.770000-2	4.250000-1	0.000000+04225	2151	50
2.177500+4	1.500000+0	6.230000-1	1.980000-1	4.250000-1	0.000000+04225	2151	51
2.395500+4	1.500000+0	8.008000+0	7.600000+0	4.080000-1	0.000000+04225	2151	52
2.547500+4	1.500000+0	4.372000+0	4.200000+0	1.720000-1	0.000000+04225	2151	53
2.623000+4	5.000000-1	7.458100+1	7.300000+1	1.581000+0	0.000000+04225	2151	54
2.804500+4	1.500000+0	6.872000+0	6.500000+0	3.720000-1	0.000000+04225	2151	55

2.871000+4	5.000000-1	2.624500+1	2.600000+1	2.450000-1	0.000000+04225	2151	56
3.008000+4	1.500000+0	7.440000-1	3.150000-1	4.290000-1	0.000000+04225	2151	57
3.034000+4	5.000000-1	5.734000+0	5.600000+0	1.340000-1	0.000000+04225	2151	58
3.259000+4	1.500000+0	1.796800+1	1.740000+1	5.680000-1	0.000000+04225	2151	59
3.446000+4	1.500000+0	5.648000+0	5.500000+0	1.480000-1	0.000000+04225	2151	60
3.483000+4	1.500000+0	5.268000+0	5.000000+0	2.680000-1	0.000000+04225	2151	61
3.560000+4	5.000000-1	1.211000+0	1.000000+0	2.110000-1	0.000000+04225	2151	62
3.600000+4	5.000000-1	9.250000-1	5.000000-1	4.250000-1	0.000000+04225	2151	63
3.648000+4	1.500000+0	2.112400+1	2.060000+1	5.240000-1	0.000000+04225	2151	64
3.706000+4	1.500000+0	1.239000+0	1.000000+0	2.390000-1	0.000000+04225	2151	65
3.797000+4	5.000000-1	8.810000-1	4.560000-1	4.250000-1	0.000000+04225	2151	66
3.846500+4	1.500000+0	2.730000+0	2.000000+0	7.300000-1	0.000000+04225	2151	67
3.912000+4	5.000000-1	3.222000+0	3.000000+0	2.220000-1	0.000000+04225	2151	68
4.022000+4	1.500000+0	7.922000+0	7.500000+0	4.220000-1	0.000000+04225	2151	69
4.036000+4	1.500000+0	3.727300+1	3.700000+1	2.730000-1	0.000000+04225	2151	70
4.215000+4	5.000000-1	5.720000-1	1.470000-1	4.250000-1	0.000000+04225	2151	71
4.244000+4	1.500000+0	7.550000-1	3.300000-1	4.250000-1	0.000000+04225	2151	72
4.336000+4	1.500000+0	5.310000-1	1.060000-1	4.250000-1	0.000000+04225	2151	73
4.409000+4	1.500000+0	6.530000-1	2.280000-1	4.250000-1	0.000000+04225	2151	74
4.470000+4	1.500000+0	5.750000-1	1.500000-1	4.250000-1	0.000000+04225	2151	75
4.501000+4	5.000000-1	7.370000-1	3.120000-1	4.250000-1	0.000000+04225	2151	76
4.535000+4	5.000000-1	7.890000-1	3.640000-1	4.250000-1	0.000000+04225	2151	77
4.626000+4	1.500000+0	4.450000+0	4.000000+0	4.500000-1	0.000000+04225	2151	78
4.661000+4	1.500000+0	7.350000-1	3.100000-1	4.250000-1	0.000000+04225	2151	79
4.715000+4	5.000000-1	8.680000-1	4.430000-1	4.250000-1	0.000000+04225	2151	80
4.771000+4	1.500000+0	1.065000+0	6.400000-1	4.250000-1	0.000000+04225	2151	81
4.877000+4	5.000000-1	9.550000-1	5.300000-1	4.250000-1	0.000000+04225	2151	82
4.997000+4	5.000000-1	1.185000+0	7.600000-1	4.250000-1	0.000000+04225	2151	83
5.018000+4	1.500000+0	3.575000+0	3.150000+0	4.250000-1	0.000000+04225	2151	84
5.000000+4	1.000000+6	2	2	0	04225	2151	85
0.000000+0	6.663200-1	1	0	3	04225	2151	86
9.111729+1	0.000000+0	0	0	1	04225	2151	87
5.000000-1	0.000000+0	5	0	96	154225	2151	88
0.000000+0	0.000000+0	0.000000+0	1.000000+0	0.000000+0	0.000000+04225	2151	89
5.000000+4	2.518200+3	0.000000+0	1.933900-1	1.550000-1	0.000000+04225	2151	90
6.000000+4	2.516700+3	0.000000+0	1.932800-1	1.550000-1	0.000000+04225	2151	91
7.000000+4	2.504400+3	0.000000+0	1.923400-1	1.550000-1	0.000000+04225	2151	92
8.000000+4	2.485100+3	0.000000+0	1.908600-1	1.550000-1	0.000000+04225	2151	93
9.000000+4	2.475600+3	0.000000+0	1.901300-1	1.550000-1	0.000000+04225	2151	94
1.000000+5	2.386600+3	0.000000+0	1.832900-1	1.550000-1	0.000000+04225	2151	95
2.000000+5	1.861200+3	0.000000+0	1.429400-1	1.550000-1	0.000000+04225	2151	96
3.000000+5	1.396000+3	0.000000+0	1.072200-1	1.550000-1	0.000000+04225	2151	97
4.000000+5	1.079700+3	0.000000+0	8.292000-2	1.550000-1	0.000000+04225	2151	98
5.000000+5	8.768200+2	0.000000+0	6.734000-2	1.550000-1	0.000000+04225	2151	99
6.000000+5	7.181900+2	0.000000+0	5.515700-2	1.550000-1	0.000000+04225	2151	100
7.000000+5	6.074500+2	0.000000+0	4.665200-2	1.550000-1	0.000000+04225	2151	101
8.000000+5	5.166200+2	0.000000+0	3.967600-2	1.550000-1	0.000000+04225	2151	102
9.000000+5	4.461800+2	0.000000+0	3.426600-2	1.550000-1	0.000000+04225	2151	103
1.000000+6	3.818300+2	0.000000+0	2.932400-2	1.550000-1	0.000000+04225	2151	104
9.111729+1	0.000000+0	1	0	2	04225	2151	105
5.000000-1	0.000000+0	5	0	96	154225	2151	106
0.000000+0	0.000000+0	0.000000+0	1.000000+0	0.000000+0	0.000000+04225	2151	107
5.000000+4	2.518200+3	0.000000+0	1.226300+0	2.400000-1	0.000000+04225	2151	108
6.000000+4	2.516700+3	0.000000+0	1.225600+0	2.400000-1	0.000000+04225	2151	109
7.000000+4	2.504400+3	0.000000+0	1.219600+0	2.400000-1	0.000000+04225	2151	110
8.000000+4	2.485100+3	0.000000+0	1.210200+0	2.400000-1	0.000000+04225	2151	111
9.000000+4	2.475600+3	0.000000+0	1.205600+0	2.400000-1	0.000000+04225	2151	112
1.000000+5	2.386600+3	0.000000+0	1.162300+0	2.400000-1	0.000000+04225	2151	113
2.000000+5	1.861200+3	0.000000+0	9.064100-1	2.400000-1	0.000000+04225	2151	114
3.000000+5	1.396000+3	0.000000+0	6.798700-1	2.400000-1	0.000000+04225	2151	115
4.000000+5	1.079700+3	0.000000+0	5.258100-1	2.400000-1	0.000000+04225	2151	116
5.000000+5	8.768200+2	0.000000+0	4.270100-1	2.400000-1	0.000000+04225	2151	117
6.000000+5	7.181900+2	0.000000+0	3.497600-1	2.400000-1	0.000000+04225	2151	118
7.000000+5	6.074500+2	0.000000+0	2.958300-1	2.400000-1	0.000000+04225	2151	119
8.000000+5	5.166200+2	0.000000+0	2.515900-1	2.400000-1	0.000000+04225	2151	120
9.000000+5	4.461800+2	0.000000+0	2.172900-1	2.400000-1	0.000000+04225	2151	121

1.000000+6	3.818300+2	0.000000+0	1.859500-1	2.400000-1	0.000000+04225	2151	122
1.500000+0	0.000000+0	5	0	96	154225	2151	123
0.000000+0	0.000000+0	0.000000+0	1.000000+0	0.000000+0	0.000000+04225	2151	124
5.000000+4	1.259100+3	0.000000+0	6.131700-1	2.400000-1	0.000000+04225	2151	125
6.000000+4	1.258400+3	0.000000+0	6.128200-1	2.400000-1	0.000000+04225	2151	126
7.000000+4	1.252200+3	0.000000+0	6.098200-1	2.400000-1	0.000000+04225	2151	127
8.000000+4	1.242600+3	0.000000+0	6.051200-1	2.400000-1	0.000000+04225	2151	128
9.000000+4	1.237800+3	0.000000+0	6.028100-1	2.400000-1	0.000000+04225	2151	129
1.000000+5	1.193300+3	0.000000+0	5.811300-1	2.400000-1	0.000000+04225	2151	130
2.000000+5	9.306000+2	0.000000+0	4.532000-1	2.400000-1	0.000000+04225	2151	131
3.000000+5	6.980200+2	0.000000+0	3.399300-1	2.400000-1	0.000000+04225	2151	132
4.000000+5	5.398400+2	0.000000+0	2.629000-1	2.400000-1	0.000000+04225	2151	133
5.000000+5	4.384100+2	0.000000+0	2.135100-1	2.400000-1	0.000000+04225	2151	134
6.000000+5	3.591000+2	0.000000+0	1.748800-1	2.400000-1	0.000000+04225	2151	135
7.000000+5	3.037200+2	0.000000+0	1.479100-1	2.400000-1	0.000000+04225	2151	136
8.000000+5	2.583100+2	0.000000+0	1.258000-1	2.400000-1	0.000000+04225	2151	137
9.000000+5	2.230900+2	0.000000+0	1.086400-1	2.400000-1	0.000000+04225	2151	138
1.000000+6	1.909100+2	0.000000+0	9.297500-2	2.400000-1	0.000000+04225	2151	139
9.111729+1	0.000000+0	2	0	2	04225	2151	140
1.500000+0	0.000000+0	5	0	96	154225	2151	141
0.000000+0	0.000000+0	0.000000+0	1.000000+0	0.000000+0	0.000000+04225	2151	142
5.000000+4	1.259100+3	0.000000+0	1.259100-1	1.550000-1	0.000000+04225	2151	143
6.000000+4	1.258400+3	0.000000+0	1.258400-1	1.550000-1	0.000000+04225	2151	144
7.000000+4	1.252200+3	0.000000+0	1.252200-1	1.550000-1	0.000000+04225	2151	145
8.000000+4	1.242600+3	0.000000+0	1.242600-1	1.550000-1	0.000000+04225	2151	146
9.000000+4	1.237800+3	0.000000+0	1.237800-1	1.550000-1	0.000000+04225	2151	147
1.000000+5	1.193300+3	0.000000+0	1.193300-1	1.550000-1	0.000000+04225	2151	148
2.000000+5	9.306000+2	0.000000+0	9.306000-2	1.550000-1	0.000000+04225	2151	149
3.000000+5	6.980200+2	0.000000+0	6.980200-2	1.550000-1	0.000000+04225	2151	150
4.000000+5	5.398400+2	0.000000+0	5.398400-2	1.550000-1	0.000000+04225	2151	151
5.000000+5	4.384100+2	0.000000+0	4.384100-2	1.550000-1	0.000000+04225	2151	152
6.000000+5	3.591000+2	0.000000+0	3.591000-2	1.550000-1	0.000000+04225	2151	153
7.000000+5	3.037200+2	0.000000+0	3.037200-2	1.550000-1	0.000000+04225	2151	154
8.000000+5	2.583100+2	0.000000+0	2.583100-2	1.550000-1	0.000000+04225	2151	155
9.000000+5	2.230900+2	0.000000+0	2.230900-2	1.550000-1	0.000000+04225	2151	156
1.000000+6	1.909100+2	0.000000+0	1.909100-2	1.550000-1	0.000000+04225	2151	157
2.500000+0	0.000000+0	5	0	96	154225	2151	158
0.000000+0	0.000000+0	0.000000+0	1.000000+0	0.000000+0	0.000000+04225	2151	159
5.000000+4	8.393900+2	0.000000+0	8.393900-2	1.550000-1	0.000000+04225	2151	160
6.000000+4	8.389100+2	0.000000+0	8.389100-2	1.550000-1	0.000000+04225	2151	161
7.000000+4	8.348000+2	0.000000+0	8.348000-2	1.550000-1	0.000000+04225	2151	162
8.000000+4	8.283700+2	0.000000+0	8.283700-2	1.550000-1	0.000000+04225	2151	163
9.000000+4	8.252000+2	0.000000+0	8.252000-2	1.550000-1	0.000000+04225	2151	164
1.000000+5	7.955200+2	0.000000+0	7.955200-2	1.550000-1	0.000000+04225	2151	165
2.000000+5	6.204000+2	0.000000+0	6.204000-2	1.550000-1	0.000000+04225	2151	166
3.000000+5	4.653400+2	0.000000+0	4.653400-2	1.550000-1	0.000000+04225	2151	167
4.000000+5	3.599000+2	0.000000+0	3.599000-2	1.550000-1	0.000000+04225	2151	168
5.000000+5	2.922700+2	0.000000+0	2.922700-2	1.550000-1	0.000000+04225	2151	169
6.000000+5	2.394000+2	0.000000+0	2.394000-2	1.550000-1	0.000000+04225	2151	170
7.000000+5	2.024800+2	0.000000+0	2.024800-2	1.550000-1	0.000000+04225	2151	171
8.000000+5	1.722100+2	0.000000+0	1.722100-2	1.550000-1	0.000000+04225	2151	172
9.000000+5	1.487300+2	0.000000+0	1.487300-2	1.550000-1	0.000000+04225	2151	173
1.000000+6	1.272800+2	0.000000+0	1.272800-2	1.550000-1	0.000000+04225	2151	174
							4225 2 099999

# Covariance Data

0.000000+0	0.000000+0	0	0	0	04225 0 0	0
42092.0	9.111729+1	0	0	1	0422532151	1
42092.0	1.000000+0	0	0	1	0422532151	2
5.100000-4	4.000000+4	1	2	0	1422532151	3
0.0	7.000000-1	0	1	0	0422532151	4
9.111729+1		0	0	1	0422532151	5
		3	0	33	2422532151	6
346.8700000	0.5	3.116000-1	7.600000-3	3.040000-1	422532151	7
1864.800000	1.5	4.470000-1	2.200000-2	4.250000-1	422532151	8



[illegible]

0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	127
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	128
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	129
0.000000+0	0.000000+0	0.000000+0	2.312071-3	0.000000+0	0.000000+0422533	1	130
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	131
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	132
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	133
0.000000+0	0.000000+0	2.041142-3	0.000000+0	0.000000+0	0.000000+0422533	1	134
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	135
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	136
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	137
1.819705-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	138
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	139
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	140
0.000000+0	0.000000+0	0.000000+0	1.605124-3	0.000000+0	0.000000+0422533	1	141
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	142
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	143
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	1.384882-3422533	1	144
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	145
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	146
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	147
9.261675-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	148
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	149
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	150
5.441865-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	151
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	152
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	2.971038-2422533	1	153
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	154
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	155
0.000000+0	0.000000+0	0.000000+0	5.860563-2	0.000000+0	0.000000+0422533	1	156
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	157
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	158
2.004716-2	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	159
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	1	160
0.000000+0	0.000000+0	3.286788-2	1.334331-2	9.971225-3	1.037007-2422533	1	161
1.149410-2	1.243684-2	1.258187-2	1.258459-2	1.229180-2	1.174792-2422533	1	162
1.145784-2	1.182062-2	1.203799-2	5.416960-3	4.048000-3	4.209920-3422533	1	163
4.666240-3	5.048960-3	5.107840-3	5.108944-3	4.990080-3	4.769280-3422533	1	164
4.651520-3	4.798794-3	4.887040-3	3.025000-3	3.146000-3	3.487000-3422533	1	165
3.773000-3	3.817000-3	3.817825-3	3.729000-3	3.564000-3	3.476000-3422533	1	166
3.586055-3	3.652000-3	3.271840-3	3.626480-3	3.923920-3	3.969680-3422533	1	167
3.970538-3	3.878160-3	3.706560-3	3.615040-3	3.729497-3	3.798080-3422533	1	168
4.019560-3	4.349240-3	4.399960-3	4.400911-3	4.298520-3	4.108320-3422533	1	169
4.006880-3	4.133743-3	4.209760-3	4.705960-3	4.760840-3	4.761869-3422533	1	170
4.651080-3	4.445280-3	4.335520-3	4.472789-3	4.555040-3	4.816360-3422533	1	171
4.817401-3	4.705320-3	4.497120-3	4.386080-3	4.524949-3	4.608160-3422533	1	172
4.818442-3	4.706337-3	4.498092-3	4.387028-3	4.525927-3	4.609156-3422533	1	173
4.596840-3	4.393440-3	4.284960-3	4.420628-3	4.501920-3	4.199040-3422533	1	174
4.095360-3	4.225025-3	4.302720-3	3.994240-3	4.120703-3	4.196480-3422533	1	175
4.251170-3	4.329346-3	4.408960-3	0.000000+0	0.000000+0	0.000000+0422533	1	176
0.000000+0	0.000000+0	0	0	0	0422533	099999	
4.209200+4	9.111730+1	0	0	0	1422533	2	1
0.000000+0	0.000000+0	0	2	0	1422533	2	2
0.000000+0	0.000000+0	1	5	1035	45422533	2	3
1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000-2422533	2	4
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000-1422533	2	5
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000-1422533	2	6
4.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000+0422533	2	7
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000+2422533	2	8
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000+5422533	2	9
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000+6422533	2	10
6.434000+6	8.187300+6	2.000000+7	7.920284-4	0.000000+0	0.000000+0422533	2	11
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	2	12
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	2	13
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	2	14
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	2	15

[illegible]



[illegible]

9.272634-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	2	148
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	2	149
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	2	150
5.445259-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	2	151
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	2	152
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	3.187582-2422533	2	153
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	2	154
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	2	155
0.000000+0	0.000000+0	0.000000+0	6.060902-2	0.000000+0	0.000000+0	0.000000+0422533	2	156
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	2	157
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	2	158
2.076884-2	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	2	159
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533	2	160
0.000000+0	0.000000+0	3.332341-2	1.350848-2	1.212112-2	1.223065-2422533	2	161	
1.241320-2	1.296084-2	1.533395-2	1.669684-2	2.062781-2	2.515498-2422533	2	162	
2.632328-2	2.500529-2	2.526450-2	5.476000-3	4.913600-3	4.958000-3422533	2	163	
5.032000-3	5.254000-3	6.216000-3	6.768484-3	8.362000-3	1.019720-2422533	2	164	
1.067080-2	1.013652-2	1.024160-2	4.408960-3	4.448800-3	4.515200-3422533	2	165	
4.714400-3	5.577600-3	6.073342-3	7.503200-3	9.149920-3	9.574880-3422533	2	166	
9.095472-3	9.189760-3	4.489000-3	4.556000-3	4.757000-3	5.628000-3422533	2	167	
6.128222-3	7.571000-3	9.232600-3	9.661400-3	9.177660-3	9.272800-3422533	2	168	
4.624000-3	4.828000-3	5.712000-3	6.219688-3	7.684000-3	9.370400-3422533	2	169	
9.805600-3	9.314640-3	9.411200-3	5.041000-3	5.964000-3	6.494086-3422533	2	170	
8.023000-3	9.783800-3	1.023820-2	9.725580-3	9.826400-3	7.056000-3422533	2	171	
7.683144-3	9.492000-3	1.157520-2	1.211280-2	1.150632-2	1.162560-2422533	2	172	
8.366029-3	1.033566-2	1.260401-2	1.318940-2	1.252901-2	1.265889-2422533	2	173	
1.276900-2	1.557140-2	1.629460-2	1.547874-2	1.563920-2	1.898884-2422533	2	174	
1.987076-2	1.887584-2	1.907152-2	2.079364-2	1.975252-2	1.995728-2422533	2	175	
1.876352-2	1.895803-2	1.915456-2	0.000000+0	0.000000+0	0.000000+0422533	2	176	
0.000000+0	0.000000+0	0	0	0	0422533	099999		
4.209200+4	9.111730+1	0	0	0	1422533102	1		
0.000000+0	0.000000+0	0	102	0	1422533102	2		
0.000000+0	0.000000+0	1	5	1035	45422533102	3		
1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000-2422533102	4		
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000-1422533102	5		
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000-1422533102	6		
4.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000+0422533102	7		
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000+2422533102	8		
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000+5422533102	9		
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000+6422533102	10		
6.434000+6	8.187300+6	2.000000+7	6.172243-2	0.000000+0	0.000000+0422533102	11		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	12		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	13		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	14		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	15		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	16		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	17		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	6.136520-2422533102	18		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	19		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	20		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	21		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	22		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	23		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	24		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	25		
6.136520-2	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	26		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	27		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	28		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	29		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	30		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	31		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	32		
6.136520-2	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	33		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	34		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	35		
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0422533102	36		

[illegible]

[illegible]

5.171076-2	5.466696-2	5.830536-2	6.282607-2	7.322280-2	7.799820-2422533102	169
8.659392-2	9.571039-2	1.056955-1	5.779216-2	6.163856-2	6.641771-2422533102	170
7.740880-2	8.245720-2	9.154432-2	1.011820-1	1.117379-1	6.574096-2422533102	171
7.083819-2	8.256080-2	8.794520-2	9.763712-2	1.079162-1	1.191747-1422533102	172
7.633064-2	8.896216-2	9.476404-2	1.052074-1	1.162835-1	1.284149-1422533102	173
1.036840-1	1.104460-1	1.226176-1	1.355266-1	1.496656-1	1.176490-1422533102	174
1.306144-1	1.443653-1	1.594264-1	1.450086-1	1.602749-1	1.769958-1422533102	175
1.771484-1	1.956297-1	2.160390-1	0.000000+0	0.000000+0	0.000000+0422533102	176
0.000000+0	0.000000+0	0	0	0	0422533	099999

<sup>94</sup>Mo

Resonance Parameters

						4231	0	0	0
4.209400+4	9.309840+1	0	0	1	04231	2151	1		
4.209400+4	1.000000+0	0	0	2	04231	2151	2		
1.000000-5	2.000000+4	1	2	0	04231	2151	3		
0.000000+0	6.900000-1	0	0	2	04231	2151	4		
9.309840+1	0.000000+0	0	0	84	144231	2151	5		
-1.430000+2	5.000000-1	2.770000-1	1.490000-1	1.280000-1	0.000000+04231	2151	6		
1542.40000	0.5	1.560000+0	1.420000+0	1.400000-1	0.000000+04231	2151	7		
3.602000+3	5.000000-1	2.637000+0	2.500000+0	1.370000-1	0.000000+04231	2151	8		
4.622000+3	5.000000-1	6.890000-1	5.260000-1	1.630000-1	0.000000+04231	2151	9		
5.433000+3	5.000000-1	1.541400+1	1.530000+1	1.140000-1	0.000000+04231	2151	10		
6.718000+3	5.000000-1	1.131000+0	1.000000+0	1.310000-1	0.000000+04231	2151	11		
7.865000+3	5.000000-1	1.116000+0	1.000000+0	1.160000-1	0.000000+04231	2151	12		
9.705000+3	5.000000-1	6.390000-1	5.000000-1	1.390000-1	0.000000+04231	2151	13		
1.075200+4	5.000000-1	2.509100+1	2.500000+1	9.100000-2	0.000000+04231	2151	14		
1.352500+4	5.000000-1	2.015100+1	2.000000+1	1.510000-1	0.000000+04231	2151	15		
1.570500+4	5.000000-1	2.360000+0	2.200000+0	1.600000-1	0.000000+04231	2151	16		
1.709500+4	5.000000-1	9.135000+0	9.000000+0	1.350000-1	0.000000+04231	2151	17		
1.815500+4	5.000000-1	2.020700+1	2.000000+1	2.070000-1	0.000000+04231	2151	18		
2.025500+4	5.000000-1	3.017700+1	3.000000+1	1.770000-1	0.000000+04231	2151	19		
9.309840+1	0.000000+0	1	0	270	454231	2151	20		
108.500000	0.5	1.881100-1	1.100000-4	1.880000-1	0.000000+04231	2151	21		
1051.30000	0.5	1.940000-1	6.000000-3	1.880000-1	0.000000+04231	2151	22		
1664.00000	1.5	1.940000-1	6.000000-3	1.880000-1	0.000000+04231	2151	23		
2.179200+3	1.500000+0	4.710000-1	2.960000-1	1.750000-1	0.000000+04231	2151	24		
3.163000+3	1.500000+0	3.020000-1	1.270000-1	1.750000-1	0.000000+04231	2151	25		
3.575000+3	1.500000+0	3.330000-1	1.580000-1	1.750000-1	0.000000+04231	2151	26		
4.368000+3	1.500000+0	4.147000+0	4.000000+0	1.470000-1	0.000000+04231	2151	27		
4.928000+3	5.000000-1	1.294000+0	1.090000+0	2.040000-1	0.000000+04231	2151	28		
5.135000+3	1.500000+0	1.669000+0	1.500000+0	1.690000-1	0.000000+04231	2151	29		
5.454000+3	5.000000-1	1.834000-1	8.400000-3	1.750000-1	0.000000+04231	2151	30		
5.953000+3	5.000000-1	2.840000-1	1.090000-1	1.750000-1	0.000000+04231	2151	31		
6.030000+3	5.000000-1	1.870000-1	1.200000-2	1.750000-1	0.000000+04231	2151	32		
6.407000+3	5.000000-1	1.750000-1	3.500000-2	1.400000-1	0.000000+04231	2151	33		
6.960000+3	5.000000-1	2.050000-1	3.500000-2	1.700000-1	0.000000+04231	2151	34		
7.128000+3	5.000000-1	1.845000-1	9.500000-3	1.750000-1	0.000000+04231	2151	35		
8.275000+3	1.500000+0	2.150000+0	2.000000+0	1.500000-1	0.000000+04231	2151	36		
8.608000+3	1.500000+0	7.300000-1	5.000000-1	2.300000-1	0.000000+04231	2151	37		
8.660000+3	5.000000-1	7.850000-1	6.100000-1	1.750000-1	0.000000+04231	2151	38		
9.590000+3	1.500000+0	6.840000-1	5.000000-1	1.840000-1	0.000000+04231	2151	39		
9.813000+3	1.500000+0	3.670000-1	1.920000-1	1.750000-1	0.000000+04231	2151	40		
1.022500+4	1.500000+0	3.168000+0	3.000000+0	1.680000-1	0.000000+04231	2151	41		
1.053500+4	1.500000+0	4.310000-1	2.560000-1	1.750000-1	0.000000+04231	2151	42		
1.077600+4	1.500000+0	6.805000+0	6.630000+0	1.750000-1	0.000000+04231	2151	43		
1.142000+4	1.500000+0	5.570000-1	3.820000-1	1.750000-1	0.000000+04231	2151	44		
1.181500+4	1.500000+0	1.975000+0	1.800000+0	1.750000-1	0.000000+04231	2151	45		
1.220500+4	1.500000+0	4.250000-1	2.500000-1	1.750000-1	0.000000+04231	2151	46		
1.228000+4	5.000000-1	4.790000-1	3.040000-1	1.750000-1	0.000000+04231	2151	47		
1.298000+4	5.000000-1	2.130000-1	3.800000-2	1.750000-1	0.000000+04231	2151	48		
1.341500+4	5.000000-1	6.810000-1	5.060000-1	1.750000-1	0.000000+04231	2151	49		
1.370500+4	1.500000+0	1.335000+0	1.160000+0	1.750000-1	0.000000+04231	2151	50		
1.399000+4	1.500000+0	3.800000+0	3.500000+0	3.000000-1	0.000000+04231	2151	51		
1.411000+4	5.000000-1	4.380000-1	2.630000-1	1.750000-1	0.000000+04231	2151	52		
1.534000+4	5.000000-1	3.980000-1	2.230000-1	1.750000-1	0.000000+04231	2151	53		
1.676500+4	5.000000-1	2.489999-1	7.399999-2	1.750000-1	0.000000+04231	2151	54		
1.732000+4	5.000000-1	6.380000-1	4.630000-1	1.750000-1	0.000000+04231	2151	55		
1.739000+4	5.000000-1	3.440000-1	1.690000-1	1.750000-1	0.000000+04231	2151	56		
1.752000+4	5.000000-1	2.240000-1	4.900000-2	1.750000-1	0.000000+04231	2151	57		
1.780500+4	1.500000+0	1.214000+0	1.000000+0	2.140000-1	0.000000+04231	2151	58		
1.833600+4	5.000000-1	6.960000-1	5.210000-1	1.750000-1	0.000000+04231	2151	59		
1.849500+4	1.500000+0	4.900000-1	3.150000-1	1.750000-1	0.000000+04231	2151	60		
1.887500+4	1.500000+0	1.203000+0	1.000000+0	2.030000-1	0.000000+04231	2151	61		
1.922500+4	1.500000+0	1.217000+0	1.000000+0	2.170000-1	0.000000+04231	2151	62		
1.970000+4	1.500000+0	3.650000-1	1.900000-1	1.750000-1	0.000000+04231	2151	63		

2.007500+4	5.000000-1	5.780000-1	4.030000-1	1.750000-1	0.000000+04231	2151	64
2.067000+4	1.500000+0	1.205000+0	1.030000+0	1.750000-1	0.000000+04231	2151	65
2.000000+4	1.000000+6	2	2	0	04231	2151	66
0.000000+0	4.474100-1	1	0	3	04231	2151	67
9.309840+1	0.000000+0	0	0	1	04231	2151	68
5.000000-1	0.000000+0	5	0	114	184231	2151	69
0.000000+0	0.000000+0	2.000000+0	1.000000+0	0.000000+0	0.000000+04231	2151	70
2.000000+4	1.256600+3	0.000000+0	1.143500-1	1.280000-1	0.000000+04231	2151	71
3.000000+4	1.219300+3	0.000000+0	1.109600-1	1.280000-1	0.000000+04231	2151	72
4.000000+4	1.200100+3	0.000000+0	1.092100-1	1.280000-1	0.000000+04231	2151	73
5.000000+4	1.176800+3	0.000000+0	1.070900-1	1.280000-1	0.000000+04231	2151	74
6.000000+4	1.156000+3	0.000000+0	1.052000-1	1.280000-1	0.000000+04231	2151	75
7.000000+4	1.131400+3	0.000000+0	1.029600-1	1.280000-1	0.000000+04231	2151	76
8.000000+4	1.101000+3	0.000000+0	1.001900-1	1.280000-1	0.000000+04231	2151	77
9.000000+4	1.079800+3	0.000000+0	9.826300-2	1.280000-1	0.000000+04231	2151	78
1.000000+5	1.060400+3	0.000000+0	9.649800-2	1.280000-1	0.000000+04231	2151	79
2.000000+5	8.498600+2	0.000000+0	7.733700-2	1.280000-1	0.000000+04231	2151	80
3.000000+5	6.518200+2	0.000000+0	5.931500-2	1.280000-1	0.000000+04231	2151	81
4.000000+5	5.087700+2	0.000000+0	4.629900-2	1.280000-1	0.000000+04231	2151	82
5.000000+5	4.121400+2	0.000000+0	3.750400-2	1.280000-1	0.000000+04231	2151	83
6.000000+5	3.355200+2	0.000000+0	3.053200-2	1.280000-1	0.000000+04231	2151	84
7.000000+5	2.817800+2	0.000000+0	2.564200-2	1.280000-1	0.000000+04231	2151	85
8.000000+5	2.368900+2	0.000000+0	2.155700-2	1.280000-1	0.000000+04231	2151	86
9.000000+5	2.074200+2	6.271400-4	1.887500-2	1.280000-1	0.000000+04231	2151	87
1.000000+6	2.104200+2	5.506000-2	1.914800-2	1.280000-1	0.000000+04231	2151	88
9.309840+1	0.000000+0	1	0	2	04231	2151	89
5.000000-1	0.000000+0	5	0	114	184231	2151	90
0.000000+0	0.000000+0	1.000000+0	1.000000+0	0.000000+0	0.000000+04231	2151	91
2.000000+4	1.256600+3	0.000000+0	9.085400-1	1.880000-1	0.000000+04231	2151	92
3.000000+4	1.219300+3	0.000000+0	8.815400-1	1.880000-1	0.000000+04231	2151	93
4.000000+4	1.200100+3	0.000000+0	8.676600-1	1.880000-1	0.000000+04231	2151	94
5.000000+4	1.176800+3	0.000000+0	8.508500-1	1.880000-1	0.000000+04231	2151	95
6.000000+4	1.156000+3	0.000000+0	8.358200-1	1.880000-1	0.000000+04231	2151	96
7.000000+4	1.131400+3	0.000000+0	8.179900-1	1.880000-1	0.000000+04231	2151	97
8.000000+4	1.101000+3	0.000000+0	7.959900-1	1.880000-1	0.000000+04231	2151	98
9.000000+4	1.079800+3	0.000000+0	7.807000-1	1.880000-1	0.000000+04231	2151	99
1.000000+5	1.060400+3	0.000000+0	7.666800-1	1.880000-1	0.000000+04231	2151	100
2.000000+5	8.498600+2	0.000000+0	6.144500-1	1.880000-1	0.000000+04231	2151	101
3.000000+5	6.518200+2	0.000000+0	4.712600-1	1.880000-1	0.000000+04231	2151	102
4.000000+5	5.087700+2	0.000000+0	3.678400-1	1.880000-1	0.000000+04231	2151	103
5.000000+5	4.121400+2	0.000000+0	2.979700-1	1.880000-1	0.000000+04231	2151	104
6.000000+5	3.355200+2	0.000000+0	2.425800-1	1.880000-1	0.000000+04231	2151	105
7.000000+5	2.817800+2	0.000000+0	2.037200-1	1.880000-1	0.000000+04231	2151	106
8.000000+5	2.368900+2	0.000000+0	1.712700-1	1.880000-1	0.000000+04231	2151	107
9.000000+5	2.074200+2	7.582400-1	1.499600-1	1.880000-1	0.000000+04231	2151	108
1.000000+6	2.104200+2	9.817500+0	1.521300-1	1.880000-1	0.000000+04231	2151	109
1.500000+0	0.000000+0	5	0	114	184231	2151	110
0.000000+0	0.000000+0	2.000000+0	1.000000+0	0.000000+0	0.000000+04231	2151	111
2.000000+4	6.283100+2	0.000000+0	4.542700-1	1.880000-1	0.000000+04231	2151	112
3.000000+4	6.096400+2	0.000000+0	4.407700-1	1.880000-1	0.000000+04231	2151	113
4.000000+4	6.000400+2	0.000000+0	4.338300-1	1.880000-1	0.000000+04231	2151	114
5.000000+4	5.884200+2	0.000000+0	4.254300-1	1.880000-1	0.000000+04231	2151	115
6.000000+4	5.780200+2	0.000000+0	4.179100-1	1.880000-1	0.000000+04231	2151	116
7.000000+4	5.656900+2	0.000000+0	4.090000-1	1.880000-1	0.000000+04231	2151	117
8.000000+4	5.504800+2	0.000000+0	3.980000-1	1.880000-1	0.000000+04231	2151	118
9.000000+4	5.399000+2	0.000000+0	3.903500-1	1.880000-1	0.000000+04231	2151	119
1.000000+5	5.302100+2	0.000000+0	3.833400-1	1.880000-1	0.000000+04231	2151	120
2.000000+5	4.249300+2	0.000000+0	3.072200-1	1.880000-1	0.000000+04231	2151	121
3.000000+5	3.259100+2	0.000000+0	2.356300-1	1.880000-1	0.000000+04231	2151	122
4.000000+5	2.543900+2	0.000000+0	1.839200-1	1.880000-1	0.000000+04231	2151	123
5.000000+5	2.060700+2	0.000000+0	1.489900-1	1.880000-1	0.000000+04231	2151	124
6.000000+5	1.677600+2	0.000000+0	1.212900-1	1.880000-1	0.000000+04231	2151	125
7.000000+5	1.408900+2	0.000000+0	1.018600-1	1.880000-1	0.000000+04231	2151	126
8.000000+5	1.184400+2	0.000000+0	8.563500-2	1.880000-1	0.000000+04231	2151	127
9.000000+5	1.037100+2	7.582400-1	7.498100-2	1.880000-1	0.000000+04231	2151	128
1.000000+6	1.052100+2	9.817500+0	7.606500-2	1.880000-1	0.000000+04231	2151	129

9.309840+1	0.000000+0	2	0	2	04231	2151	130
1.500000+0	0.000000+0	5	0	114	184231	2151	131
0.000000+0	0.000000+0	1.000000+0	1.000000+0	0.000000+0	0.000000+04231	2151	132
2.000000+4	6.283100+2	0.000000+0	4.398200-2	1.280000-1	0.000000+04231	2151	133
3.000000+4	6.096400+2	0.000000+0	4.267500-2	1.280000-1	0.000000+04231	2151	134
4.000000+4	6.000400+2	0.000000+0	4.200300-2	1.280000-1	0.000000+04231	2151	135
5.000000+4	5.884200+2	0.000000+0	4.118900-2	1.280000-1	0.000000+04231	2151	136
6.000000+4	5.780200+2	0.000000+0	4.046100-2	1.280000-1	0.000000+04231	2151	137
7.000000+4	5.656900+2	0.000000+0	3.959800-2	1.280000-1	0.000000+04231	2151	138
8.000000+4	5.504800+2	0.000000+0	3.853300-2	1.280000-1	0.000000+04231	2151	139
9.000000+4	5.399000+2	0.000000+0	3.779300-2	1.280000-1	0.000000+04231	2151	140
1.000000+5	5.302100+2	0.000000+0	3.711500-2	1.280000-1	0.000000+04231	2151	141
2.000000+5	4.249300+2	0.000000+0	2.974500-2	1.280000-1	0.000000+04231	2151	142
3.000000+5	3.259100+2	0.000000+0	2.281400-2	1.280000-1	0.000000+04231	2151	143
4.000000+5	2.543900+2	0.000000+0	1.780700-2	1.280000-1	0.000000+04231	2151	144
5.000000+5	2.060700+2	0.000000+0	1.442500-2	1.280000-1	0.000000+04231	2151	145
6.000000+5	1.677600+2	0.000000+0	1.174300-2	1.280000-1	0.000000+04231	2151	146
7.000000+5	1.408300+2	0.000000+0	9.862100-3	1.280000-1	0.000000+04231	2151	147
8.000000+5	1.184400+2	0.000000+0	8.291100-3	1.280000-1	0.000000+04231	2151	148
9.000000+5	1.037100+2	1.319800+0	7.259600-3	1.280000-1	0.000000+04231	2151	149
1.000000+6	1.052100+2	3.337800+0	7.364600-3	1.280000-1	0.000000+04231	2151	150
2.500000+0	0.000000+0	5	0	114	184231	2151	151
0.000000+0	0.000000+0	1.000000+0	1.000000+0	0.000000+0	0.000000+04231	2151	152
2.000000+4	4.188700+2	0.000000+0	2.932100-2	1.280000-1	0.000000+04231	2151	153
3.000000+4	4.064300+2	0.000000+0	2.845000-2	1.280000-1	0.000000+04231	2151	154
4.000000+4	4.000300+2	0.000000+0	2.800200-2	1.280000-1	0.000000+04231	2151	155
5.000000+4	3.922800+2	0.000000+0	2.746000-2	1.280000-1	0.000000+04231	2151	156
6.000000+4	3.853500+2	0.000000+0	2.697400-2	1.280000-1	0.000000+04231	2151	157
7.000000+4	3.771300+2	0.000000+0	2.639900-2	1.280000-1	0.000000+04231	2151	158
8.000000+4	3.669900+2	0.000000+0	2.568900-2	1.280000-1	0.000000+04231	2151	159
9.000000+4	3.599400+2	0.000000+0	2.519600-2	1.280000-1	0.000000+04231	2151	160
1.000000+5	3.534700+2	0.000000+0	2.474300-2	1.280000-1	0.000000+04231	2151	161
2.000000+5	2.832900+2	0.000000+0	1.983000-2	1.280000-1	0.000000+04231	2151	162
3.000000+5	2.172700+2	0.000000+0	1.520900-2	1.280000-1	0.000000+04231	2151	163
4.000000+5	1.695900+2	0.000000+0	1.187100-2	1.280000-1	0.000000+04231	2151	164
5.000000+5	1.373800+2	0.000000+0	9.616500-3	1.280000-1	0.000000+04231	2151	165
6.000000+5	1.118400+2	0.000000+0	7.828800-3	1.280000-1	0.000000+04231	2151	166
7.000000+5	9.392500+1	0.000000+0	6.574800-3	1.280000-1	0.000000+04231	2151	167
8.000000+5	7.896300+1	0.000000+0	5.527400-3	1.280000-1	0.000000+04231	2151	168
9.000000+5	6.913900+1	8.798500-1	4.839700-3	1.280000-1	0.000000+04231	2151	169
1.000000+6	7.013900+1	2.225200+0	4.909700-3	1.280000-1	0.000000+04231	2151	170
4231 2 099999							

# Covariance Data

0.000000+0	0.000000+0	0	0	0	04231	0	0
42094.0	9.309840+1	0	0	1	0423132151		1
42094.0	1.000000+0	0	0	1	0423132151		2
1.000000-5	2.000000+4	1	2	0	1423132151		3
0.0	7.000000-1	0	1	0	0423132151		4
9.309840+1		0	0	1	0423132151		5
		3	0	102	4423132151		6
1542.400000	0.5	1.560000+0	1.420000+0	1.400000-1	423132151		7
108.5000000	0.5	1.881100-1	1.100000-4	1.880000-1	423132151		8
1051.300000	0.5	1.940000-1	6.000000-3	1.880000-1	423132151		9
1664.000000	1.5	1.940000-1	6.000000-3	1.880000-1	423132151		10
1.394646+6	6.419856+2				423132151		11
					423132151		12
1.586016+0					423132151		13
				1.254400-2	423132151		14
					423132151		15
			4.961418+2	7.543787-4	423132151		16
					423132151		17
8.891025-9					423132151		18
	2.262016-2				423132151		19
		4.413985+5	3.772795+0		423132151		20





[illegible]

0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	128
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	129
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	130
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	131
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	132
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	133
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	134
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	135
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	136
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	137
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	138
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	139
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	140
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	141
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	142
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	143
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	144
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	145
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	146
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	147
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	148
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	149
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	150
1.791315-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	151
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	152
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	4.232072-4423133	1	153
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	154
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	155
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	156
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	157
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	158
4.443422-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	159
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	1	160
0.000000+0	0.000000+0	5.833191-4	1.941821-3	1.806570-3	1.618184-3423133	1	161
1.497424-3	1.439459-3	1.410477-3	1.386325-3	1.376664-3	1.357342-3423133	1	162
1.328360-3	1.342851-3	1.342851-3	6.464160-3	6.013920-3	5.386800-3423133	1	163
4.984800-3	4.791840-3	4.695360-3	4.614960-3	4.582800-3	4.518480-3423133	1	164
4.422000-3	4.470240-3	4.470240-3	5.595040-3	5.011600-3	4.637600-3423133	1	165
4.458080-3	4.368320-3	4.293520-3	4.263600-3	4.203760-3	4.114000-3423133	1	166
4.158880-3	4.158880-3	4.489000-3	4.154000-3	3.993200-3	3.912800-3423133	1	167
3.845800-3	3.819000-3	3.765400-3	3.685000-3	3.725200-3	3.725200-3423133	1	168
3.844000-3	3.695200-3	3.620800-3	3.558800-3	3.534000-3	3.484400-3423133	1	169
3.410000-3	3.447200-3	3.447200-3	3.552160-3	3.480640-3	3.421040-3423133	1	170
3.397200-3	3.349520-3	3.278000-3	3.313760-3	3.313760-3	3.410560-3423133	1	171
3.352160-3	3.328800-3	3.282080-3	3.212000-3	3.247040-3	3.247040-3423133	1	172
3.294760-3	3.271800-3	3.225880-3	3.157000-3	3.191440-3	3.191440-3423133	1	173
3.249000-3	3.203400-3	3.135000-3	3.169200-3	3.169200-3	3.158440-3423133	1	174
3.091000-3	3.124720-3	3.124720-3	3.025000-3	3.058000-3	3.058000-3423133	1	175
3.091360-3	3.091360-3	3.091360-3	0.000000+0	0.000000+0	0.000000+0423133	1	176
0.000000+0	0.000000+0	0	0	0	0423133	099999	
4.209400+4	9.309840+1	0	0	0	1423133	2	1
0.000000+0	0.000000+0	0	2	0	1423133	2	2
0.000000+0	0.000000+0	1	5	1035	45423133	2	3
1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000-2423133	2	4
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000-1423133	2	5
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000-1423133	2	6
4.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000+0423133	2	7
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000+2423133	2	8
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000+5423133	2	9
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000+6423133	2	10
6.434000+6	8.187300+6	2.000000+7	6.515256-4	0.000000+0	0.000000+0423133	2	11
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	2	12
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	2	13
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	2	14
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	2	15
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	2	16

[illegible]

[illegible]

0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	2	149
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	2	150
1.783827-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	2	151
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	2	152
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	4.280761-4423133	2	153
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	2	154
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	2	155
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	2	156
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	2	157
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	2	158
4.585457-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	2	159
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133	2	160
0.000000+0	0.000000+0	6.207074-4	1.435046-3	1.400167-3	1.430064-3423133	2	161
1.579548-3	1.873533-3	2.157552-3	2.553934-3	2.541228-3	3.188992-3423133	2	162
3.602564-3	3.548003-3	3.243803-3	3.317760-3	3.237120-3	3.306240-3423133	2	163
3.651840-3	4.331520-3	4.988160-3	5.904576-3	5.875200-3	7.372800-3423133	2	164
8.328960-3	8.202816-3	7.499520-3	3.158440-3	3.225880-3	3.563080-3423133	2	165
4.226240-3	4.866920-3	5.761062-3	5.732400-3	7.193600-3	8.126520-3423133	2	166
8.003442-3	7.317240-3	3.294760-3	3.639160-3	4.316480-3	4.970840-3423133	2	167
5.884074-3	5.854800-3	7.347200-3	8.300040-3	8.174334-3	7.473480-3423133	2	168
4.019560-3	4.767680-3	5.490440-3	6.499134-3	6.466800-3	8.115200-3423133	2	169
9.167640-3	9.028794-3	8.254680-3	5.655040-3	6.512320-3	7.708752-3423133	2	170
7.670400-3	9.625600-3	1.087392-2	1.070923-2	9.791040-3	7.499560-3423133	2	171
8.877366-3	8.833200-3	1.108480-2	1.252236-2	1.233271-2	1.127532-2423133	2	172
1.050830-2	1.045602-2	1.312128-2	1.482295-2	1.459845-2	1.334680-2423133	2	173
1.040400-2	1.305600-2	1.474920-2	1.452582-2	1.328040-2	1.638400-2423133	2	174
1.850880-2	1.822848-2	1.666560-2	2.090916-2	2.059249-2	1.882692-2423133	2	175
2.028061-2	1.854178-2	1.695204-2	0.000000+0	0.000000+0	0.000000+0423133	2	176
0.000000+0	0.000000+0	0	0	0	0423133	099999	
4.209400+4	9.309840+1	0	0	0	1423133102		1
0.000000+0	0.000000+0	0	102	0	1423133102		2
0.000000+0	0.000000+0	1	5	1035	45423133102		3
1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000-2423133102		4
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000-1423133102		5
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000-1423133102		6
4.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000+0423133102		7
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000+2423133102		8
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000+5423133102		9
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000+6423133102		10
6.434000+6	8.187300+6	2.000000+7	2.897825-2	0.000000+0	0.000000+0423133102		11
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		12
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		13
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		14
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		15
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		16
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		17
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	2.897485-2423133102		18
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		19
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		20
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		21
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		22
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		23
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		24
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		25
2.897485-2	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		26
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		27
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		28
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		29
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		30
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		31
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		32
2.897144-2	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		33
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		34
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		35
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		36
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423133102		37

[illegible]

[illegible]



4.350700-2	5.492446-2	8.145400-2	2.016400-2	2.357200-2	3.288294-2423133102	170
4.103800-2	2.527600-2	4.444600-2	5.610988-2	8.321200-2	2.755600-2423133102	171
3.844062-2	4.797400-2	2.954800-2	5.195800-2	6.559324-2	9.727600-2423133102	172
5.362466-2	6.692373-2	4.121946-2	7.248141-2	9.150257-2	1.357000-1423133102	173
8.352100-2	5.144200-2	9.045700-2	1.141955-1	1.693540-1	3.168400-2423133102	174
5.571400-2	7.033492-2	1.043080-1	9.796900-2	1.236788-1	1.834180-1423133102	175
1.561356-1	2.315520-1	3.433960-1	0.000000+0	0.000000+0	0.000000+0423133102	176
0.000000+0	0.000000+0	0	0	0	0423133	099999

<sup>95</sup>Mo

Resonance Parameters									
							4234	0	0
4.209500+4	9.409056+1	0	0	1			04234	2151	1
4.209500+4	1.000000+0	0	0	2			04234	2151	2
1.000000-5	2.000000+3	1	2	0			04234	2151	3
2.500000+0	7.000000-1	0	0	2			04234	2151	4
9.409056+1	0.000000+0	0	0	90			154234	2151	5
-3.700000+1	2.000000+0	4.300000-1	2.580000-1	1.720000-1	0.000000+0	4234	2151	6	
44.6440000	3.0	3.556000-1	1.737000-1	1.819000-1			4234	2151	7
159.365000	3.0	1.838200-1	1.382000-2	1.700000-1			4234	2151	8
358.420000	3.0	3.720000-1	2.220000-1	1.500000-1			4234	2151	9
661.400000	3.0	1.790000-1	9.000000-3	1.700000-1			4234	2151	10
680.370000	3.0	1.110000+0	9.000000-1	2.100000-1			4234	2151	11
769.900000	3.0	1.840000-1	1.400000-2	1.700000-1			4234	2151	12
1024.80000	3.0	2.500000-1	8.000000-2	1.700000-1			4234	2151	13
1203.70000	3.0	2.840000-1	1.440000-1	1.400000-1			4234	2151	14
1418.70000	3.0	5.600000-1	4.200000-1	1.400000-1			4234	2151	15
1589.60000	3.0	5.400000-1	3.600000-1	1.800000-1			4234	2151	16
1677.60000	3.0	3.000000-1	1.200000-1	1.800000-1			4234	2151	17
1766.20000	3.0	5.200000-1	3.300000-1	1.900000-1			4234	2151	18
2.048100+3	3.000000+0	5.040000-1	3.540000-1	1.500000-1	0.000000+0	4234	2151	19	
2.130100+3	2.000000+0	1.914000+0	1.764000+0	1.500000-1	0.000000+0	4234	2151	20	
9.409050+1	0.000000+0	1	0	222			374234	2151	21
110.200000	1.0	3.102500-1	2.500000-4	3.100000-1			4234	2151	22
117.870000	2.0	2.002100-1	2.100000-4	2.000000-1			4234	2151	23
217.880000	2.0	1.810200-1	1.020000-3	1.800000-1			4234	2151	24
245.700000	3.0	1.806000-1	6.000000-4	1.800000-1			4234	2151	25
263.600000	3.0	1.809000-1	9.000000-4	1.800000-1			4234	2151	26
330.800000	1.0	1.815000-1	1.500000-3	1.800000-1			4234	2151	27
417.400000	3.0	1.812000-1	1.200000-3	1.800000-1			4234	2151	28
554.290000	3.0	3.280000-1	1.460000-1	1.820000-1			4234	2151	29
596.700000	3.0	1.807000-1	7.000000-4	1.800000-1			4234	2151	30
629.700000	2.0	2.000000-1	2.000000-2	1.800000-1			4234	2151	31
700.700000	3.0	1.820000-1	2.000000-3	1.800000-1			4234	2151	32
708.200000	3.0	1.849000-1	4.900000-3	1.800000-1			4234	2151	33
745.400000	3.0	1.880000-1	8.000000-3	1.800000-1			4234	2151	34
898.650000	3.0	4.610000-1	3.210000-1	1.400000-1			4234	2151	35
932.000000	2.0	1.850000-1	5.000000-3	1.800000-1			4234	2151	36
954.000000	3.0	1.830000-1	3.000000-3	1.800000-1			4234	2151	37
980.700000	3.0	2.160000-1	3.600000-2	1.800000-1			4234	2151	38
1008.90000	2.0	1.880000-1	8.000000-3	1.800000-1			4234	2151	39
1036.10000	4.0	1.870000-1	7.000000-3	1.800000-1			4234	2151	40
1062.80000	3.0	1.850000-1	5.000000-3	1.800000-1			4234	2151	41
1122.00000	2.0	1.830000-1	3.000000-3	1.800000-1			4234	2151	42
1145.00000	3.0	3.840000-1	2.240000-1	1.600000-1			4234	2151	43
1173.20000	3.0	1.910000-1	1.100000-2	1.800000-1			4234	2151	44
1293.00000	3.0	1.880000-1	8.000000-3	1.800000-1			4234	2151	45
1340.90000	3.0	2.290000-1	4.900000-2	1.800000-1			4234	2151	46
1364.00000	3.0	1.870000-1	7.000000-3	1.800000-1			4234	2151	47
1384.60000	2.0	1.890000-1	9.000000-3	1.800000-1			4234	2151	48
1441.00000	2.0	1.880000-1	8.000000-3	1.800000-1			4234	2151	49
1496.10000	3.0	5.100000-1	3.300000-1	1.800000-1			4234	2151	50
1575.20000	4.0	1.890000-1	9.000000-3	1.800000-1			4234	2151	51
1789.10000	4.0	2.200000-1	4.000000-2	1.800000-1			4234	2151	52
1842.00000	3.0	2.040000-1	2.400000-2	1.800000-1			4234	2151	53
1921.00000	3.0	1.980000-1	1.800000-2	1.800000-1			4234	2151	54
1949.70000	3.0	1.080000+0	9.100000-1	1.700000-1			4234	2151	55
1959.50000	2.0	1.980000-1	1.800000-2	1.800000-1			4234	2151	56
2.112200+3	1.000000+0	3.008000-1	1.208000-1	1.800000-1	0.000000+0	4234	2151	57	
2.140900+3	3.000000+0	2.094000-1	2.940000-2	1.800000-1	0.000000+0	4234	2151	58	
2.000000+3	4.000000+5	2	2	0			04234	2151	59
2.500000+0	6.433100-1	1	0	3			04234	2151	60
9.409056+1	0.000000+0	0	0	2			04234	2151	61
2.000000+0	0.000000+0	5	0	132			214234	2151	62
0.000000+0	0.000000+0	1.000000+0	1.000000+0	0.000000+0	0.000000+0	4234	2151	63	

3.000000+3	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	64
3.000000+3	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	65
4.000000+3	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	66
5.000000+3	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	67
6.000000+3	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	68
7.000000+3	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	69
8.000000+3	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	70
9.000000+3	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	71
1.000000+4	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	72
2.000000+4	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	73
3.000000+4	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	74
4.000000+4	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	75
5.000000+4	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	76
6.000000+4	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	77
7.000000+4	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	78
8.000000+4	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	79
9.000000+4	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	80
1.000000+5	1.944000+2	0.000000+0	1.081400-2	1.620000-1	0.000000+0	2151	81
2.000000+5	1.441100+2	0.000000+0	8.016600-3	1.620000-1	0.000000+0	2151	82
3.000000+5	1.254700+2	2.149100+0	6.980100-3	1.620000-1	0.000000+0	2151	83
4.000000+5	1.058500+2	2.651400+0	5.888300-3	1.620000-1	0.000000+0	2151	84
3.000000+0	0.000000+0	5	0	132	214234	2151	85
0.000000+0	0.000000+0	2.000000+0	1.000000+0	0.000000+0	0.000000+0	2151	86
2.000000+3	1.388600+2	0.000000+0	7.724600-3	1.620000-1	0.000000+0	2151	87
3.000000+3	1.388600+2	0.000000+0	7.724600-3	1.620000-1	0.000000+0	2151	88
4.000000+3	1.388600+2	0.000000+0	7.724600-3	1.620000-1	0.000000+0	2151	89
5.000000+3	1.388600+2	0.000000+0	7.724600-3	1.620000-1	0.000000+0	2151	90
6.000000+3	1.388600+2	0.000000+0	7.724600-3	1.620000-1	0.000000+0	2151	91
7.000000+3	1.388600+2	0.000000+0	7.724600-3	1.620000-1	0.000000+0	2151	92
8.000000+3	1.388600+2	0.000000+0	7.724600-3	1.620000-1	0.000000+0	2151	93
9.000000+3	1.388600+2	0.000000+0	7.724600-3	1.620000-1	0.000000+0	2151	94
1.000000+4	1.388600+2	0.000000+0	7.724600-3	1.620000-1	0.000000+0	2151	95
2.000000+4	1.388600+2	0.000000+0	7.724600-3	1.620000-1	0.000000+0	2151	96
3.000000+4	1.388600+2	0.000000+0	7.724600-3	1.620000-1	0.000000+0	2151	97
4.000000+4	1.388600+2	0.000000+0	7.724600-3	1.620000-1	0.000000+0	2151	98
5.000000+4	1.388600+2	0.000000+0	7.724600-3	1.620000-1	0.000000+0	2151	99
6.000000+4	1.388600+2	0.000000+0	7.724600-3	1.620000-1	0.000000+0	2151	100
7.000000+4	1.388600+2	0.000000+0	7.7				

2.000000+5	2.091200+2	1.352300+1	1.440900-1	2.100000-1	0.000000+0	4234	2151	130
4.000000+5	1.764100+2	2.913600+1	1.215500-1	2.100000-1	0.000000+0	4234	2151	131
2.000000+0	0.000000+0	5	0	132	214234	2151	132	132
0.000000+0	0.000000+0	2.000000+0	2.000000+0	0.000000+0	0.000000+0	4234	2151	133
2.000000+3	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	134
3.000000+3	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	135
4.000000+3	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	136
5.000000+3	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	137
6.000000+3	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	138
7.000000+3	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	139
8.000000+3	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	140
9.000000+3	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	141
1.000000+4	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	142
2.000000+4	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	143
3.000000+4	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	144
4.000000+4	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	145
5.000000+4	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	146
6.000000+4	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	147
7.000000+4	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	148
8.000000+4	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	149
9.000000+4	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	150
1.000000+5	1.944000+2	0.000000+0	1.339400-1	2.100000-1	0.000000+0	4234	2151	151
2.000000+5	1.441100+2	0.000000+0	9.928900-2	2.100000-1	0.000000+0	4234	2151	152
3.000000+5	1.254700+2	8.113500+0	8.645100-2	2.100000-1	0.000000+0	4234	2151	153
4.000000+5	1.058500+2	1.748200+1	7.292900-2	2.100000-1	0.000000+0	4234	2151	154
3.000000+0	0.000000+0	5	0	132	214234	2151	155	155
0.000000+0	0.000000+0	1.000000+0	2.000000+0	0.000000+0	0.000000+0	4234	2151	156
2.000000+3	1.388600+2	0.000000+0	9.567300-2	2.100000-1	0.000000+0	4234	2151	157
3.000000+3	1.388600+2	0.000000+0	9.567300-2	2.100000-1	0.000000+0	4234	2151	158
4.000000+3	1.388600+2	0.000000+0	9.567300-2	2.100000-1	0.000000+0	4234	2151	159
5.000000+3	1.388600+2	0.000000+0	9.567300-2	2.100000-1	0.000000+0	4234	2151	160
6.000000+3	1.388600+2	0.000000+0	9.567300-2	2.100000-1	0.000000+0	4234	2151	161
7.000000+3	1.388600+2	0.000000+0	9.567300-2	2.100000-1	0.000000+0	4234	2151	162
8.000000+3	1.388600+2	0.000000+0	9.567300-2	2.100000-1	0.000000+0	4234	2151	163
9.000000+3	1.388600+2	0.000000+0	9.567300-2	2.100000-1				

0.000000+4	1.080000+2	0.000000+0	7.441200-2	2.100000-1	0.000000+04234	2151	196
1.000000+5	1.080000+2	0.000000+0	7.441200-2	2.100000-1	0.000000+04234	2151	197
2.000000+5	8.005900+1	0.000000+0	5.516000-2	2.100000-1	0.000000+04234	2151	198
3.000000+5	6.970700+1	0.000000+0	4.802800-2	2.100000-1	0.000000+04234	2151	199
4.000000+5	5.880400+1	0.000000+0	4.051600-2	2.100000-1	0.000000+04234	2151	200
9.409056+1	0.000000+0	2	0	6	04234	2151	201
0.000000+0	0.000000+0	5	0	132	214234	2151	202
0.000000+0	0.000000+0	1.000000+0	1.000000+0	0.000000+0	0.000000+04234	2151	203
2.000000+3	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	204
3.000000+3	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	205
4.000000+3	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	206
5.000000+3	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	207
6.000000+3	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	208
7.000000+3	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	209
8.000000+3	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	210
9.000000+3	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	211
1.000000+4	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	212
2.000000+4	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	213
3.000000+4	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	214
4.000000+4	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	215
5.000000+4	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	216
6.000000+4	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	217
7.000000+4	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	218
8.000000+4	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	219
9.000000+4	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	220
1.000000+5	9.720000+2	0.000000+0	4.568400-2	1.620000-1	0.000000+04234	2151	221
2.000000+5	7.205300+2	0.000000+0	3.386500-2	1.620000-1	0.000000+04234	2151	222
3.000000+5	6.273700+2	3.089500-2	2.948600-2	1.620000-1	0.000000+04234	2151	223
4.000000+5	5.292400+2	1.493900-1	2.487400-2	1.620000-1	0.000000+04234	2151	224
1.000000+0	0.000000+0	5	0	132	214234	2151	225
0.000000+0	0.000000+0	1.000000+0	2.000000+0	0.000000+0	0.000000+04234	2151	226
2.000000+3	3.240000+2	0.000000+0	1.522800-2	1.620000-1	0.000000+04234	2151	227
3.000000+3	3.240000+2	0.000000+0	1.522800-2	1.620000-1	0.000000+04234	2151	228
4.000000+3	3.240000+2	0.000000+0	1.522800-2	1.620000-1	0.000000+04234	2151	229
5.000000+3	3.240000+2	0.000000+0	1.522800-2	1.620000-1	0.000000+04234	2151	230
6.000000+3	3.240000+2	0.000000+0	1.522800-2	1.620000-1	0.000000+04234	2151	231
7.000000+3	3.240000+2	0.000000+0	1.52280				

5.000000+4	1.944000+2	0.000000+0	9.136800-3	1.620000-1	0.000000+04234	2151	262
6.000000+4	1.944000+2	0.000000+0	9.136800-3	1.620000-1	0.000000+04234	2151	263
7.000000+4	1.944000+2	0.000000+0	9.136800-3	1.620000-1	0.000000+04234	2151	264
8.000000+4	1.944000+2	0.000000+0	9.136800-3	1.620000-1	0.000000+04234	2151	265
9.000000+4	1.944000+2	0.000000+0	9.136800-3	1.620000-1	0.000000+04234	2151	266
1.000000+5	1.944000+2	0.000000+0	9.136800-3	1.620000-1	0.000000+04234	2151	267
2.000000+5	1.441100+2	0.000000+0	6.773000-3	1.620000-1	0.000000+04234	2151	268
3.000000+5	1.254700+2	2.149100+0	5.897200-3	1.620000-1	0.000000+04234	2151	269
4.000000+5	1.058500+2	2.651400+0	4.974800-3	1.620000-1	0.000000+04234	2151	270
3.000000+0	0.000000+0	5	0	132	214234	2151	271
0.000000+0	0.000000+0	2.000000+0	2.000000+0	0.000000+0	0.000000+04234	2151	272
2.000000+3	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	273
3.000000+3	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	274
4.000000+3	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	275
5.000000+3	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	276
6.000000+3	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	277
7.000000+3	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	278
8.000000+3	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	279
9.000000+3	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	280
1.000000+4	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	281
2.000000+4	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	282
3.000000+4	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	283
4.000000+4	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	284
5.000000+4	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	285
6.000000+4	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	286
7.000000+4	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	287
8.000000+4	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	288
9.000000+4	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	289
1.000000+5	1.388600+2	0.000000+0	6.526300-3	1.620000-1	0.000000+04234	2151	290
2.000000+5	1.029300+2	0.000000+0	4.837800-3	1.620000-1	0.000000+04234	2151	291
3.000000+5	8.962400+1	8.827100-3	4.212300-3	1.620000-1	0.000000+04234	2151	292
4.000000+5	7.560500+1	4.268400-2	3.553400-3	1.620000-1	0.000000+04234	2151	293
4.000000+0	0.000000+0	5	0	132	214234	2151	294
0.000000+0	0.000000+0	1.000000+0	2.000000+0	0.000000+0	0.000000+04234	2151	295
2.000000+3	1.080000+2	0.000000+0	5.076000-3	1.620000-1	0.000000+04234	2151	296
3.000000+3	1.080000+2	0.000000+0	5.076000-3	1.620000-1	0.000000+04234	2151	297
4.000000+3	1						

2.000000+4	8.836400+1	0.000000+0	4.153100-3	1.620000-1	0.000000+04234	2151	328
3.000000+4	8.836400+1	0.000000+0	4.153100-3	1.620000-1	0.000000+04234	2151	329
4.000000+4	8.836400+1	0.000000+0	4.153100-3	1.620000-1	0.000000+04234	2151	330
5.000000+4	8.836400+1	0.000000+0	4.153100-3	1.620000-1	0.000000+04234	2151	331
6.000000+4	8.836400+1	0.000000+0	4.153100-3	1.620000-1	0.000000+04234	2151	332
7.000000+4	8.836400+1	0.000000+0	4.153100-3	1.620000-1	0.000000+04234	2151	333
8.000000+4	8.836400+1	0.000000+0	4.153100-3	1.620000-1	0.000000+04234	2151	334
9.000000+4	8.836400+1	0.000000+0	4.153100-3	1.620000-1	0.000000+04234	2151	335
1.000000+5	8.836400+1	0.000000+0	4.153100-3	1.620000-1	0.000000+04234	2151	336
2.000000+5	6.550300+1	0.000000+0	3.078600-3	1.620000-1	0.000000+04234	2151	337
3.000000+5	5.703300+1	0.000000+0	2.680600-3	1.620000-1	0.000000+04234	2151	338
4.000000+5	4.811200+1	0.000000+0	2.261300-3	1.620000-1	0.000000+04234	2151	339
					4234	2	099999

Covariance Data

0.000000+0	0.000000+0	0	0	0	04234	0	0
42095.0	9.409060+1	0	0	1	0423432151		1
42095.0	1.000000+0	0	0	1	0423432151		2
1.000000-5	2.141200+3	1	2	0	1423432151		3
0.0	7.000000-1	0	1	0	0423432151		4
9.409060+1		0	0	1	0423432151		5
		3	0	738	12423432151		6
44.64400000	3.0	3.556000-1	1.737000-1	1.819000-1	423432151		7
159.3650000	3.0	1.838200-1	1.382000-2	1.700000-1	423432151		8
358.4200000	3.0	3.720000-1	2.220000-1	1.500000-1	423432151		9
110.2000000	1.0	3.102500-1	2.500000-4	3.100000-1	423432151		10
117.8700000	2.0	2.002100-1	2.100000-4	2.000000-1	423432151		11
217.8800000	2.0	1.810200-1	1.020000-3	1.800000-1	423432151		12
245.7000000	3.0	1.806000-1	6.000000-4	1.800000-1	423432151		13
263.6000000	3.0	1.809000-1	9.000000-4	1.800000-1	423432151		14
330.8000000	1.0	1.815000-1	1.500000-3	1.800000-1	423432151		15
417.4000000	3.0	1.812000-1	1.200000-3	1.800000-1	423432151		16
554.2900000	3.0	3.280000-1	1.460000-1	1.820000-1	423432151		17
596.7000000	3.0	1.807000-1	7.000000-4	1.800000-1	423432151		18
3.457083-6-3.889458-6	6.703187-6-1.768604-8	3.507554-8	6.383531-8423432151				19
3.885721-8-5.126473-7	8.126433-7-3.518246-7	1.533620-9	1.159969-6423432151				20
-1.467045-8	9.38075-10	4.322973-7	9.436199-9	3.465002-9	3.935214-7423432151		21
6.282926-8	2.261424-9	3.948495-7	2.167339-8	3.218487-9	5.013773-7423432151		22
-1.013706-7	5.006870-9	6.531984-8	8.846634-6	1.099907-8	3.557000-7423432151		23
4.977136-7-1.618966-6	3.682988-6-1.386903-7	2.032045-9-2.493383-9423432151					24
5.416361-6-9.181010-6	2.009027-8-4.132261-8-1.084439-7-7.233406-8423432151						25
1.017607-6-1.112623-6	4.072601-7-1.989121-9-1.517007-6	1.914806-8423432151					26
-1.219339-9-6.148632-7-1.260756-8-4.385059-9-5.644510-7-7.419473-8423432151							27
-2.879924-9-5.315586-7-2.737794-8-4.048155-9-6.662148-7	1.296427-7423432151						28
-6.535177-9-9.883325-8-1.037891-5-1.332815-8-4.416017-7-5.820049-7423432151							29
1.927981-6-4.372736-6	1.976242-7-2.750747-9	1.939843-9	1.684122-5423432151				30
-5.663597-8	1.130529-7	1.194464-7	1.317459-7-1.729099-6	2.651787-6423432151			31
-1.159607-6	4.485292-9	3.361112-6-4.170572-8	2.736181-9	1.124162-6423432151			32
2.635003-8	1.040248-8	1.005921-6	2.027223-7	6.742456-9	1.101088-6423432151		33
6.289368-8	9.730830-9	1.420688-6-2.947031-7	1.457085-8	1.548261-7423432151			34
2.866125-5	3.453094-8	1.090620-6	1.613159-6-5.128362-6	1.173796-5423432151			35
-3.568435-7	5.622562-9-1.085070-8	3.230787-5-5.107129-8-1.964409-6423432151					36
2.488507-8-9.411617-7	3.660267-7-5.403063-9-1.33943-11	3.520157-8423432151					37
1.930110-8-4.37129-12	1.620827-8-8.335814-9-2.25775-11-6.243661-8423432151						38
8.467680-9	1.11298-11-3.452750-8-8.517926-8	1.08115-10-5.877627-8423432151					39
1.513820-7	2.57188-10-2.609579-8-1.275556-6-1.402872-9	1.309924-8423432151					40
-2.372568-7	1.775027-6-2.676320-6	2.894123-8	3.86781-11-5.848889-9423432151				41
4.163664-8	1.539635-7	2.673998-9-5.942464-8	6.840281-8-2.688753-8423432151				42
1.02400-10	7.890831-8-6.32782-11	6.23795-11	2.674940-8	3.17213-10423432151			43
2.47118-10	2.401118-8	5.029326-9	1.64181-10	2.668694-8-2.352066-9423432151			44
2.39566-10	3.360663-8-4.57470-10	3.82101-10	3.680169-9	5.899620-7423432151			45
7.49154-10	2.709666-8	2.549923-8-3.774455-8	1.482264-7-9.759311-9423432151				46
1.63166-10-4.19262-10	1.889160-4-5.784524-8	6.931132-8	4.036384-8423432151				47
1.314019-7	5.905111-9	4.912584-6-4.373112-8	3.610533-9	3.341508-6423432151			48
5.507221-8	1.134326-8	3.686359-6	2.387851-8	8.448104-9	2.546275-6423432151		49
-8.978769-9	1.033241-8	2.929257-6-2.940117-7	2.572197-8	8.438883-7423432151			50

-2.481044-6 1.500483-8 9.874112-7-3.864009-7 6.853749-7-8.282434-7423432151 51  
 -1.480092-6 1.618196-8 3.884915-8 8.058085-5-3.652059-5 1.173510-5423432151 52  
 -4.768872-8-3.80797-10-3.040359-7 1.161239-8-2.39615-10-2.424835-7423432151 53  
 -6.807646-9-6.34474-10-2.814011-7 6.576941-9-4.47711-10-1.719341-7423432151 54  
 -3.588904-8-4.45641-10-1.950899-7 1.594192-7 9.94287-10 1.198526-8423432151 55  
 1.438172-7-7.74357-10-2.641303-8-4.500225-8 6.392655-7-8.979775-7423432151 56  
 1.108274-7-1.093511-9-5.780841-9 5.620122-4-2.110844-4 7.863896-7423432151 57  
 5.477335-9 4.014171-6-3.205545-7 3.431932-9 3.366967-6 1.647134-7423432151 58  
 9.024974-9 4.554657-6-1.694922-7 6.191058-9 2.741450-6 1.204471-6423432151 59  
 5.326215-9 3.275222-6-3.312883-6-1.084808-8 2.442668-7 7.108181-6423432151 60  
 2.143398-8 2.485424-7 2.495273-6-2.329653-5 3.401978-5-1.811803-6423432151 61  
 1.521616-8 1.307687-7 8.822629-5-7.727461-7-4.73621-10-3.139329-7423432151 62  
 1.162582-7-3.21458-10-9.207496-7-5.614561-8 5.51380-10-1.405840-6423432151 63  
 1.486414-7 2.39914-10-6.473742-7-4.703196-7 1.778378-9-7.381468-7423432151 64  
 1.164066-6 8.293874-9-1.019669-7 8.177407-6 4.851710-9 3.359336-7423432151 65  
 -4.071946-7 7.553566-6-9.371420-6 5.493027-7-3.375256-9-5.608271-8423432151 66  
 3.879499-2 1.345031-7-3.746013-4 6.602439-7-6.18151-10-1.586740-6423432151 67  
 6.643449-9-4.50668-10 4.529567-7-4.944465-8-1.51861-10 1.973379-7423432151 68  
 2.509940-8-6.07230-10 1.944506-7-5.364604-8 7.40677-10 1.191477-7423432151 69  
 -6.705552-6-5.123621-9-1.035313-7-3.381389-7 4.906462-7-1.671701-6423432151 70  
 -1.740151-7 1.297210-9 1.186199-8 9.257723-9 7.877537-6 2.943468-9423432151 71  
 2.04349-11 1.247705-8 3.41572-10 6.81885-11 2.095425-8 1.89446-10423432151 72  
 4.88430-11 1.435731-8 5.51963-10 5.97298-11 1.664134-8-2.714003-9423432151 73  
 1.40974-10 4.638075-9 1.442240-8 1.09106-10 5.714683-9 6.19487-10423432151 74  
 -1.137144-8 2.083294-8-8.012959-9 8.63185-11 2.29722-10 5.074184-2423432151 75  
 9.860694-6 1.071872-8 7.190726-6 2.746958-7 5.550931-8 1.715330-5423432151 76  
 1.490635-7 3.981738-8 1.173340-5 4.002269-7 4.866011-8 1.358008-5423432151 77  
 -2.126987-6 1.153298-7 3.792894-6 9.440011-6 8.694282-8 4.646988-6423432151 78  
 2.751950-7-8.007245-6 1.487358-5-6.555744-6 7.072017-8 1.861942-7423432151 79  
 1.543449-2 6.877105-8 1.509988-4-5.177221-9-5.93556-10-2.046630-7423432151 80  
 1.257471-9-4.17897-10-1.358446-7-2.717787-8-4.79525-10-1.614619-7423432151 81  
 6.335362-8-1.149351-9-4.801961-8-3.673804-7-1.226326-9-4.387913-8423432151 82  
 -6.250570-8 5.506219-7-8.494493-7 7.752283-8-7.34539-10-3.607684-9423432151 83  
 3.610453-9 3.97713-6 2.15242-10 4.28528-11 1.320321-8 1.16804-10423432151 84  
 3.07247-11 9.045250-9 3.46344-10 3.75620-11 1.048489-8-1.707416-9423432151 85  
 8.88790-11 2.928995-9 8.615481-9 6.84216-11 3.597392-9 3.60534-10423432151 86  
 -7.084080-9 1.294700-8-5.067248-9 5.45817-11 1.45610-10 2.160426-2423432151 87  
 1.919678-7 3.693487-8 1.198628-5 5.261685-8 2.666972-8 8.094084-6423432151 88  
 2.984972-7 3.219010-8 9.338733-6-1.493024-6 7.846121-8 2.673560-6423432151 89  
 -2.834127-8 5.379216-8 3.034624-6-1.276161-7-5.028783-6 8.573798-6423432151 90  
 -4.594997-6 4.900487-8 1.374931-7 1.044818-2-2.084678-7-2.081059-4423432151 91  
 1.26718-10 4.69561-10 1.463141-7 1.525979-8 5.58612-10 1.716595-7423432151 92  
 -4.420740-8 1.370382-9 5.053994-8 1.673221-7 1.148512-9 5.345390-8423432151 93  
 2.648970-8-3.016159-7 4.753033-7-8.642977-8 8.85832-10 3.163590-9423432151 94  
 3.539777-8 9.504206-6 4.67399-10 9.45419-11 2.734078-8 1.030659-9423432151 95  
 1.16702-10 3.184264-8-5.181591-9 2.73644-10 8.830892-9 4.040991-8423432151 96  
 2.23578-10 1.141196-8 1.830329-9-2.342276-8 4.426114-8-1.553145-8423432151 97  
 1.68871-10 4.34689-10 1.678587-2 4.525691-8 2.855826-8 8.731658-6423432151 98  
 4.141448-7 3.441191-8 1.011506-5-1.774624-6 8.473346-8 2.933258-6423432151 99  
 6.314140-7 5.955313-8 3.281465-6 7.596637-8-7.336039-6 1.205462-5423432151 100  
 -5.081723-6 5.392564-8 1.583808-7 2.023383-2 6.999769-8-7.161779-5423432151 101  
 -3.021407-9 4.42374-10 5.261652-8 8.179129-9 7.59402-10 6.520753-9423432151 102  
 9.978987-7 1.314404-9 5.233947-8 3.128851-8 4.200004-8 1.045843-7423432151 103  
 -1.913350-8 3.36161-10-1.047824-9 1.855697-8 5.882017-6 7.29258-10423432151 104  
 8.36925-11 2.298633-8-3.694840-9 1.97796-10 6.421447-9 2.477271-8423432151 105  
 1.57766-10 8.180540-9 1.021875-9-1.583706-8 2.980544-8-1.130069-8423432151 106  
 1.22740-10 3.18143-10 1.872511-2 2.741678-7 2.397647-8 6.899121-6423432151 107  
 -1.191918-6 5.834636-8 1.982304-6 2.749514-6 4.294061-8 2.310059-6423432151 108  
 1.519271-7-5.082943-6 8.691387-6-3.453650-6 3.689871-8 1.048411-7423432151 109  
 1.476116-2-3.017450-7-4.428452-5-2.209157-7 1.908194-9 1.083521-7423432151 110  
 1.334533-6 3.041206-9 6.761280-8 2.672213-7-2.219984-6 3.352469-6423432151 111  
 -1.690423-7 1.386207-9 1.110176-8 2.896265-8 8.341801-6-4.289725-9423432151 112  
 2.42597-10 7.709950-9 3.769888-8 1.99110-10 1.021610-8 1.412773-9423432151 113  
 -1.799462-8 3.564261-8-1.364773-8 1.49462-10 3.69151-10 1.802640-2423432151 114  
 -1.420382-6 6.775615-8 2.300340-6 4.307980-6 5.095904-8 2.698346-6423432151 115  
 2.781840-7-6.444644-6 1.102108-5-4.010868-6 4.283455-8 1.223324-7423432151 116



1.366299-1	7.539210-6	-1.566925-4	-2.956001-6	-1.081503-8	-4.078305-7	423432151	117	
-4.964283-7	4.493380-6	-6.954120-6	7.133585-7	-6.925328-9	-3.169317-8	423432151	118	
3.409492-7	1.059120-5	4.202537-8	4.38065-10	2.364612-8	8.63559-10	423432151	119	
-3.855738-8	7.188852-8	-3.378854-8	3.66130-10	9.62137-10	2.022472-2	423432151	120	
-1.336023-8	1.346913-8	7.375710-7	3.653343-8	-1.921820-6	3.074530-6	423432151	121	
-1.170035-6	1.234711-8	3.761935-8	1.486645-1	4.371182-5	-2.304074-3	423432151	122	
1.5216864-5	4.985117-5	9.706925-5	4.221815-7	1.050056-8	4.050060-8	423432151	123	
1.524944-7	7.698076-6	1.253820-8	-8.128960-8	1.506554-7	-2.404667-8	423432151	124	
2.63318-10	6.75654-10	2.031071-2	1.788765-7	-1.794966-6	3.668507-6	423432151	125	
-1.317659-6	1.453744-8	3.460838-8	4.042925-4	-1.045469-4	1.644352-4	423432151	126	
-3.789739-8	-5.42386-12	1.031457-8	4.261105-3	-6.494924-3	2.777725-6	423432151	127	
-2.550940-8	-1.951532-7	9.953896-3	-4.592998-6	4.462771-8	2.867660-7	423432151	128	
2.176935+0	4.940079-6	3.719275-5	1.924818-7	1.577938-6	2.069725-2	423432151	129	
0.0	0.0	0	0	0	0423432	0	130	
0.0	0.0	0	0	0	04234	0	131	
4.209500+4	9.409060+1	0	0	0	1423433	1	1	
0.000000+0	0.000000+0	0	1	0	1423433	1	2	
0.000000+0	0.000000+0	1	5	1035	45423433	1	3	
1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000-2	423433	1	4
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000-1	423433	1	5
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000-1	423433	1	6
4.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000+0	423433	1	7
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000+2	423433	1	8
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000+5	423433	1	9
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000+6	423433	1	10
6.434000+6	8.187300+6	2.000000+7	3.205485-3	0.000000+0	0.000000+0	423433	1	11
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	423433	1	12
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	423433	1	13
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	423433	1	14
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	423433	1	15
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	423433	1	16
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	423433	1	17
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	3.209336-3	423433	1	18
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	423433	1	19
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	423433	1	20
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	423433	1	21
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	423433	1	

[illegible]

6.525470-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	118
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	119
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	120
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	121
0.000000+0	0.000000+0	5.875291-4	0.000000+0	0.000000+0	0.000000+0423433	1	122
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	123
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	124
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	125
0.000000+0	0.000000+0	0.000000+0	5.148815-4	0.000000+0	0.000000+0423433	1	126
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	127
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	128
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	129
0.000000+0	0.000000+0	0.000000+0	5.355984-4	0.000000+0	0.000000+0423433	1	130
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	131
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	132
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	133
0.000000+0	0.000000+0	4.683329-4	0.000000+0	0.000000+0	0.000000+0423433	1	134
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	135
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	136
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	137
5.009539-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	138
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	139
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	140
0.000000+0	0.000000+0	0.000000+0	5.319020-4	0.000000+0	0.000000+0423433	1	141
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	142
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	143
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	5.799909-4423433	1	144
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	145
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	146
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	147
1.231870-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	148
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	149
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	150
1.008136-2	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	151
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	152
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	4.075673-3423433	1	153
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	154
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	155
0.000000+0	0.000000+0	0.000000+0	8.107202-3	0.000000+0	0.000000+0423433	1	156
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	157
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	158
4.050156-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	159
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	1	160
0.000000+0	0.000000+0	1.575276-4	5.999378-4	5.848766-4	5.848766-4423433	1	161
5.873868-4	5.898970-4	5.924072-4	5.924072-4	5.974276-4	6.175092-4423433	1	162
6.551622-4	6.829501-4	6.149990-4	2.284840-3	2.227480-3	2.227480-3423433	1	163
2.237040-3	2.246600-3	2.256160-3	2.256160-3	2.275280-3	2.351760-3423433	1	164
2.495160-3	2.600989-3	2.342200-3	2.171560-3	2.171560-3	2.180880-3423433	1	165
2.190200-3	2.199520-3	2.199520-3	2.218160-3	2.292720-3	2.432520-3423433	1	166
2.535692-3	2.283400-3	2.171560-3	2.180880-3	2.190200-3	2.199520-3423433	1	167
2.199520-3	2.218160-3	2.292720-3	2.432520-3	2.535692-3	2.283400-3423433	1	168
2.190240-3	2.199600-3	2.208960-3	2.208960-3	2.227680-3	2.302560-3423433	1	169
2.442960-3	2.546575-3	2.293200-3	2.209000-3	2.218400-3	2.218400-3423433	1	170
2.237200-3	2.312400-3	2.453400-3	2.557458-3	2.303000-3	2.227840-3423433	1	171
2.227840-3	2.246720-3	2.322240-3	2.463840-3	2.568341-3	2.312800-3423433	1	172
2.227840-3	2.246720-3	2.322240-3	2.463840-3	2.568341-3	2.312800-3423433	1	173
2.265760-3	2.341920-3	2.484720-3	2.590106-3	2.332400-3	2.420640-3423433	1	174
2.568240-3	2.677169-3	2.410800-3	2.724840-3	2.840411-3	2.557800-3423433	1	175
2.960883-3	2.666286-3	2.401000-3	0.000000+0	0.000000+0	0.000000+0423433	1	176
0.000000+0	0.000000+0	0	0	0	0423433	099999	
4.209500+4	9.409060+1	0	0	0	1423433	2	1
0.000000+0	0.000000+0	0	2	0	1423433	2	2
0.000000+0	0.000000+0	1	5	1035	45423433	2	3
1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000-2423433	2	4
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000-1423433	2	5
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000-1423433	2	6

0.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000+0	423433	2	7
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000+2	2423433	2	8
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000+5	5423433	2	9
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000+6	6423433	2	10
6.434000+6	8.187300+6	2.000000+7	7.845601-4	0.000000+0	0.000000+0	423433	2	11
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	12
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	13
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	14
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	15
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	16
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	17
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	7.817616-4	423433	2	18
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	423433	2	19
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	20
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	21
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	22
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	23
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	24
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	25
7.815379-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	26
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	27
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	28
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	29
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	30
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	31
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	32
7.813702-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	33
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	34
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	35
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	36
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	37
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	38
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	7.813143-4	423433	2	39
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0423433	2	40
0.000000+0	0.000000+0	0.000000+0	0.00000					

[illegible]

0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	139
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	140
0.000000+0	0.000000+0	0.000000+0	7.034695-4	0.000000+0	0.000000+0423433	2	141
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	142
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	143
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	7.351690-4423433	2	144
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	145
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	146
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	147
1.545905-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	148
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	149
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	150
2.549611-2	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	151
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	152
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	5.857147-3423433	2	153
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	154
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	155
0.000000+0	0.000000+0	0.000000+0	1.067606-2	0.000000+0	0.000000+0423433	2	156
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	157
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	158
4.855853-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	159
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433	2	160
0.000000+0	0.000000+0	1.951330-4	6.760996-4	7.040376-4	7.235942-4423433	2	161
8.269648-4	1.028118-3	1.204128-3	1.358541-3	1.598054-3	1.684661-3423433	2	162
1.620404-3	1.497337-3	1.472333-3	2.342560-3	2.439360-3	2.507120-3423433	2	163
2.865280-3	3.562240-3	4.172080-3	4.707094-3	5.536960-3	5.837040-3423433	2	164
5.614400-3	5.187996-3	5.101360-3	2.540160-3	2.610720-3	2.983680-3423433	2	165
3.709440-3	4.344480-3	4.901602-3	5.765760-3	6.078240-3	5.846400-3423433	2	166
5.402376-3	5.312160-3	2.683240-3	3.066560-3	3.812480-3	4.465160-3423433	2	167
5.037757-3	5.925920-3	6.247080-3	6.008800-3	5.552442-3	5.459720-3423433	2	168
3.504640-3	4.357120-3	5.103040-3	5.757437-3	6.772480-3	7.139520-3423433	2	169
6.867200-3	6.345648-3	6.239680-3	5.416960-3	6.344320-3	7.157894-3423433	2	170
8.419840-3	8.876160-3	8.537600-3	7.889184-3	7.757440-3	7.430440-3423433	2	171
8.383295-3	9.861280-3	1.039572-2	9.999200-3	9.239778-3	9.085480-3423433	2	172
9.458341-3	1.112586-2	1.172883-2	1.128146-2	1.042466-2	1.025057-2423433	2	173
1.308736-2	1.379664-2	1.327040-2	1.226254-2	1.205776-2	1.454436-2423433	2	174
1.398960-2	1.292711-2	1.271124-2	1.345600-2	1.243404-2	1.222640-2423433	2	175
1.148970-2	1.129783-2	1.110916-2	0.000000+0	0.000000+0	0.000000+0423433	2	176
0.000000+0	0.000000+0	0	0	0	0423433	099999	
4.209500+4	9.409060+1	0	0	0	1423433102	1	
0.000000+0	0.000000+0	0	102	0	1423433102	2	
0.000000+0	0.000000+0	1	5	1035	45423433102	3	
1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000-2423433102	4	
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000-1423433102	5	
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000-1423433102	6	
4.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000+0423433102	7	
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000+2423433102	8	
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000+5423433102	9	
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000+6423433102	10	
6.434000+6	8.187300+6	2.000000+7	4.367682-4	0.000000+0	0.000000+0423433102	11	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433102	12	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433102	13	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433102	14	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433102	15	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433102	16	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433102	17	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	4.366428-4423433102	18	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433102	19	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433102	20	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433102	21	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433102	22	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433102	23	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433102	24	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433102	25	
4.366428-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433102	26	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433102	27	

[illegible]

[illegible]



0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423433102	160
0.000000+0	0.000000+0	5.462504-4	2.776594-3	2.870082-3	3.038360-3423433102	161
3.711474-3	4.356541-3	4.987585-3	5.566042-3	6.310440-3	7.020949-3423433102	162
9.746124-3	1.046177-2	7.885713-3	1.411344-2	1.458864-2	1.544400-2423433102	163
1.886544-2	2.214432-2	2.535192-2	2.829222-2	3.207600-2	3.568752-2423433102	164
4.953960-2	5.317726-2	4.008312-2	1.507984-2	1.596400-2	1.950064-2423433102	165
2.288992-2	2.620552-2	2.924482-2	3.315600-2	3.688912-2	5.120760-2423433102	166
5.496774-2	4.143272-2	1.690000-2	2.064400-2	2.423200-2	2.774200-2423433102	167
3.095950-2	3.510000-2	3.905200-2	5.421000-2	5.819060-2	4.386200-2423433102	168
2.521744-2	2.960032-2	3.388792-2	3.781822-2	4.287600-2	4.770352-2423433102	169
6.621960-2	7.108206-2	5.357912-2	3.474496-2	3.977776-2	4.439116-2423433102	170
5.032800-2	5.599456-2	7.772880-2	8.343637-2	6.289136-2	4.553956-2423433102	171
5.082121-2	5.761800-2	6.410536-2	8.898780-2	9.552211-2	7.200116-2423433102	172
5.671542-2	6.430050-2	7.154026-2	9.930855-2	1.066007-1	8.035181-2423433102	173
7.290000-2	8.110800-2	1.125900-1	1.208574-1	9.109800-2	9.024016-2423433102	174
1.252668-1	1.344650-1	1.013550-1	1.738890-1	1.866575-1	1.406958-1423433102	175
2.003637-1	1.510270-1	1.138388-1	0.000000+0	0.000000+0	0.000000+0423433102	176
0.000000+0	0.000000+0	0	0	0	0423433 099999	

<sup>96</sup>Mo

# Resonance Parameters

					4237 0 0	0
4.209600+4	9.508081+1	0	0	1	04237 2151	1
4.209600+4	1.000000+0	0	0	2	04237 2151	2
1.000000-5	1.900000+4	1	2	0	04237 2151	3
0.000000+0	6.900000-1	0	0	2	04237 2151	4
9.508081+1	0.000000+0	0	0	90	154237 2151	5
131.171000	0.5	3.452000-1	2.598000-1	8.540000-2	0.000000+04237 2151	6
2.366000+3	5.000000-1	3.993000+0	3.829000+0	1.640000-1	0.000000+04237 2151	7
3.287000+3	5.000000-1	8.453000+0	8.318000+0	1.350000-1	0.000000+04237 2151	8
3.587000+3	5.000000-1	8.099000+0	8.000000+0	9.900000-2	0.000000+04237 2151	9
5.385000+3	5.000000-1	4.071000+0	4.000000+0	7.100000-2	0.000000+04237 2151	10
5.800000+3	5.000000-1	3.070000-1	2.000000-1	1.070000-1	0.000000+04237 2151	11
7.064000+3	5.000000-1	1.136000+0	1.000000+0	1.360000-1	0.000000+04237 2151	12
7.909000+3	5.000000-1	3.096000+0	3.000000+0	9.600000-2	0.000000+04237 2151	13
8.031000+3	5.000000-1	2.082000+0	2.000000+0	8.200000-2	0.000000+04237 2151	14
1.000000+4	5.000000-1	2.012000+1	2.000000+1	1.200000-1	0.000000+04237 2151	15
1.107500+4	5.000000-1	1.864000+0	1.750000+0	1.140000-1	0.000000+04237 2151	16
1.542400+4	5.000000-1	5.124000+0	5.000000+0	1.240000-1	0.000000+04237 2151	17
1.631700+4	5.000000-1	2.870000+0	2.700000+0	1.700000-1	0.000000+04237 2151	18
1.796500+4	5.000000-1	1.181000+0	1.067000+0	1.140000-1	0.000000+04237 2151	19
1.810700+4	5.000000-1	1.624000+0	1.510000+0	1.140000-1	0.000000+04237 2151	20
9.508081+1	0.000000+0	1	0	360	604237 2151	21
113.290000	0.5	1.364200-1	4.200000-4	1.360000-1	0.000000+04237 2151	22
419.060000	0.5	1.419000-1	5.900000-3	1.360000-1	0.000000+04237 2151	23
968.400000	0.5	1.384000-1	2.400000-3	1.360000-1	0.000000+04237 2151	24
1271.000000	0.5	1.371000-1	1.100000-3	1.360000-1	0.000000+04237 2151	25
1498.400000	0.5	1.460000-1	1.000000-2	1.360000-1	0.000000+04237 2151	26
2.084000+3	5.000000-1	1.435000-1	7.500000-3	1.360000-1	0.000000+04237 2151	27
2.488000+3	5.000000-1	1.700000-1	3.400000-2	1.360000-1	0.000000+04237 2151	28
2.784000+3	5.000000-1	2.030000-1	6.700000-2	1.360000-1	0.000000+04237 2151	29
3.286000+3	5.000000-1	2.279999-1	9.199990-2	1.360000-1	0.000000+04237 2151	30
3.764000+3	1.500000+0	2.800000-1	2.000000-1	8.000000-2	0.000000+04237 2151	31
4.326000+3	5.000000-1	4.280000-1	3.340000-1	9.400000-2	0.000000+04237 2151	32
4.420000+3	5.000000-1	3.880000-1	2.520000-1	1.360000-1	0.000000+04237 2151	33
4.567000+3	5.000000-1	1.887000-1	5.270000-2	1.360000-1	0.000000+04237 2151	34
4.953000+3	5.000000-1	1.497000-1	1.370000-2	1.360000-1	0.000000+04237 2151	35
5.413000+3	5.000000-1	2.530000-1	1.170000-1	1.360000-1	0.000000+04237 2151	36
5.619000+3	1.500000+0	6.250000-1	5.000000-1	1.250000-1	0.000000+04237 2151	37
6.046000+3	1.500000+0	1.091000+0	1.000000+0	9.100000-2	0.000000+04237 2151	38
6.570000+3	1.500000+0	1.316000+0	1.180000+0	1.360000-1	0.000000+04237 2151	39
7.382000+3	5.000000-1	1.680000-1	3.200000-2	1.360000-1	0.000000+04237 2151	40
7.741000+3	5.000000-1	1.930000-1	5.700000-2	1.360000-1	0.000000+04237 2151	41
7.776000+3	1.500000+0	3.110000-1	2.000000-1	1.110000-1	0.000000+04237 2151	42
7.951000+3	5.000000-1	1.106000+0	1.000000+0	1.060000-1	0.000000+04237 2151	43
8.334000+3	5.000000-1	1.134000+0	1.000000+0	1.340000-1	0.000000+04237 2151	44
8.420000+3	1.500000+0	1.164000+0	1.000000+0	1.640000-1	0.000000+04237 2151	45

8.712000+3	5.000000-1	6.610000-1	5.250000-1	1.360000-1	0.000000+04237	2151	46
9.090000+3	1.500000+0	1.121000+0	9.850000-1	1.360000-1	0.000000+04237	2151	47
9.396000+3	1.500000+0	8.151000+0	8.000000+0	1.510000-1	0.000000+04237	2151	48
9.700000+3	1.500000+0	6.730000-1	5.370000-1	1.360000-1	0.000000+04237	2151	49
1.011200+4	1.500000+0	5.160000+0	5.000000+0	1.600000-1	0.000000+04237	2151	50
1.027000+4	5.000000-1	5.440000-1	4.080000-1	1.360000-1	0.000000+04237	2151	51
1.086400+4	5.000000-1	1.850000-1	4.900000-2	1.360000-1	0.000000+04237	2151	52
1.092800+4	5.000000-1	1.637000-1	2.770000-2	1.360000-1	0.000000+04237	2151	53
1.150000+4	5.000000-1	1.594000-1	2.340000-2	1.360000-1	0.000000+04237	2151	54
1.191600+4	1.500000+0	6.060000-1	4.700000-1	1.360000-1	0.000000+04237	2151	55
1.205100+4	5.000000-1	4.280000-1	2.920000-1	1.360000-1	0.000000+04237	2151	56
1.231800+4	5.000000-1	2.940000-1	1.580000-1	1.360000-1	0.000000+04237	2151	57
1.308000+4	5.000000-1	3.860000-1	2.500000-1	1.360000-1	0.000000+04237	2151	58
1.360500+4	1.500000+0	6.270000-1	4.910000-1	1.360000-1	0.000000+04237	2151	59
1.388000+4	5.000000-1	4.510000-1	3.150000-1	1.360000-1	0.000000+04237	2151	60
1.394400+4	1.500000+0	4.110000-1	2.750000-1	1.360000-1	0.000000+04237	2151	61
1.408000+4	1.500000+0	4.460000-1	3.100000-1	1.360000-1	0.000000+04237	2151	62
1.447800+4	1.500000+0	5.870000-1	4.510000-1	1.360000-1	0.000000+04237	2151	63
1.469000+4	5.000000-1	1.810000-1	4.500000-2	1.360000-1	0.000000+04237	2151	64
1.502700+4	1.500000+0	5.970000-1	4.610000-1	1.360000-1	0.000000+04237	2151	65
1.535100+4	1.500000+0	5.118000+0	5.000000+0	1.180000-1	0.000000+04237	2151	66
1.560000+4	5.000000-1	5.280000-1	3.920000-1	1.360000-1	0.000000+04237	2151	67
1.581500+4	1.500000+0	6.214000+0	6.000000+0	2.140000-1	0.000000+04237	2151	68
1.616600+4	1.500000+0	7.550000-1	6.190000-1	1.360000-1	0.000000+04237	2151	69
1.642800+4	1.500000+0	5.520000-1	4.160000-1	1.360000-1	0.000000+04237	2151	70
1.670000+4	5.000000-1	3.700000-1	2.340000-1	1.360000-1	0.000000+04237	2151	71
1.680000+4	1.500000+0	3.490000-1	2.130000-1	1.360000-1	0.000000+04237	2151	72
1.704200+4	1.500000+0	3.060000-1	1.700000-1	1.360000-1	0.000000+04237	2151	73
1.724500+4	5.000000-1	1.710000-1	3.500000-2	1.360000-1	0.000000+04237	2151	74
1.779000+4	1.500000+0	1.670000+0	1.500000+0	1.700000-1	0.000000+04237	2151	75
1.827500+4	5.000000-1	4.620000-1	3.260000-1	1.360000-1	0.000000+04237	2151	76
1.856500+4	1.500000+0	1.156000+0	1.020000+0	1.360000-1	0.000000+04237	2151	77
1.899500+4	1.500000+0	1.028000+0	8.920000-1	1.360000-1	0.000000+04237	2151	78
1.913500+4	5.000000-1	1.745000-1	3.850000-2	1.360000-1	0.000000+04237	2151	79
1.937500+4	1.500000+0	4.000000+0	3.800000+0	2.000000-1	0.000000+04237	2151	80
1.960500+4	5.000000-1	4.870000-1	3.510000-1	1.360000-1	0.000000+04237	2151	81
1.900000+4	1.000000+6	2	2	0	04237	2151	82
0.000000+0	6.342600-1	1	0	3	04237	2151	83
9.508081+1	0.000000+0	0	0	1	04237	2151	84
5.000000-1	0.000000+0	5	0	120	194237	2151	85
0.000000+0	0.000000+0	2.000000+0	1.000000+0	0.000000+0	0.000000+04237	2151	86
1.900000+4	7.335800+2	0.000000+0	4.797400-2	9.600000-2	0.000000+04237	2151	87
2.000000+4	7.535000+2	0.000000+0	4.927700-2	9.600000-2	0.000000+04237	2151	88
3.000000+4	7.462100+2	0.000000+0	4.880100-2	9.600000-2	0.000000+04237	2151	89
4.000000+4	7.372800+2	0.000000+0	4.821600-2	9.600000-2	0.000000+04237	2151	90
5.000000+4	7.264400+2	0.000000+0	4.750700-2	9.600000-2	0.000000+04237	2151	91
6.000000+4	7.150800+2	0.000000+0	4.676500-2	9.600000-2	0.000000+04237	2151	92
7.000000+4	6.995800+2	0.000000+0	4.575100-2	9.600000-2	0.000000+04237	2151	93
8.000000+4	6.777900+2	0.000000+0	4.432600-2	9.600000-2	0.000000+04237	2151	94
9.000000+4	6.636800+2	0.000000+0	4.340300-2	9.600000-2	0.000000+04237	2151	95
1.000000+5	6.527000+2	0.000000+0	4.268500-2	9.600000-2	0.000000+04237	2151	96
2.000000+5	5.033700+2	0.000000+0	3.291900-2	9.600000-2	0.000000+04237	2151	97
3.000000+5	3.913800+2	0.000000+0	2.559500-2	9.600000-2	0.000000+04237	2151	98
4.000000+5	3.111100+2	0.000000+0	2.034600-2	9.600000-2	0.000000+04237	2151	99
5.000000+5	2.522300+2	0.000000+0	1.649500-2	9.600000-2	0.000000+04237	2151	100
6.000000+5	2.069200+2	0.000000+0	1.353200-2	9.600000-2	0.000000+04237	2151	101
7.000000+5	1.729400+2	0.000000+0	1.131000-2	9.600000-2	0.000000+04237	2151	102
8.000000+5	1.564600+2	1.760300-4	1.023200-2	9.600000-2	0.000000+04237	2151	103
9.000000+5	1.699100+2	3.621700-2	1.111100-2	9.600000-2	0.000000+04237	2151	104
1.000000+6	1.524400+2	1.468900-1	9.969500-3	9.600000-2	0.000000+04237	2151	105
9.508081+1	0.000000+0	1	0	2	04237	2151	106
5.000000-1	0.000000+0	5	0	120	194237	2151	107
0.000000+0	0.000000+0	1.000000+0	1.000000+0	0.000000+0	0.000000+04237	2151	108
1.900000+4	7.335800+2	0.000000+0	3.667900-1	1.250000-1	0.000000+04237	2151	109
2.000000+4	7.535000+2	0.000000+0	3.767500-1	1.250000-1	0.000000+04237	2151	110
3.000000+4	7.462100+2	0.000000+0	3.731100-1	1.250000-1	0.000000+04237	2151	111

4.000000+4	7.372800+2	0.000000+0	3.686400-1	1.250000-1	0.000000+04237	2151	112
5.000000+4	7.264400+2	0.000000+0	3.632200-1	1.250000-1	0.000000+04237	2151	113
6.000000+4	7.150800+2	0.000000+0	3.575400-1	1.250000-1	0.000000+04237	2151	114
7.000000+4	6.995800+2	0.000000+0	3.497900-1	1.250000-1	0.000000+04237	2151	115
8.000000+4	6.777900+2	0.000000+0	3.389000-1	1.250000-1	0.000000+04237	2151	116
9.000000+4	6.636800+2	0.000000+0	3.318400-1	1.250000-1	0.000000+04237	2151	117
1.000000+5	6.527000+2	0.000000+0	3.263500-1	1.250000-1	0.000000+04237	2151	118
2.000000+5	5.033700+2	0.000000+0	2.516900-1	1.250000-1	0.000000+04237	2151	119
3.000000+5	3.913800+2	0.000000+0	1.956900-1	1.250000-1	0.000000+04237	2151	120
4.000000+5	3.111100+2	0.000000+0	1.555600-1	1.250000-1	0.000000+04237	2151	121
5.000000+5	2.522300+2	0.000000+0	1.261200-1	1.250000-1	0.000000+04237	2151	122
6.000000+5	2.069200+2	0.000000+0	1.034600-1	1.250000-1	0.000000+04237	2151	123
7.000000+5	1.729400+2	0.000000+0	8.647200-2	1.250000-1	0.000000+04237	2151	124
8.000000+5	1.564600+2	2.342300-1	7.823000-2	1.250000-1	0.000000+04237	2151	125
9.000000+5	1.699100+2	5.177900+0	8.495300-2	1.250000-1	0.000000+04237	2151	126
1.000000+6	1.524400+2	1.033500+1	7.622200-2	1.250000-1	0.000000+04237	2151	127
1.500000+0	0.000000+0		5	0	120	194237	2151
0.000000+0	0.000000+0	2.000000+0	1.000000+0	0.000000+0	0.000000+04237	2151	129
1.900000+4	3.667900+2	0.000000+0	1.833900-1	1.250000-1	0.000000+04237	2151	130
2.000000+4	3.767500+2	0.000000+0	1.883700-1	1.250000-1	0.000000+04237	2151	131
3.000000+4	3.731100+2	0.000000+0	1.865500-1	1.250000-1	0.000000+04237	2151	132
4.000000+4	3.686400+2	0.000000+0	1.843200-1	1.250000-1	0.000000+04237	2151	133
5.000000+4	3.632200+2	0.000000+0	1.816100-1	1.250000-1	0.000000+04237	2151	134
6.000000+4	3.575400+2	0.000000+0	1.787700-1	1.250000-1	0.000000+04237	2151	135
7.000000+4	3.497900+2	0.000000+0	1.748900-1	1.250000-1	0.000000+04237	2151	136
8.000000+4	3.389000+2	0.000000+0	1.694500-1	1.250000-1	0.000000+04237	2151	137
9.000000+4	3.318400+2	0.000000+0	1.659200-1	1.250000-1	0.000000+04237	2151	138
1.000000+5	3.263500+2	0.000000+0	1.631700-1	1.250000-1	0.000000+04237	2151	139
2.000000+5	2.516900+2	0.000000+0	1.258400-1	1.250000-1	0.000000+04237	2151	140
3.000000+5	1.956900+2	0.000000+0	9.784400-2	1.250000-1	0.000000+04237	2151	141
4.000000+5	1.555600+2	0.000000+0	7.777800-2	1.250000-1	0.000000+04237	2151	142
5.000000+5	1.261200+2	0.000000+0	6.305800-2	1.250000-1	0.000000+04237	2151	143
6.000000+5	1.034600+2	0.000000+0	5.173000-2	1.250000-1	0.000000+04237	2151	144
7.000000+5	8.647200+1	0.000000+0	4.323500-2	1.250000-1	0.000000+04237	2151	145
8.000000+5	7.823000+1	2.342300-1	3.911500-2	1.250000-1	0.000000+04237	2151	146
9.000000+5	8.495300+1	5.177900+0	4.247700-2	1.250000-1	0.000000+04237	2151	147
1.000000+6	7.622200+1	1.033500+1	3.811100-2	1.250000-1	0.000000+04237	2151	148
9.508081+1	0.000000+0		2	0	2	04237	2151
1.500000+0	0.000000+0		5	0	120	194237	2151
0.000000+0	0.000000+0	1.000000+0	1.000000+0	0.000000+0	0.000000+04237	2151	151
1.900000+4	3.667900+2	0.000000+0	2.310800-2	9.600000-2	0.000000+04237	2151	152
2.000000+4	3.767500+2	0.000000+0	2.373500-2	9.600000-2	0.000000+04237	2151	153
3.000000+4	3.731100+2	0.000000+0	2.350600-2	9.600000-2	0.000000+04237	2151	154
4.000000+4	3.686400+2	0.000000+0	2.322400-2	9.600000-2	0.000000+04237	2151	155
5.000000+4	3.632200+2	0.000000+0	2.288300-2	9.600000-2	0.000000+04237	2151	156
6.000000+4	3.575400+2	0.000000+0	2.252500-2	9.600000-2	0.000000+04237	2151	157
7.000000+4	3.497900+2	0.000000+0	2.203700-2	9.600000-2	0.000000+04237	2151	158
8.000000+4	3.389000+2	0.000000+0	2.135000-2	9.600000-2	0.000000+04237	2151	159
9.000000+4	3.318400+2	0.000000+0	2.090600-2	9.600000-2	0.000000+04237	2151	160
1.000000+5	3.263500+2	0.000000+0	2.056000-2	9.600000-2	0.000000+04237	2151	161
2.000000+5	2.516900+2	0.000000+0	1.585600-2	9.600000-2	0.000000+04237	2151	162
3.000000+5	1.956900+2	0.000000+0	1.232800-2	9.600000-2	0.000000+04237	2151	163
4.000000+5	1.555600+2	0.000000+0	9.800000-3	9.600000-2	0.000000+04237	2151	164
5.000000+5	1.261200+2	0.000000+0	7.945300-3	9.600000-2	0.000000+04237	2151	165
6.000000+5	1.034600+2	0.000000+0	6.518000-3	9.600000-2	0.000000+04237	2151	166
7.000000+5	8.647200+1	0.000000+0	5.447700-3	9.600000-2	0.000000+04237	2151	167
8.000000+5	7.823000+1	5.960500-1	4.928500-3	9.600000-2	0.000000+04237	2151	168
9.000000+5	8.495300+1	1.890400+0	5.352100-3	9.600000-2	0.000000+04237	2151	169
1.000000+6	7.622200+1	2.377100+0	4.802000-3	9.600000-2	0.000000+04237	2151	170
2.500000+0	0.000000+0		5	0	120	194237	2151
0.000000+0	0.000000+0	1.000000+0	1.000000+0	0.000000+0	0.000000+04237	2151	172
1.900000+4	2.445300+2	0.000000+0	1.540500-2	9.600000-2	0.000000+04237	2151	173
2.000000+4	2.511700+2	0.000000+0	1.582300-2	9.600000-2	0.000000+04237	2151	174
3.000000+4	2.487400+2	0.000000+0	1.567100-2	9.600000-2	0.000000+04237	2151	175
4.000000+4	2.457600+2	0.000000+0	1.548300-2	9.600000-2	0.000000+04237	2151	176
5.000000+4	2.421500+2	0.000000+0	1.525500-2	9.600000-2	0.000000+04237	2151	177

6.000000+4	2.383600+2	0.000000+0	1.501700-2	9.600000-2	0.000000+04237	2151	178
7.000000+4	2.331900+2	0.000000+0	1.469100-2	9.600000-2	0.000000+04237	2151	179
8.000000+4	2.259300+2	0.000000+0	1.423400-2	9.600000-2	0.000000+04237	2151	180
9.000000+4	2.212300+2	0.000000+0	1.393700-2	9.600000-2	0.000000+04237	2151	181
1.000000+5	2.175700+2	0.000000+0	1.370700-2	9.600000-2	0.000000+04237	2151	182
2.000000+5	1.677900+2	0.000000+0	1.057100-2	9.600000-2	0.000000+04237	2151	183
3.000000+5	1.304600+2	0.000000+0	8.218900-3	9.600000-2	0.000000+04237	2151	184
4.000000+5	1.037000+2	0.000000+0	6.533300-3	9.600000-2	0.000000+04237	2151	185
5.000000+5	8.407800+1	0.000000+0	5.296900-3	9.600000-2	0.000000+04237	2151	186
6.000000+5	6.897300+1	0.000000+0	4.345300-3	9.600000-2	0.000000+04237	2151	187
7.000000+5	5.764800+1	0.000000+0	3.631800-3	9.600000-2	0.000000+04237	2151	188
8.000000+5	5.215300+1	3.973700-1	3.285600-3	9.600000-2	0.000000+04237	2151	189
9.000000+5	5.663500+1	1.260300+0	3.568000-3	9.600000-2	0.000000+04237	2151	190
1.000000+6	5.081500+1	1.584700+0	3.201300-3	9.600000-2	0.000000+04237	2151	191
						4237 2	099999

Covariance Data

0.000000+0	0.000000+0	0	0	0	04237 0 0	0
42096.0	9.508080+1	0	0	1	0423732151	1
42096.0	1.000000+0	0	0	1	0423732151	2
1.000000-5	1.900000+4	1	2	0	1423732151	3
0.0	7.000000-1	0	1	0	0423732151	4
9.508080+1		0	0	1	0423732151	5
		3	0	63	3423732151	6
131.1710000	0.5	3.452000-1	2.598000-1	8.540000-2	423732151	7
113.2900000	0.5	1.364200-1	4.200000-4	1.360000-1	423732151	8
419.0600000	0.5	1.419000-1	5.900000-3	1.360000-1	423732151	9
8.449829-5-1.504718-5	6.865532-7	1.137985-8	4.78522-11	4.031212-8423732151		10
-1.354975-7-1.231459-9-3.921703-8	2.682354-4-1.758360-5-1.017361-7423732151					11
-3.25748-10-1.023846-7	5.286876-7	1.559265-8	3.271907-6	5.700454-6423732151		12
-8.02752-10	1.48355-10-1.515247-8	2.234351-8	2.525425-9-2.214231-9423732151			13
6.155148-4	3.069553-8	2.367844-5-3.752552-8-3.59442-13	8.832315-8423732151			14
1.198195-9	1.345105-6	5.94097-10	4.02802-11	7.050314-9	3.820072-3423732151	15
8.585841-7	4.366537-8	9.361430-6	2.027010-3-2.004630-6	6.990560-4423732151		16
9.148947-8	3.010841-6	7.826025-3			423732151	17
0.0	0.0	0	0	0	0423732	0 18
0.0	0.0	0	0	0	04237 0 0	0 19
0.0	0.0	0	0	0	0423732	099999
0.0	0.0	0	0	0	04237 0 0	0
4.209600+4	9.508080+1	0	0	0	1423733	1 1
0.000000+0	0.000000+0	0	1	0	1423733	1 2
0.000000+0	0.000000+0	1	5	1035	45423733	1 3
1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000-2423733	1 4
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000-1423733	1 5
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000-1423733	1 6
0.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000+0423733	1 7
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000+2423733	1 8
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000+5423733	1 9
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000+6423733	1 10
6.434000+6	8.187300+6	2.000000+7	2.246701-4	0.000000+0	0.000000+0423733	1 11
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	1 12
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	1 13
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	1 14
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	1 15
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	1 16
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	1 17
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	3.377876-4423733	1 18
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	1 19
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	1 20
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	1 21
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	1 22
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	1 23
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	1 24
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	1 25
3.492040-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	1 26
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	1 27

[illegible]

[illegible]

0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	1	160
0.000000+0	0.000000+0	6.362502-4	2.557714-3	2.376101-3	2.002786-3423733	1	161
1.589112-3	1.422634-3	1.397410-3	1.397208-3	1.407499-3	1.412544-3423733	1	162
1.422634-3	1.463194-3	1.457947-3	1.028196-2	9.551880-3	8.051160-3423733	1	163
6.388200-3	5.718960-3	5.617560-3	5.616749-3	5.658120-3	5.678400-3423733	1	164
5.718960-3	5.882011-3	5.860920-3	8.873640-3	7.479480-3	5.934600-3423733	1	165
5.312880-3	5.218680-3	5.217926-3	5.256360-3	5.275200-3	5.312880-3423733	1	166
5.464354-3	5.444760-3	6.304360-3	5.002200-3	4.478160-3	4.398760-3423733	1	167
4.398125-3	4.430520-3	4.446400-3	4.478160-3	4.605835-3	4.589320-3423733	1	168
3.969000-3	3.553200-3	3.490200-3	3.489696-3	3.515400-3	3.528000-3423733	1	169
3.553200-3	3.654504-3	3.641400-3	3.180960-3	3.124560-3	3.124109-3423733	1	170
3.147120-3	3.158400-3	3.180960-3	3.271651-3	3.259920-3	3.069160-3423733	1	171
3.068717-3	3.091320-3	3.102400-3	3.124560-3	3.213643-3	3.202120-3423733	1	172
3.068274-3	3.090874-3	3.101952-3	3.124109-3	3.213179-3	3.201658-3423733	1	173
3.113640-3	3.124800-3	3.147120-3	3.236846-3	3.225240-3	3.136000-3423733	1	174
3.158400-3	3.248448-3	3.236800-3	3.180960-3	3.271651-3	3.259920-3423733	1	175
3.364928-3	3.352862-3	3.340840-3	0.000000+0	0.000000+0	0.000000+0423733	1	176
0.000000+0	0.000000+0	0	0	0	0423733	099999	
4.209600+4	9.508080+1	0	0	0	1423733	2	1
0.000000+0	0.000000+0	0	2	0	1423733	2	2
0.000000+0	0.000000+0	1	5	1035	45423733	2	3
1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000-2423733	2	4
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000-1423733	2	5
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000-1423733	2	6
4.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000+0423733	2	7
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000+2423733	2	8
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000+5423733	2	9
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000+6423733	2	10
6.434000+6	8.187300+6	2.000000+7	7.771271-4	0.000000+0	0.000000+0423733	2	11
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	12
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	13
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	14
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	15
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	16
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	17
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	7.615944-4423733	2	18
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	19
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	20
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	21
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	22
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	23
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	24
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	25
7.602703-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	26
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	27
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	28
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	29
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	30
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	31
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	32
7.594434-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	33
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	34
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	35
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	36
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	37
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	38
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	7.590576-4423733	2	39
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	40
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	41
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	42
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	43
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	44
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	45
0.000000+0	0.000000+0	0.000000+0	7.589474-4	0.000000+0	0.000000+0423733	2	46
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	47
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	48

[illegible]



0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	115
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	116
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	117
9.769346-5	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	118
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	119
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	120
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	121
0.000000+0	0.000000+0	9.982008-5	0.000000+0	0.000000+0	0.000000+0423733	2	122
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	123
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	124
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	125
0.000000+0	0.000000+0	0.000000+0	1.039380-4	0.000000+0	0.000000+0423733	2	126
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	127
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	128
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	129
0.000000+0	0.000000+0	0.000000+0	9.451728-5	0.000000+0	0.000000+0423733	2	130
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	131
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	132
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	133
0.000000+0	0.000000+0	1.056167-4	0.000000+0	0.000000+0	0.000000+0423733	2	134
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	135
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	136
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	137
1.176791-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	138
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	139
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	140
0.000000+0	0.000000+0	0.000000+0	1.136143-4	0.000000+0	0.000000+0423733	2	141
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	142
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	143
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	1.315838-4423733	2	144
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	145
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	146
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	147
1.974306-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	148
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	149
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	150
1.625460-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	151
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	152
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	3.489275-2423733	2	153
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	154
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	155
0.000000+0	0.000000+0	0.000000+0	1.366561-4	0.000000+0	0.000000+0423733	2	156
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	157
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	158
4.477879-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	159
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733	2	160
0.000000+0	0.000000+0	6.629080-4	1.848635-3	1.663256-3	1.647808-3423733	2	161
1.848635-3	2.167897-3	2.554102-3	2.826506-3	3.305915-3	3.681821-3423733	2	162
3.764211-3	3.439542-3	3.254421-3	5.155240-3	4.638280-3	4.595200-3423733	2	163
5.155240-3	6.045560-3	7.122560-3	7.882204-3	9.219120-3	1.026740-2423733	2	164
1.049716-2	9.591762-3	9.075520-3	4.173160-3	4.134400-3	4.638280-3423733	2	165
5.439320-3	6.408320-3	7.091788-3	8.294640-3	9.237800-3	9.444520-3423733	2	166
8.629914-3	8.165440-3	4.096000-3	4.595200-3	5.388800-3	6.348800-3423733	2	167
7.025920-3	8.217600-3	9.152000-3	9.356800-3	8.549760-3	8.089600-3423733	2	168
5.155240-3	6.045560-3	7.122560-3	7.882204-3	9.219120-3	1.026740-2423733	2	169
1.049716-2	9.591762-3	9.075520-3	7.089640-3	8.352640-3	9.243476-3423733	2	170
1.081128-2	1.204060-2	1.231004-2	1.124828-2	1.064288-2	9.840640-3423733	2	171
1.089018-2	1.273728-2	1.418560-2	1.450304-2	1.325213-2	1.253888-2423733	2	172
1.205165-2	1.409575-2	1.569854-2	1.604984-2	1.466551-2	1.387619-2423733	2	173
1.648656-2	1.836120-2	1.877208-2	1.715296-2	1.622976-2	2.044900-2423733	2	174
2.090660-2	1.910337-2	1.807520-2	2.137444-2	1.953086-2	1.847968-2423733	2	175
1.784629-2	1.688578-2	1.597696-2	0.000000+0	0.000000+0	0.000000+0423733	2	176
0.000000+0	0.000000+0	0	0	0	0423733	099999	
4.209600+4	9.508080+1	0	0	0	1423733102	1	
0.000000+0	0.000000+0	0	102	0	1423733102	2	
0.000000+0	0.000000+0	1	5	1035	45423733102	3	

1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000-2423733102	4
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000-1423733102	5
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000-1423733102	6
4.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000+0423733102	7
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000+2423733102	8
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000+5423733102	9
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000+6423733102	10
6.434000+6	8.187300+6	2.000000+7	1.571567-1	0.000000+0	0.000000+0423733102	11
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	12
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	13
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	14
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	15
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	16
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	17
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	1.571488-1423733102	18
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	19
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	20
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	21
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	22
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	23
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	24
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	25
1.571488-1	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	26
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	27
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	28
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	29
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	30
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	31
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	32
1.571488-1	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	33
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	34
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	35
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	36
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	37
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	38
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	1.571488-1423733102	39
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	40
0.000000+0	0.000000+0</					

[illegible]

0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	136
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	137
1.139834-2	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	138
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	139
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	140
0.000000+0	0.000000+0	0.000000+0	1.144215-2	0.000000+0	0.000000+0423733102	141
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	142
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	143
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	1.149291-2423733102	144
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	145
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	146
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	147
1.155410-2	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	148
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	149
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	150
1.206373-2	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	151
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	152
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	3.061450-2423733102	153
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	154
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	155
0.000000+0	0.000000+0	0.000000+0	3.097600-2	0.000000+0	0.000000+0423733102	156
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	157
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	158
3.097600-2	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	159
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0423733102	160
0.000000+0	0.000000+0	3.097600-2	2.400640-2	2.266880-2	2.488640-2423733102	161
3.463680-2	3.850880-2	4.642880-2	5.094672-2	6.019200-2	7.001280-2423733102	162
9.074560-2	1.056563-1	1.056000-1	1.860496-2	1.756832-2	1.928696-2423733102	163
2.684352-2	2.984432-2	3.598232-2	3.948371-2	4.664880-2	5.425992-2423733102	164
7.032784-2	8.188365-2	8.184000-2	1.658944-2	1.821232-2	2.534784-2423733102	165
2.818144-2	3.397744-2	3.728374-2	4.404960-2	5.123664-2	6.640928-2423733102	166
7.732122-2	7.728000-2	1.999396-2	2.782752-2	3.093832-2	3.730132-2423733102	167
4.093106-2	4.835880-2	5.624892-2	7.290584-2	8.488525-2	8.484000-2423733102	168
3.873024-2	4.305984-2	5.191584-2	5.696770-2	6.730560-2	7.828704-2423733102	169
1.014701-1	1.181430-1	1.180800-1	4.787344-2	5.771944-2	6.333604-2423733102	170
7.482960-2	8.703864-2	1.128133-1	1.313500-1	1.312800-1	6.959044-2423733102	171
7.636219-2	9.021960-2	1.049396-1	1.360153-1	1.583644-1	1.582800-1423733102	172
8.379288-2	9.899874-2	1.151512-1	1.492507-1	1.737746-1	1.736820-1423733102	173
1.169640-1	1.360476-1	1.763352-1	2.053094-1	2.052000-1	1.582448-1423733102	174
2.051057-1	2.388073-1	2.386800-1	2.658434-1	3.095250-1	3.093600-1423733102	175
3.603841-1	3.601920-1	3.600000-1	0.000000+0	0.000000+0	0.000000+0423733102	176
0.000000+0	0.000000+0	0	0	0	0423733 099999	

<sup>97</sup>Mo

Resonance Parameters									
						4240	0	0	0
4.209700+4	9.607355+1	0	0	1		04240	2151		1
4.209700+4	1.000000+0	0	0	2		04240	2151		2
1.000000-5	1.800000+3	1	2	0		04240	2151		3
2.500000+0	6.900000-1	0	0	2		04240	2151		4
9.607355+1	0.000000+0	0	0	162		274240	2151		5
-6.850000+1	2.000000+0	4.710000-1	3.000000-1	1.710000-1	0.000000+04240	2151			6
70.8390000	2.0	1.588600-1	1.886000-2	1.400000-1	0.000000+04240	2151			7
267.900000	3.0	1.347000-1	1.470000-2	1.200000-1	0.000000+04240	2151			8
285.855000	2.0	2.400000-1	1.050000-1	1.350000-1	0.000000+04240	2151			9
311.770000	3.0	1.286000-1	8.600000-3	1.200000-1	0.000000+04240	2151			10
396.990000	3.0	2.100000-1	7.000000-2	1.400000-1	0.000000+04240	2151			11
505.090000	2.0	2.350000-1	7.500000-2	1.600000-1	0.000000+04240	2151			12
557.830000	3.0	5.920000-1	4.730000-1	1.190000-1	0.000000+04240	2151			13
675.700000	3.0	5.320000-1	3.120000-1	2.200000-1	0.000000+04240	2151			14
786.030000	3.0	4.200000-1	3.000000-1	1.200000-1	0.000000+04240	2151			15
862.500000	2.0	1.780000-1	3.800000-2	1.400000-1	0.000000+04240	2151			16
1008.50000	2.0	2.000000-1	6.000000-2	1.400000-1	0.000000+04240	2151			17
1107.87000	2.0	5.900000-1	4.700000-1	1.200000-1	0.000000+04240	2151			18
1133.70000	2.0	1.620000-1	2.200000-2	1.400000-1	0.000000+04240	2151			19
1176.70000	2.0	1.920000-1	5.200000-2	1.400000-1	0.000000+04240	2151			20
1249.60000	3.0	1.370000+0	1.240000+0	1.300000-1	0.000000+04240	2151			21
1271.60000	3.0	1.400000-1	2.000000-2	1.200000-1	0.000000+04240	2151			22
1290.90000	3.0	1.410000-1	2.100000-2	1.200000-1	0.000000+04240	2151			23
1319.00000	2.0	1.590000-1	1.900000-2	1.400000-1	0.000000+04240	2151			24
1365.00000	3.0	1.680000-1	4.800000-2	1.200000-1	0.000000+04240	2151			25
1423.40000	3.0	1.700000-1	5.000000-2	1.200000-1	0.000000+04240	2151			26
1534.80000	2.0	1.720000+0	1.570000+0	1.500000-1	0.000000+04240	2151			27
1597.30000	2.0	2.100000-1	7.000000-2	1.400000-1	0.000000+04240	2151			28
1695.40000	3.0	2.700000-1	1.100000-1	1.600000-1	0.000000+04240	2151			29
1713.00000	2.0	5.300000-1	3.900000-1	1.400000-1	0.000000+04240	2151			30
1934.00000	2.0	1.900000-1	5.000000-2	1.400000-1	0.000000+04240	2151			31
1942.80000	3.0	1.600000-1	4.000000-2	1.200000-1	0.000000+04240	2151			32
9.607355+1	0.000000+0	1	0	210		354240	2151		33
79.5000000	1.0	1.201600-1	1.600000-4	1.200000-1	0.000000+04240	2151			34
109.200000	1.0	2.103700-1	3.700000-4	2.100000-1	0.000000+04240	2151			35
127.010000	1.0	2.105200-1	5.200000-4	2.100000-1	0.000000+04240	2151			36
136.220000	4.0	2.104500-1	4.500000-4	2.100000-1	0.000000+04240	2151			37
209.500000	4.0	2.105000-1	5.000000-4	2.100000-1	0.000000+04240	2151			38
227.420000	3.0	2.117000-1	1.700000-3	2.100000-1	0.000000+04240	2151			39
233.300000	3.0	2.106000-1	6.000000-4	2.100000-1	0.000000+04240	2151			40
248.000000	4.0	2.111000-1	1.100000-3	2.100000-1	0.000000+04240	2151			41
320.900000	4.0	2.111000-1	1.100000-3	2.100000-1	0.000000+04240	2151			42
352.540000	3.0	2.186000-1	8.600000-3	2.100000-1	0.000000+04240	2151			43
380.790000	3.0	2.159000-1	5.900000-3	2.100000-1	0.000000+04240	2151			44
457.500000	2.0	2.122000-1	2.200000-3	2.100000-1	0.000000+04240	2151			45
528.900000	3.0	2.112000-1	1.200000-3	2.100000-1	0.000000+04240	2151			46
533.700000	3.0	2.135000-1	3.500000-3	2.100000-1	0.000000+04240	2151			47
548.300000	3.0	2.143000-1	4.300000-3	2.100000-1	0.000000+04240	2151			48
564.100000	3.0	2.122000-1	2.200000-3	2.100000-1	0.000000+04240	2151			49
568.000000	3.0	2.150000-1	5.000000-3	2.100000-1	0.000000+04240	2151			50
571.200000	2.0	2.170000-1	7.000000-3	2.100000-1	0.000000+04240	2151			51
579.500000	4.0	2.111000-1	1.100000-3	2.100000-1	0.000000+04240	2151			52
653.100000	4.0	2.120000-1	2.000000-3	2.100000-1	0.000000+04240	2151			53
694.400000	2.0	2.210000-1	1.100000-2	2.100000-1	0.000000+04240	2151			54
699.400000	4.0	2.150000-1	5.000000-3	2.100000-1	0.000000+04240	2151			55
809.600000	2.0	2.140000-1	4.000000-3	2.100000-1	0.000000+04240	2151			56
906.300000	4.0	2.170000-1	7.000000-3	2.100000-1	0.000000+04240	2151			57
976.000000	2.0	2.230000-1	1.300000-2	2.100000-1	0.000000+04240	2151			58
1333.40000	4.0	2.360000-1	2.600000-2	2.100000-1	0.000000+04240	2151			59
1375.60000	3.0	2.230000-1	1.300000-2	2.100000-1	0.000000+04240	2151			60
1398.60000	3.0	2.210000-1	1.100000-2	2.100000-1	0.000000+04240	2151			61
1493.00000	3.0	2.200000-1	1.000000-2	2.100000-1	0.000000+04240	2151			62
1553.00000	1.0	2.220000-1	1.200000-2	2.100000-1	0.000000+04240	2151			63

1630.00000	2.0	2.180000-1	8.000000-3	2.100000-1	0.000000+04240	2151	64
1795.50000	4.0	2.400000-1	3.000000-2	2.100000-1	0.000000+04240	2151	65
1834.00000	3.0	2.220000-1	1.200000-2	2.100000-1	0.000000+04240	2151	66
1868.00000	1.0	2.500000-1	4.000000-2	2.100000-1	0.000000+04240	2151	67
1868.00000	4.0	2.220000-1	1.200000-2	2.100000-1	0.000000+04240	2151	68
1.800000+3	3.000000+5	2	2	0	04240	2151	69
2.500000+0	6.388000-1	1	0	3	04240	2151	70
9.607355+1	0.000000+0	0	0	2	04240	2151	71
2.000000+0	0.000000+0	5	0	132	214240	2151	72
0.000000+0	0.000000+0	0.000000+0	1.000000+0	0.000000+0	0.000000+04240	2151	73
1.800000+3	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	74
2.000000+3	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	75
3.000000+3	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	76
4.000000+3	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	77
5.000000+3	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	78
6.000000+3	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	79
7.000000+3	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	80
8.000000+3	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	81
9.000000+3	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	82
1.000000+4	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	83
2.000000+4	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	84
3.000000+4	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	85
4.000000+4	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	86
5.000000+4	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	87
6.000000+4	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	88
7.000000+4	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	89
8.000000+4	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	90
9.000000+4	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	91
1.000000+5	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	92
2.000000+5	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	93
3.000000+5	1.116000+2	0.000000+0	4.203900-3	1.300000-1	0.000000+04240	2151	94
3.000000+0	0.000000+0	5	0	132	214240	2151	95
0.000000+0	0.000000+0	0.000000+0	1.000000+0	0.000000+0	0.000000+04240	2151	96
1.800000+3	7.971400+1	0.000000+0	3.002800-3	1.300000-1	0.000000+04240	2151	97
2.000000+3	7.971400+1	0.000000+0	3.002800-3	1.300000-1	0.000000+04240	2151	98
3.000000+3	7.971400+1	0.000000+0	3.002800-3	1.300000-1	0.000000+04240	2151	99
4.000000+3	7.971400+1	0.000000+0	3.002800-3	1.300000-1	0.000000+04240	2151	100
5.000000+3	7.971400+1	0.000000+0	3.002800-3	1.300000-1	0.000		

[illegible]

[illegible]



[illegible]

0.000000+0	0.000000+0	0.000000+0	1.000000+0	0.000000+0	0.000000+04240	2151	328
1.800000+3	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	329
2.000000+3	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	330
3.000000+3	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	331
4.000000+3	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	332
5.000000+3	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	333
6.000000+3	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	334
7.000000+3	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	335
8.000000+3	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	336
9.000000+3	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	337
1.000000+4	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	338
2.000000+4	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	339
3.000000+4	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	340
4.000000+4	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	341
5.000000+4	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	342
6.000000+4	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	343
7.000000+4	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	344
8.000000+4	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	345
9.000000+4	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	346
1.000000+5	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	347
2.000000+5	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	348
3.000000+5	5.072700+1	0.000000+0	1.674000-3	1.300000-1	0.000000+04240	2151	349
						4240 2	099999

Covariance Data

					4240 0 0	0
42097.0	9.607350+1	0	0	1	0424032151	1
42097.0	1.000000+0	0	0	1	0424032151	2
1.000000-5	1.800000+3	1	2	0	1424032151	3
0.0	7.000000-1	0	1	0	0424032151	4
9.607350+1		0	0	1	0424032151	5
		3	0	3237	26424032151	6
70.83900000	2.0	1.588600-1	1.886000-2	1.400000-1	424032151	7
267.9000000	3.0	1.347000-1	1.470000-2	1.200000-1	424032151	8
285.8550000	2.0	2.400000-1	1.050000-1	1.350000-1	424032151	9
311.7700000	3.0	1.286000-1	8.600000-3	1.200000-1	424032151	10
396.9900000	3.0	2.100000-1	7.000000-2	1.400000-1	424032151	11
505.0900000	2.0	2.350000-1	7.500000-2	1.600000-1	424032151	12
557.8300000	3.0	5.920000-1	4.730000-1	1.190000-1	424032151	13
79.50000000	1.0	1.201600-1	1.600000-4	1.200000-1	424032151	14
109.2000000	1.0	2.103700-1	3.700000-4	2.100000-1	424032151	15
127.0100000	1.0	2.105200-1	5.200000-4	2.100000-1	424032151	16
136.2200000	4.0	2.104500-1	4.500000-4	2.100000-1	424032151	17
209.5000000	4.0	2.105000-1	5.000000-4	2.100000-1	424032151	18
227.4200000	3.0	2.117000-1	1.700000-3	2.100000-1	424032151	19
233.3000000	3.0	2.106000-1	6.000000-4	2.100000-1	424032151	20
248.0000000	4.0	2.111000-1	1.100000-3	2.100000-1	424032151	21
320.9000000	4.0	2.111000-1	1.100000-3	2.100000-1	424032151	22
352.5400000	3.0	2.186000-1	8.600000-3	2.100000-1	424032151	23
380.7900000	3.0	2.159000-1	5.900000-3	2.100000-1	424032151	24
457.5000000	2.0	2.122000-1	2.200000-3	2.100000-1	424032151	25
528.9000000	3.0	2.112000-1	1.200000-3	2.100000-1	424032151	26
533.7000000	3.0	2.135000-1	3.500000-3	2.100000-1	424032151	27
548.3000000	3.0	2.143000-1	4.300000-3	2.100000-1	424032151	28
564.1000000	3.0	2.122000-1	2.200000-3	2.100000-1	424032151	29
568.0000000	3.0	2.150000-1	5.000000-3	2.100000-1	424032151	30
571.2000000	2.0	2.170000-1	7.000000-3	2.100000-1	424032151	31
579.5000000	4.0	2.111000-1	1.100000-3	2.100000-1	424032151	32
2.259015-4-2.157133-7-3.004512-6-1.422038-9	1.211987-9-7.949436-8	424032151	33			
-1.319228-8-1.150811-8	2.449003-8-1.54502-10	4.83141-10-8.869105-8	424032151	34		
3.608801-8	9.500429-8-3.762952-7	2.166087-7-7.76001-10	1.256020-8	424032151	35	
7.784301-8-6.114403-7	2.183094-8-6.68815-10-1.53714-11-1.115573-8	424032151	36			
1.472127-8-2.31574-12	4.883682-9	1.157992-8	1.27867-11	1.583731-8	424032151	37
5.296469-9	1.12107-11	1.831668-8	4.250484-9	6.93511-13-1.630544-8	424032151	38
-1.213924-8	5.49679-11-1.277890-8-1.890741-9	1.92220-12-1.644115-8	424032151	39		
-2.291814-9	8.58551-12-4.252960-8	4.08840-10	3.11860-11-1.898833-8	424032151	40	

-1.047404-8 2.65000-10-7.083596-8-3.996637-8 2.31789-10-1.301477-7424032151 41  
 2.728819-8 1.81007-10-1.699338-8-1.171988-8 8.75944-11-7.601536-9424032151 42  
 -7.632332-9-1.44650-11 1.045269-9 3.654634-8 7.66087-10-4.167790-8424032151 43  
 -3.457759-7 1.513668-9 1.526285-8-1.252574-7 1.028366-9-3.214006-8424032151 44  
 5.990414-8 9.87661-10-4.485085-8-2.704309-8 1.29259-10-4.660929-9424032151 45  
 1.264018-6-4.902384-6-7.85049-10 1.465305-9 3.114756-8-2.436840-9424032151 46  
 7.905562-9 5.665158-8 6.45201-11 1.095527-9 6.610024-8 1.351127-8424032151 47  
 2.694112-8-6.638698-8 1.639663-7 2.965474-8 7.043615-8 7.599783-9424032151 48  
 -9.405375-8 1.782549-8 1.124486-9 6.96273-11 2.931597-8-5.904219-9424032151 49  
 2.31676-10 1.472189-7 3.119515-9 2.86205-10 1.166618-7 1.269687-9424032151 50  
 1.69534-10 1.693333-7-1.221032-9 2.14344-10 1.345034-7-4.410733-9424032151 51  
 4.91517-10 1.542713-7 3.486420-9 2.74916-10 1.012705-7-3.05008-10424032151 52  
 3.62809-9 1.524590-7 1.342545-9 3.95582-10 8.728748-8-9.513830-9424032151 53  
 1.600466-9 1.431530-7-1.971583-8 1.265291-9 1.091807-7 1.770385-8424032151 54  
 1.152722-9 3.310076-8-1.707864-8 7.46186-10 1.344520-8 5.512188-8424032151 55  
 1.267289-9 7.070018-8 5.044505-9 1.483427-9 5.168554-8-7.009009-8424032151 56  
 1.204599-9 9.762355-9-4.915807-8 1.501593-9 1.373342-8 5.174676-8424032151 57  
 2.126087-9 2.174546-8 6.402498-8 6.60384-10 9.664093-9 1.088652-3424032151 58  
 -2.512879-8-5.633588-9 4.390187-6 1.291781-7-2.673189-7 3.973808-6424032151 59  
 8.394174-9 2.390075-8 7.305944-6 1.646306-7-8.887544-7 4.285308-6424032151 60  
 -2.264199-7 1.441342-6 4.036918-6-1.037661-7 3.863170-6 2.764592-8424032151 61  
 1.213619-6 6.04083-11-1.076005-7 7.024105-8 1.454799-8 9.742356-6424032151 62  
 -3.958151-7 1.751283-8 7.704610-6 3.949140-8 9.987898-9 1.203594-5424032151 63  
 -1.945135-7 1.413086-8 1.097746-5-5.240552-8 2.789817-8 1.238960-5424032151 64  
 3.082532-7 1.836695-8 8.400691-6 6.794697-8 2.198157-8 1.263525-5424032151 65  
 9.604819-8 2.440007-8 7.342448-6-1.390348-7 5.476610-8 9.323297-6424032151 66  
 -5.658229-7 6.028103-8 1.163995-5-5.318385-7 6.938067-8 2.973716-6424032151 67  
 -1.060578-6 5.135255-8 1.242503-6-8.419552-7 7.075930-8 4.244083-6424032151 68  
 -5.765780-7 7.437337-8 4.439716-6 2.814286-7 5.545829-8 7.956902-7424032151 69  
 -1.198385-6 6.917582-8 2.080295-6 2.577473-6 1.069723-7 2.865823-6424032151 70  
 5.382986-6 4.453189-8 9.175866-7 1.290799-4-5.288012-8-1.144909-5424032151 71  
 8.370645-9 4.521018-8-9.071002-8-5.90881-11-2.92664-10 7.178365-9424032151 72  
 -1.546956-8-3.453059-8 1.324894-7-8.927988-8-7.283511-9-2.388630-8424032151 73  
 3.122093-8 2.334857-7-9.382143-9 3.928462-9-2.89113-11-1.429837-8424032151 74  
 -6.032446-9-6.34829-11-4.493947-8-3.092867-9-8.20053-11-3.998836-8424032151 75  
 -2.280008-9-4.84749-11-5.963793-8-7.77266-10-5.34096-11-3.414940-8424032151 76  
 5.441635-9-1.01731-10-2.927300-8 1.929839-9-3.97324-11-1.056940-8424032151 77  
 6.402185-9 7.32830-11 6.337444-8-9.13907-10-1.09845-10-2.100776-8424032151 78  
 4.956910-9-3.69365-10-1.368135-8 1.884861-8-3.81993-10-8.27503-10424032151 79  
 -8.960342-9-4.09639-10-7.299387-9 9.809075-9-2.85374-10-2.917099-9424032151 80  
 5.553776-9-3.45218-10-2.134713-8-1.252785-8-6.82480-10-4.948114-9424032151 81  
 1.411915-7-8.95328-10-1.039858-8 5.717234-8-7.64680-10 2.734090-9424032151 82  
 -3.681968-8-9.33615-10 4.238745-9-1.523053-8-2.70368-10-2.557465-9424032151 83  
 1.386508-7-6.158644-6-6.694600-9 6.057149-9 1.803755-8-9.36911-11424032151 84  
 6.48865-10-3.641871-8 1.286538-8 4.165725-8-1.423110-7 1.545296-7424032151 85  
 7.000470-9 9.829369-9 1.640944-8-1.899597-7 1.608614-8-2.857007-9424032151 86  
 7.28080-13-4.682919-9-3.441231-9 1.29916-11 3.349545-9 8.247001-9424032151 87  
 2.66911-11 5.776397-9 9.53691-10 2.19735-11 4.03250-11 1.758188-9424032151 88  
 1.29503-11-1.667034-8-4.137364-9 9.52202-11-1.162589-8-3.19377-10424032151 89  
 2.63443-11-8.796261-9 7.99600-10 1.02572-10 1.047214-8-4.21696-11424032151 90  
 4.46388-11-1.451430-8-7.058385-9 6.62252-10-8.55118-10-1.361420-8424032151 91  
 3.33758-10-6.051461-8 2.282498-8 1.35283-10-9.704077-9-2.678662-9424032151 92  
 1.10897-11-4.432118-9 5.117704-8 1.84378-10 7.176409-9 1.483049-8424032151 93  
 4.03932-10-1.463919-8-9.936248-8 4.89058-10 5.85143-10-3.933524-8424032151 94  
 5.04632-10-1.641591-8 1.809161-8 5.57933-10-2.060384-8-1.411926-8424032151 95  
 2.56950-11-3.375678-9 8.942240-4 1.018802-6 9.669924-7-2.183606-6424032151 96  
 1.799956-8 8.023205-9 7.123550-6-7.232029-7-3.032439-6 1.269047-5424032151 97  
 -5.411601-6 1.294747-6 3.620659-6-2.017398-6 1.881411-5-5.102879-7424032151 98  
 9.481769-8 5.086392-9 2.689921-6-2.969711-7 1.210183-8 7.956042-6424032151 99  
 -6.038890-7 1.409355-8 5.961640-6-8.961326-8 7.946526-9 9.476781-6424032151 100  
 -2.725229-7 1.143546-8 9.296755-6 2.292554-7 1.970117-8 9.668146-6424032151 101  
 1.746905-7 1.300279-8 6.354114-6-2.261479-7 8.034201-9 5.701714-6424032151 102  
 9.072173-8 1.993072-8 6.687249-6 1.307962-7 4.234982-8 9.999312-6424032151 103  
 4.507660-7 4.905719-8 1.367643-5-1.139941-6 5.988056-8 3.161289-6424032151 104  
 -7.024484-7 4.594188-8 1.345450-6-5.890639-7 6.664022-8 3.949936-6424032151 105  
 -1.459705-6 5.099980-8 5.154115-6 8.872163-6 1.473501-8 3.394392-7424032151 106

1.945893-6 3.999848-8 2.705976-6 9.861830-7 7.673843-8 3.770424-6424032151 107  
5.737714-6 3.880170-8 9.757371-7 4.311172-3-2.620876-5-1.215891-4424032151 108  
-2.48464-10-8.17157-10 3.553189-7-1.367126-7-3.943512-7 1.577173-6424032151 109  
-8.816510-7-5.167176-8 3.109299-7-3.111270-7 2.576916-6-8.887597-8424032151 110  
2.909399-8 1.52553-10 8.698939-8-5.334766-8 3.94482-10 2.412999-7424032151 111  
-5.698032-8 4.13231-10 1.446945-7-1.845260-8 2.17729-10 2.519007-7424032151 112  
-2.192005-8 4.32832-10 4.075981-7 4.651263-8 7.08776-10 4.702290-7424032151 113  
2.412781-8 6.32184-10 3.608224-7 1.657528-8 8.88641-10 7.039069-7424032151 114  
-5.457447-9 8.30964-10 3.678436-7 3.748408-8 5.77425-10 5.722655-7424032151 115  
1.386922-7 8.91130-10 8.743907-7-1.265379-7 1.380323-9 1.579060-7424032151 116  
1.283738-8 1.227698-9 6.810982-8-1.075525-8 2.159397-9 1.232953-7424032151 117  
-1.684247-7-8.17393-10 2.962646-7 1.400784-6-4.368937-9-4.077305-8424032151 118  
4.608488-7-1.995858-9 1.868107-7-1.543592-7-6.68548-10 2.636268-7424032151 119  
2.737663-7 8.63474-10 4.680490-8 2.594758-3-4.011210-3-2.766259-8424032151 120  
6.863798-9 8.353982-8 8.555323-8 3.964839-7-1.440858-6 1.543577-6424032151 121  
-3.688854-8-1.778144-7 1.374193-7-1.833807-6 1.252269-7-1.358648-8424032151 122  
-3.45773-10-2.170735-7-1.797838-8-7.07062-10-5.054373-7 8.915789-8424032151 123  
-7.54039-10 3.724562-7-7.295597-8-3.00175-11-2.259892-7 2.955817-8424032151 124  
-6.14871-10-6.661167-7-2.437568-8-4.99402-10-5.911045-7-1.997552-7424032151 125  
-2.66829-10-2.527877-7 2.064155-8 8.24920-11-2.675094-7 1.312234-7424032151 126  
-7.50072-10-6.176739-7-8.340279-8 1.993924-9-6.072931-7-7.303589-8424032151 127  
-1.008183-9-1.213572-6 2.129977-7-3.275945-9-2.637346-7 5.686436-8424032151 128  
-3.195009-9-1.149675-7 4.490192-7-3.094009-9-2.172268-7 2.352750-7424032151 129  
-2.003830-9-4.228789-7-1.346958-6-1.753711-9-7.500009-8-5.130027-8424032151 130  
-3.832078-9-3.475386-7 9.391528-8-5.653286-9-4.146548-7-4.465712-7424032151 131  
-3.063176-9-9.262318-8 7.271207-3 7.098127-8 1.293575-8 1.618363-6424032151 132  
3.094124-8-9.864990-7 4.694263-6-8.403244-7 1.282389-6 3.527448-6424032151 133  
-4.182076-7 5.630538-6 1.125380-8-7.272414-8 4.790191-9 2.467704-6424032151 134  
-7.108340-8 1.131744-8 7.497023-6-3.159053-7 1.353467-8 5.853589-6424032151 135  
1.319277-7 7.218173-9 8.479646-6-1.737195-7 1.095827-8 8.398793-6424032151 136  
-1.541072-8 2.110386-8 9.145295-6 4.965901-7 1.309611-8 5.894838-6424032151 137  
-2.201049-8 1.477230-8 8.326157-6-9.924673-8 1.793900-8 5.640955-6424032151 138  
-4.442577-8 4.773688-8 8.093780-6-3.412481-7 5.146327-8 1.012500-5424032151 139  
-4.487130-7 5.951424-8 2.586182-6-8.820912-7 4.425361-8 1.094350-6424032151 140  
-3.222964-7 6.297776-8 3.741638-6-7.300059-7 6.398709-8 4.045166-6424032151 141  
2.355323-6 4.657123-8 6.624995-7-8.980561-7 6.344059-8 2.023915-6424032151 142  
1.856906-6 9.679042-8 2.726987-6 4.757887-6 3.904984-8 8.173925-7424032151 143  
5.333128-4 3.861581-8 2.937110-6-1.351509-9-6.432950-9 2.690746-8424032151 144  
-1.006023-8 3.204403-9 6.130093-9-2.955128-9 2.514671-8-6.08812-10424032151 145  
1.92536-10 9.87973-12 5.196732-9-6.30170-10 2.41027-11 1.579968-8424032151 146  
-1.164043-9 2.83971-11 1.196091-8-1.53419-10 1.60341-11 1.894028-8424032151 147  
-5.31830-10 2.47467-11 1.987795-8 4.79251-10 4.70586-11 2.236700-8424032151 148  
7.16277-10 3.23868-11 1.552086-8 2.26673-10 3.90804-11 2.445840-8424032151 149  
1.218653-6-2.848545-9-1.348539-6 3.12950-10 7.33966-11 1.743181-8424032151 150  
8.87454-10 9.88186-11 2.686227-8-2.177405-9 1.23980-10 6.431236-9424032151 151  
-1.403781-9 9.55481-11 2.760684-9-8.10702-10 1.40256-10 8.289694-9424032151 152  
-1.836327-9 1.19318-10 1.107443-8 1.084874-8 6.52753-11 1.938639-9424032151 153  
1.893822-9 1.02091-10 6.365858-9 1.936276-9 1.73536-10 7.981537-9424032151 154  
1.156850-8 8.18307-11 2.023387-9 9.367010-8-2.088751-6 5.820093-9424032151 155  
1.271312-8-3.363906-8 7.120477-8 1.197384-8 2.814831-8 3.685647-9424032151 156  
-4.530506-8 7.746526-9-1.707919-9 3.17131-11 1.382200-8-2.461590-9424032151 157  
8.12403-11 5.107693-8 1.868399-9 1.02613-10 4.124098-8 4.25764-10424032151 158  
6.21672-11 6.003738-8-3.16389-10 7.98016-11 4.822569-8-1.882866-9424032151 159  
1.88336-10 5.608752-8 1.179616-9 1.03422-10 3.676686-8-1.67025-10424032151 160  
1.38973-10 5.568377-8 9.359954-9 1.27882-10 1.614503-8-4.055706-9424032151 161  
6.56197-10 5.574123-8-8.247947-9 5.08716-10 3.960409-8 8.015716-9424032151 162  
4.58399-10 1.256348-8-6.788901-9 2.95586-10 5.142294-9 2.416004-8424032151 163  
5.10164-10 2.831847-8 2.659145-9 6.05171-10 2.002378-8-3.217618-8424032151 164  
4.96921-10 3.960358-9-2.091248-8 6.14990-10 4.859699-9 2.123049-8424032151 165  
8.65589-10 7.865670-9 2.499609-8 2.63368-10 3.711542-9 3.463341-3424032151 166  
-7.546050-7-3.786560-6 1.610635-5-6.213297-6 2.191435-6 6.114955-6424032151 167  
-2.348461-6 2.320985-5-5.536598-7 5.606139-8 8.477950-9 4.459188-6424032151 168  
-3.172453-7 2.016252-8 1.332824-5-8.568303-7 2.374692-8 1.016692-5424032151 169  
-8.715611-8 1.348394-8 1.611395-5-3.916682-7 1.996143-8 1.595777-5424032151 170  
2.553359-7 3.777333-8 1.777444-5 4.723593-7 2.569139-8 1.221624-5424032151 171  
1.404400-7 3.002884-8 1.854581-5 1.739068-5-1.055971-7-4.038319-5424032151 172

1.358814-7 6.426020-8 1.407310-5 2.836829-7 8.207395-8 2.058962-5424032151 173  
-1.536864-6 1.020811-7 5.048373-6-1.315015-6 7.792566-8 2.151784-6424032151 174  
-1.019273-6 1.115149-7 6.629131-6-1.929568-6 9.564908-8 8.115628-6424032151 175  
1.015628-5 4.494758-8 8.057823-7 1.610804-6 8.054724-8 4.144500-6424032151 176  
2.405524-6 1.414204-7 5.743300-6 9.250377-6 6.659249-8 1.572628-6424032151 177  
1.500463-4-4.419519-6 1.813549-5 2.289267-6 6.143213-8 1.557299-7424032151 178  
8.395523-7-6.686546-6 2.431920-7-8.967688-8 1.88048-10 7.970608-8424032151 179  
1.520901-7 3.47436-10 2.968425-7 1.125826-7 5.84036-10 3.599193-7424032151 180  
5.757544-8 3.69772-10 4.848444-7 3.951107-8 3.68406-10 1.020091-7424032151 181  
-1.282125-7 1.301597-9 1.733510-7-1.040260-8 4.84449-10 3.461608-8424032151 182  
-2.255011-8 6.56722-10-1.312884-7 7.943543-9 9.17855-10-2.895650-8424032151 183  
-1.150670-7 4.147033-9-5.352637-7-4.414723-7 3.095858-9-1.388976-6424032151 184  
2.804220-7 3.551861-9-1.089701-7-1.465649-7 2.227575-9-4.817457-8424032151 185  
-7.904449-8 1.757488-9 1.237659-7 4.032413-7 1.031240-8-3.052497-7424032151 186  
-3.794971-6 1.842087-8 2.215437-7-1.413439-6 1.330061-8-2.492197-7424032151 187  
6.769955-7 1.366877-8-3.821182-7-1.557234-7 2.544088-9-2.460937-8424032151 188  
7.712090-5-3.207685-4 6.650211-6-1.839128-7-5.429219-7 2.168858-6424032151 189  
-1.802095-5 6.783043-7-2.054503-7-9.99545-10-6.014931-7 3.232328-7424032151 190  
-2.503866-9-1.562527-6 4.222108-7-2.533900-9-9.133921-7 1.151543-7424032151 191  
-1.238943-9-1.593950-6 1.545802-7-2.527471-9-2.596237-6-3.235199-7424032151 192  
-3.217359-9-2.782835-6-1.340013-7-3.276619-9-2.094262-6-7.817543-8424032151 193  
3.594936-9-3.631889-6-2.425947-8-3.133691-9-1.847379-6-2.781320-7424032151 194  
4.712264-9-2.964932-6-9.718524-7 2.648689-8 7.276736-8 9.163407-7424032151 195  
-6.675645-9-1.023605-6-9.782038-8-8.156292-9-4.754976-7 4.033300-7424032151 196  
-1.318776-8-7.765615-7 1.202877-6 7.351383-9-2.037308-6-1.010138-5424032151 197  
2.855165-8 2.262732-7-3.014869-6 1.250496-8-1.411430-6 1.166535-6424032151 198  
4.381411-9-1.918596-6-1.881507-6-6.093939-9-3.375508-7 1.375370-3424032151 199  
-2.436175-5 1.185491-6 3.142557-6-8.939621-6 7.315981-5-2.468655-6424032151 200  
7.944349-7 5.046365-9 2.831408-6-1.496304-6 1.286328-8 7.962191-6424032151 201  
-1.634560-6 1.371576-8 4.985733-6-4.679416-7 7.130819-9 8.257841-6424032151 202  
-6.427090-7 1.286792-8 1.196038-5 1.273988-6 1.946844-8 1.294589-5424032151 203  
5.851898-7 1.663752-8 9.581726-6 3.109833-7 1.928562-8 1.644785-5424032151 204  
1.125704-7 1.765318-8 8.425433-6 9.865873-7 5.314309-9 1.393445-5424032151 205  
3.615594-6-1.018486-7-1.468461-6-3.369177-6 4.154019-8 4.526687-6424032151 206  
2.143363-7 4.226437-8 2.092215-6-3.524011-7 7.168492-8 4.122704-6424032151 207  
-4.856769-6-1.054685-8 8.983846-6 4.090699-5-1.028137-7-8.664957-7424032151 208  
1.181005-5-3.104773-8 5.901831-6-4.192384-6 1.069089-8 8.084133-6424032151 209  
8.450389-6 3.287985-8 1.483305-6 6.269525-2 4.895772-5 4.827650-5424032151 210  
4.103356-6-3.791125-5 2.136685-6-5.203035-7 3.45105-10-3.083078-7424032151 211  
1.842828-7 1.449627-9 7.185026-7 1.076945-6 3.189758-9 1.221741-6424032151 212  
2.626364-7 2.489521-9 8.765513-7 2.813580-7 1.134036-9-1.971587-6424032151 213  
-7.631178-7 9.067645-9-1.827148-6-1.405324-7 1.264131-9-1.791952-6424032151 214  
-1.816263-7 4.016344-9-3.455621-6 1.544648-8 4.855096-9-1.865221-6424032151 215  
-9.504743-7 6.666616-8-2.218398-6-2.489472-6 3.768324-8-9.196224-6424032151 216  
2.860741-6 1.977967-8-1.295915-6 6.902783-6-2.253546-9-9.841482-7424032151 217  
4.332182-6 1.430629-8 5.062641-7 2.629815-6 6.225017-8-2.491941-6424032151 218  
-2.080209-5 9.682978-8 7.344125-7-7.734519-6 8.046145-8-2.301523-6424032151 219  
3.555189-6 8.398023-8-3.132277-6-1.987766-6 7.648375-9-4.176196-7424032151 220  
9.333105-4-2.315576-3-3.692523-8 3.557068-7 1.143685-7-3.514308-8424032151 221  
1.735096-9 8.621153-7-5.698441-8 4.251762-9 2.779721-6-6.939029-8424032151 222  
5.177542-9 2.191786-6-3.107101-9 3.055105-9 3.423126-6-5.371200-8424032151 223  
4.318498-9 3.157064-6-1.732926-8 8.995433-9 3.606149-6 8.156396-8424032151 224  
5.668530-9 2.451040-6 1.747279-8 7.043697-9 3.737816-6 2.223537-8424032151 225  
7.960494-9 2.228797-6-7.334869-8 2.282734-8 3.181031-6-1.832251-7424032151 226  
2.171837-8 3.568825-6-3.269008-8 2.359915-8 9.447737-7-1.388332-7424032151 227  
1.766167-8 3.829829-7 2.195661-7 2.625270-8 1.522258-6 1.317226-8424032151 228  
2.672159-8 1.505845-6-9.655937-7 1.813912-8 2.875344-7-2.798711-7424032151 229  
2.169964-8 6.050586-7 9.619318-7 3.488343-8 8.446167-7 1.740570-6424032151 230  
1.427793-8 2.813744-7 1.405022-2 9.578693-8 4.990588-7 1.954131-7424032151 231  
-9.981140-8 4.842008-9 2.454070-6-7.119380-8 1.169553-8 7.721779-6424032151 232  
-2.412636-7 1.418242-8 6.101743-6 4.647401-8 8.114388-9 9.358768-6424032151 233  
-1.536303-7 1.191093-8 8.923643-6-4.974662-8 2.435244-8 1.016492-5424032151 234  
2.829695-7 1.556361-8 6.878332-6 4.986126-8 1.915671-8 1.048583-5424032151 235  
1.019413-7 2.140784-8 6.130447-6-1.876436-7 5.615976-8 8.356908-6424032151 236  
-5.018569-7 5.597629-8 9.714949-6-5.123987-7 5.151635-8 2.090820-6424032151 237  
5.403698-6 1.108172-8 6.981053-8 1.342107-6 3.414457-8 1.963533-6424032151 238

-2.954651-7 6.035298-8 3.362457-6 5.412133-7 5.949626-8 9.818749-7424032151 239  
 -1.954342-6 7.400951-8 2.101420-6 1.794410-6 1.052236-7 2.592665-6424032151 240  
 4.618583-6 3.930954-8 7.842609-7 3.841940-4-2.140766-4 3.156151-6424032151 241  
 -1.866899-7-2.16861-10-9.099042-8 4.465579-7-9.36243-10-3.816901-7424032151 242  
 2.301759-7-8.35492-10-8.044269-9 1.548849-7-5.57879-10-1.967007-7424032151 243  
 1.042463-7-8.47158-10-7.764801-7-2.780600-7-9.92198-10-7.693527-7424032151 244  
 -3.139683-8-1.100094-9-7.115489-7-5.247371-8-1.462539-9-1.518079-6424032151 245  
 2.301315-8-1.105577-9-7.701586-7-1.954175-7-4.516038-9-2.503255-6424032151 246  
 -8.946225-7-1.370534-9-3.482799-6 5.032887-7 3.94797-11-4.840732-7424032151 247  
 9.247604-7 1.003291-8 4.396137-8 2.177239-6 2.241115-8 1.637984-6424032151 248  
 1.147417-4-5.782873-8 1.032010-5-4.208040-5 3.762503-7-3.581078-6424032151 249  
 -2.756498-5 2.277172-7 3.821212-6-3.489537-6 1.559219-7 3.472274-6424032151 250  
 4.661004-6 1.979100-8 2.637586-7 2.374628-3-6.507696-5 1.425725-6424032151 251  
 4.735166-9 2.572553-6-2.977439-6 1.372542-8 7.720164-6-2.278289-6424032151 252  
 1.389254-8 3.845173-6-1.236331-6 8.617673-9 8.350752-6-9.389568-7424032151 253  
 1.351267-8 1.272993-5 2.185926-6 1.890706-8 1.354397-5 3.515789-7424032151 254  
 1.797597-8 1.080790-5 4.873100-7 2.107964-8 1.951091-5-1.784950-7424032151 255  
 2.044075-8 1.079118-5 1.705026-6 3.075889-8 2.356958-5 6.785504-6424032151 256  
 2.782573-8 3.494329-5-5.149770-6 3.052788-8 5.605333-6-9.817799-6424032151 257  
 -7.334763-8 1.649836-8-5.650699-6-1.605603-7-1.034847-5-2.072117-4424032151 258  
 -2.049840-6-8.261420-5 1.311626-3-5.817985-6-2.248280-4 3.497753-4424032151 259  
 -2.854275-6-1.511551-4 3.251380-5-1.919446-6-4.757108-5 4.685403-5424032151 260  
 -2.129307-7-3.340193-6 6.740453-6-5.493341-8 1.02340-10 1.864594-9424032151 261  
 1.654206-8 3.10087-10 1.790546-7 1.071632-7 5.23381-10 2.088506-7424032151 262  
 3.437573-8 3.39039-10 1.822408-7 2.652410-8 2.82580-10-7.976595-8424032151 263  
 -7.907836-8 1.272697-9-4.864532-8-3.212320-9 3.35632-10-9.498814-8424032151 264  
 -1.840124-8 6.81060-10-2.108076-7 8.067324-9 7.82347-10-1.164068-7424032151 265  
 -1.019506-7 7.667861-9-1.124773-7-2.623503-7 4.715462-9-8.032881-7424032151 266  
 2.925507-7 3.089278-9-9.068465-8 1.205907-7 2.963729-9-8.061234-9424032151 267  
 2.752676-7 6.134976-9 1.655680-7 2.460070-5-2.954682-8-7.405021-6424032151 268  
 -2.338933-5 1.225470-7 2.411838-6-8.474329-6 6.430549-8 2.801913-6424032151 269  
 -3.703060-7 4.333193-8 8.830320-7-7.510976-7 5.751212-9 6.527803-8424032151 270  
 1.123855-2 1.323089-7 3.276463-5-3.506809-8-3.38222-10-2.408583-7424032151 271  
 -1.887801-8-4.322680-10-2.133464-7-1.341280-8-2.54023-10-3.140361-7424032151 272  
 -5.846561-9-3.10831-10-1.989191-7 3.005791-8-7.42893-10-2.366064-7424032151 273  
 -2.114562-9-4.03377-10-1.415150-7 4.075203-9-4.98965-10-1.700479-7424032151 274  
 -2.985881-9-5.96868-10-1.099799-7 2.828778-8-1.856030-9-3.154807-8424032151 275  
 1.071175-7-1.852734-9 6.603599-8-5.525930-8-1.893704-9-2.144318-8424032151 276  
 4.973473-8-1.279325-9-7.651497-9 2.962251-8-1.466358-9-9.200652-8424032151 277  
 -7.988438-8-3.433900-9 4.708826-9 8.444170-7-4.883397-9-5.750423-8424032151 278  
 3.303952-7-3.966506-9 3.025558-8-1.950070-7-4.641672-9 4.651174-8424032151 279  
 -4.587583-8-1.236031-9-7.875547-9 2.339874-9 1.323183-6-1.17015-11424032151 280  
 1.75424-11 1.168452-8-4.35654-10 2.07059-11 9.030273-9 3.78923-11424032151 281  
 1.17986-11 1.398369-8-2.24943-10 1.65187-11 1.266371-8-5.85296-11424032151 282  
 3.29603-11 1.430749-8 3.57596-10 2.14670-11 9.698999-9 7.62135-11424032151 283  
 2.59107-11 1.463581-8 1.11602-10 2.87543-11 8.509622-9-1.88511-10424032151 284  
 6.87662-11 1.112418-8-6.51602-10 7.26906-11 1.354212-8-5.18559-10424032151 285  
 8.20637-11 3.465486-9-1.230929-9 6.02462-11 1.448894-9-5.38615-10424032151 286  
 8.48620-11 5.051614-9-6.55937-10 8.86365-11 5.240064-9 5.10208-10424032151 287  
 6.50162-11 9.08568-10-1.369246-9 8.26462-11 2.424292-9 2.995517-9424032151 288  
 1.27669-10 3.347699-9 6.306059-9 5.22727-11 1.067481-9 8.416350-3424032151 289  
 2.976195-8 8.983256-9 6.017862-6-2.506929-7 1.056806-8 4.650951-6424032151 290  
 2.127843-8 5.995168-9 7.240249-6-1.190921-7 8.478160-9 6.609565-6424032151 291  
 -2.471777-8 1.669355-8 7.461629-6 1.869799-7 1.103176-8 5.065298-6424032151 292  
 4.258453-8 1.319138-8 7.630404-6 5.807924-8 1.468037-8 4.445097-6424032151 293  
 -7.588755-8 3.254638-8 5.652814-6-3.197726-7 3.612934-8 7.115220-6424032151 294  
 -3.451453-7 4.185744-8 1.812262-6-6.359495-7 3.110301-8 7.588190-7424032151 295  
 -5.397141-7 4.280361-8 2.569159-6-3.623049-7 4.467822-8 2.720245-6424032151 296  
 2.959904-7 3.306222-8 4.868861-7-6.732983-7 4.141496-8 1.290324-6424032151 297  
 1.530709-6 6.429234-8 1.769656-6 3.284216-6 2.697287-8 5.607654-7424032151 298  
 1.223097-2-1.412891-7-7.923652-5 1.129704-8-2.12378-10 4.022810-8424032151 299  
 3.055341-8-1.51780-10 1.031502-7 1.664883-8-1.26549-10 2.634146-8424032151 300  
 -5.174038-8-4.03579-10 4.737469-8-5.911989-9-1.33138-10 5.603438-9424032151 301  
 -5.762970-9-3.65231-10-1.077169-7 2.761524-9-2.16695-10-1.722567-8424032151 302  
 -1.249585-8-4.430294-9-5.606243-7-1.721273-7-1.640725-9-4.624999-7424032151 303  
 -6.432363-9-2.26489-10-5.090521-8-5.796926-8 3.16241-10-2.164485-8424032151 304

-5.370380-7-2.182991-9-7.974188-8 1.502878-7 1.730243-9-1.945311-7424032151 305  
 -1.754095-6 6.838292-9 1.172128-7-5.862455-7 2.786596-9-9.183428-8424032151 306  
 2.695632-7 1.747744-9-1.573624-7-9.990452-8 5.25129-10-7.796376-9424032151 307  
 9.825258-9 6.559609-6-9.64580-10 4.80748-11 2.078726-8 6.21981-11424032151 308  
 2.75370-11 3.218566-8-5.32676-10 3.88807-11 2.952595-8-1.02485-10424032151 309  
 7.82462-11 3.343101-8 8.44566-10 5.06316-11 2.269005-8 1.80698-10424032151 310  
 6.15816-11 3.441206-8 2.63229-10 6.85456-11 2.008432-8-4.70973-10424032151 311  
 1.71655-10 2.701346-8-1.430629-9 1.76413-10 3.237910-8-1.102783-9424032151 312  
 1.96787-10 8.273343-9-2.887614-9 1.43836-10 3.466527-9-4.15726-10424032151 313  
 2.06459-10 1.221398-8-1.663813-9 2.12340-10 1.267844-8 2.697164-9424032151 314  
 1.50527-10 2.040750-9-2.824525-9 1.97480-10 5.816460-9 6.975780-9424032151 315  
 3.06828-10 8.083640-9 1.515618-8 1.24801-10 2.548475-9 2.224944-2424032151 316  
 -6.551406-7 3.184190-8 1.386481-5 5.822605-8 1.820451-8 2.151437-5424032151 317  
 -3.485035-7 2.580506-8 1.973568-5-9.083373-8 5.169858-8 2.235008-5424032151 318  
 5.613008-7 3.362904-8 1.516055-5 1.197051-7 4.071085-8 2.292349-5424032151 319  
 1.770803-7 4.543806-8 1.340745-5-3.050929-7 1.100176-7 1.764618-5424032151 320  
 -1.029212-6 1.157017-7 2.142053-5-7.922237-7 1.306145-7 5.501418-6424032151 321  
 -1.953484-6 9.597310-8 2.305636-6-7.345226-7 1.357045-7 8.067968-6424032151 322  
 -1.048845-6 1.415605-7 8.356197-6 9.282820-7 1.033867-7 1.430959-6424032151 323  
 -2.156018-6 1.320781-7 3.854183-6 4.773252-6 2.041316-7 5.333077-6424032151 324  
 1.006478-5 8.338873-8 1.700336-6 1.298377-2 3.734279-7 1.233448-4424032151 325  
 7.493981-8-7.92553-10-1.162832-6 2.883534-8-9.43846-10-8.756465-7424032151 326  
 -3.786635-8-1.522886-9-9.697373-7-2.948759-8-1.241769-9-6.877893-7424032151 327  
 -1.451595-8-1.368768-9-1.080558-6-6.066063-9-1.507893-9-6.236630-7424032151 328  
 -3.964023-8-6.77898-10-8.084915-7-9.495290-8-2.468868-9-1.333857-6424032151 329  
 1.850176-7-4.042506-9-2.856992-7 4.140535-8-3.460882-9-1.222618-7424032151 330  
 2.526840-7-4.354170-9-2.730878-7 1.751052-7-2.158840-9-4.611299-7424032151 331  
 -1.117188-6 1.060628-9-2.335875-8-3.264347-7-8.38576-10-2.794591-7424032151 332  
 7.471258-9-3.425424-9-3.788049-7-4.990059-7-2.835729-9-8.894126-8424032151 333  
 1.840556-8 8.758256-6 4.59945-10 3.14416-11 3.609208-8-6.15689-10424032151 334  
 4.66148-11 3.520008-8-1.77666-10 9.43745-11 3.992146-8 1.003538-9424032151 335  
 6.07606-11 2.706334-8 2.04510-10 7.41193-11 4.101573-8 3.18410-10424032151 336  
 8.27354-11 2.401073-8-6.33880-10 2.11097-10 3.232610-8-1.902269-9424032151 337  
 2.14981-10 3.831587-8-1.126934-9 2.38583-10 9.879405-9-3.527687-9424032151 338  
 1.73943-10 4.140428-9-2.25333-10 2.50305-10 1.479126-8-1.826809-9424032151 339  
 2.60723-10 1.512253-8 1.790370-9 1.88587-10 2.511687-9-3.962287-9424032151 340  
 2.44115-10 6.853690-9 8.681526-9 3.76391-10 9.534202-9 1.816250-8424032151 341  
 1.51246-10 3.047612-9 2.285688-2 2.571546-7 1.338721-8 1.553152-5424032151 342  
 -2.577827-7 2.020562-8 1.542077-5-1.135415-7 4.065104-8 1.749758-5424032151 343  
 4.346781-7 2.636858-8 1.184590-5 8.683824-8 3.193097-8 1.785486-5424032151 344  
 1.412414-7 3.581039-8 1.049095-5-2.723165-7 8.678527-8 1.361070-5424032151 345  
 -9.504764-7 9.159929-8 1.643340-5-5.456676-7 1.035304-7 4.283479-6424032151 346  
 -1.582667-6 7.608094-8 1.795562-6-6.753133-7 1.068229-7 6.363331-6424032151 347  
 -6.951515-7 1.143215-7 6.454826-6-5.490828-7 8.717027-8 1.197707-6424032151 348  
 -2.156752-6 1.077837-7 2.943781-6 3.980639-6 1.644189-7 4.063223-6424032151 349  
 7.859922-6 6.633468-8 1.328924-6 2.662255-3-1.125905-7-1.572977-4424032151 350  
 5.268840-9 7.12036-11 4.771027-8-1.894755-8 1.87912-10 6.213799-8424032151 351  
 -8.33909-10 9.70233-11 3.081813-8-2.748217-9 1.04529-10 1.549255-8424032151 352  
 1.322369-9 1.59565-10 2.011648-8-1.393289-8 2.14562-10-7.764583-8424032151 353  
 -6.490780-8 4.63537-10-1.234482-7 2.736735-8 6.01722-10-6.250821-9424032151 354  
 -2.370528-8 4.52001-10-2.871182-9-6.254964-8 2.37575-10 2.120607-8424032151 355  
 7.752379-8 1.734249-9-2.679665-8-7.133335-7 3.404519-9 6.131681-8424032151 356  
 -2.460247-7 2.196254-9-1.243851-8 1.036483-7 2.169003-9-4.100994-8424032151 357  
 -1.223009-8 4.94493-10 1.43505-10 3.902939-9 4.471174-6-3.46988-10424032151 358  
 2.67850-11 2.009584-8-1.14714-10 5.45241-11 2.281058-8 5.72284-10424032151 359  
 3.49167-11 1.545354-8 1.12738-10 4.27444-11 2.343198-8 1.82749-10424032151 360  
 4.77297-11 1.372664-8-3.93594-10 1.24709-10 1.863713-8-1.134035-9424032151 361  
 1.25271-10 2.182236-8-5.47713-10 1.37885-10 5.647509-9-2.040471-9424032151 362  
 1.00088-10 2.365209-9 1.48340-10 1.45012-10 8.547407-9-1.102683-9424032151 363  
 1.50681-10 8.616920-9 1.411000-9 1.07196-10 1.325808-9-2.226390-9424032151 364  
 1.41098-10 3.806601-9 5.067746-9 2.18044-10 5.388642-9 1.042649-8424032151 365  
 8.70268-11 1.738514-9 1.330089-2-4.115761-7 3.145041-8 2.419670-5424032151 366  
 -1.537116-7 6.288499-8 2.745062-5 6.849886-7 4.108811-8 1.860762-5424032151 367  
 1.438335-7 4.956704-8 2.805574-5 2.212213-7 5.569805-8 1.651010-5424032151 368  
 -3.790894-7 1.307553-7 2.123528-5-1.411650-6 1.408625-7 2.607651-5424032151 369  
 -1.010031-6 1.610681-7 6.764272-6-2.470929-6 1.190046-7 2.837656-6424032151 370

-1.467301-6 1.656158-7 9.896637-6-1.292660-6 1.752355-7 1.013052-5424032151 371  
 3.742679-7 1.305157-7 1.751195-6-2.971794-6 1.639565-7 4.617391-6424032151 372  
 6.162954-6 2.527048-7 6.452178-6 1.241813-5 1.036168-7 2.100334-6424032151 373  
 9.709008-3 2.472515-7 1.102541-4-1.304937-8-9.81886-10-4.829527-7424032151 374  
 -1.408425-8-6.86456-10-3.355390-7-5.520973-9-8.17888-10-5.294393-7424032151 375  
 -3.236820-9-8.96646-10-3.052629-7-7.851546-9-1.795174-9-4.503825-7424032151 376  
 -2.894209-8-2.050123-9-6.158874-7 5.480447-8-2.488816-9-1.378832-7424032151 377  
 2.659067-8-1.912995-9-5.860011-8 2.115643-8-2.818072-9-1.664036-7424032151 378  
 6.974090-8-1.963559-9-2.281968-7-4.561474-7-2.49673-10-1.120032-8424032151 379  
 -1.132407-7-1.427769-9-1.225881-7-2.587309-8-2.982522-9-1.702159-7424032151 380  
 -2.479781-7-1.598515-9-4.220577-8 8.524498-9 6.421572-6-1.05902-10424032151 381  
 7.78800-11 3.346789-8 8.50367-10 5.05965-11 2.274633-8 1.85323-10424032151 382  
 6.15564-11 3.454734-8 2.68134-10 6.92060-11 2.036429-8-4.63196-10424032151 383  
 1.71044-10 2.723298-8-1.474447-9 1.78025-10 3.293982-8-1.183056-9424032151 384  
 2.00709-10 8.465432-9-2.962905-9 1.47626-10 3.560772-9-7.38302-10424032151 385  
 2.10622-10 1.248687-8-1.687871-9 2.17587-10 1.299760-8 2.397309-9424032151 386  
 1.55866-10 2.145895-9-3.002911-9 2.02595-10 5.999208-9 7.209787-9424032151 387  
 3.14460-10 8.314717-9 1.559597-8 1.28410-10 2.626780-9 2.155455-2424032151 388  
 -2.178810-8 5.816894-8 2.608150-5 6.692328-7 3.862034-8 1.778286-5424032151 389  
 1.636485-7 4.640150-8 2.699518-5 2.069404-7 5.231410-8 1.593356-5424032151 390  
 -2.279496-7 1.170522-7 2.070128-5-9.444746-7 1.296713-7 2.623591-5424032151 391  
 -1.341080-6 1.513312-7 6.656821-6-2.245675-6 1.131583-7 2.806225-6424032151 392  
 -1.749366-6 1.571985-7 9.410562-6-1.512264-6 1.599882-7 1.016782-5424032151 393  
 2.986832-6 1.130627-7 1.682591-6-1.794785-6 1.469384-7 4.872863-6424032151 394  
 5.299680-6 2.313229-7 6.701519-6 1.218901-5 9.821587-8 2.075248-6424032151 395  
 2.219599-3-4.114106-7-1.362354-4 9.541733-6-2.418147-8-2.480197-5424032151 396  
 7.673659-9-1.92562-10 5.734514-8-2.154425-9-2.86952-10 1.415309-8424032151 397  
 3.794744-8-1.351263-9 1.805311-7 1.443865-7-1.256979-9 3.744432-7424032151 398  
 -9.262580-8-1.134132-9 3.862182-8 4.832178-8-6.74479-10 1.787751-8424032151 399  
 3.005384-8-4.6338108-10-3.454329-8-1.303292-7-3.282898-9 1.120593-7424032151 400  
 1.248570-6-5.872444-9-6.563966-8 4.578542-7-4.188402-9 9.365496-8424032151 401  
 -2.272796-7-4.289722-9 1.357088-7 5.821200-8-7.74996-10 9.805213-9424032151 402  
 2.892809-8 1.163700-5 1.701305-7-2.06147-10-2.227428-7 3.18493-10424032151 403  
 1.25104-10 6.808135-8 5.36074-10 1.40610-10 4.016360-8-1.238677-9424032151 404  
 3.72409-10 5.462170-8-3.558170-9 3.72217-10 6.349965-8-1.373663-9424032151 405  
 4.09372-10 1.658959-8-6.073656-9 2.97341-10 6.965601-9 7.65634-10424032151 406  
 4.31643-10 2.542528-8-2.750692-9 4.55271-10 2.549513-8 5.19352-10424032151 407  
 3.34938-10 4.338108-9-7.768488-9 4.29736-10 1.134646-8 1.529115-8424032151 408  
 6.57073-10 1.582114-8 3.075058-8 2.59413-10 5.135331-9 1.271696-2424032151 409  
 1.229719-4-1.695303-7-1.464320-4 1.830835-7 5.278078-8 3.060169-5424032151 410  
 2.349956-7 5.958476-8 1.808739-5-2.789961-7 1.340860-7 2.345852-5424032151 411  
 -1.138384-6 1.481528-7 2.963373-5-1.470729-6 1.726386-7 7.547944-6424032151 412  
 -2.574210-6 1.289920-7 3.182038-6-1.956557-6 1.791710-7 1.072500-5424032151 413  
 -1.662853-6 1.835637-7 1.151348-5 2.869016-6 1.311632-7 1.936387-6424032151 414  
 -2.240704-6 1.691416-7 5.493755-6 6.130444-6 2.652562-7 7.556743-6424032151 415  
 1.383742-5 1.120638-7 2.354791-6 1.697400-2-9.608296-8 1.466866-4424032151 416  
 -2.976129-9 1.255396-9 7.299000-7 5.709224-9 1.507047-9 4.693956-7424032151 417  
 -2.563808-9 3.331933-9 6.316977-7-1.089549-8 3.682604-9 8.128266-7424032151 418  
 -4.910940-8 4.334302-9 2.003872-7-5.905487-8 3.271323-9 8.503669-8424032151 419  
 -4.234514-8 4.629895-9 2.760332-7-3.478482-8 4.597968-9 3.249554-7424032151 420  
 8.054439-8 3.346630-9 6.936228-8-4.009519-8 4.204053-9 1.741595-7424032151 421  
 1.245136-7 6.578315-9 2.205402-7 3.616896-7 2.836340-9 6.288445-8424032151 422  
 1.617238-8 8.131057-6 2.77371-10 8.02686-11 4.509100-8 3.50084-10424032151 423  
 9.07070-11 2.674624-8-5.98217-10 2.22605-10 3.564332-8-1.942060-9424032151 424  
 2.32864-10 4.326285-8-1.591917-9 2.63342-10 1.112571-8-3.898877-9424032151 425  
 1.93988-10 4.681860-9-1.148853-9 2.76024-10 1.637912-8-2.254490-9424032151 426  
 2.85190-10 1.705437-8 3.241357-9 2.04167-10 2.798865-9-3.920430-9424032151 427  
 2.65377-10 7.866820-9 9.499501-9 4.12293-10 1.092420-8 2.051263-8424032151 428  
 1.68770-10 3.455723-9 2.387562-2 1.534054-7 3.562320-8 2.072275-5424032151 429  
 1.586365-7 4.043517-8 1.235250-5-1.635176-7 9.017678-8 1.609834-5424032151 430  
 -6.841270-7 1.000690-7 2.046435-5-1.072077-6 1.169850-7 5.176216-6424032151 431  
 -1.726905-6 8.757193-8 2.183325-6-1.354758-6 1.217770-7 7.288478-6424032151 432  
 -1.235852-6 1.228678-7 7.918977-6 2.843150-6 8.529010-8 1.264259-6424032151 433  
 -1.211401-6 1.123785-7 3.798738-6 4.042286-6 1.779114-7 5.241181-6424032151 434  
 9.484364-6 7.595269-8 1.613662-6 4.641891-3-1.526368-7-5.701654-5424032151 435  
 1.022625-9 3.10455-10 1.198351-7 6.504450-9 3.70392-10 1.705594-7424032151 436



1.912266-8 5.99059-10 2.597985-7-3.130998-8 8.44864-10 5.575563-8424032151 437  
-7.887302-9 6.91624-10 2.387347-8-2.783120-8 9.61448-10 5.811901-8424032151 438  
-3.614629-8 4.86051-10 9.211989-8 2.442932-7-2.67651-10 7.56421-10424032151 439  
6.980751-8 2.20895-10 5.263700-8-1.724535-9 7.83411-10 7.371355-8424032151 440  
9.940779-8 5.66790-10 1.719894-8 1.861135-8 1.002630-5 4.18036-10424032151 441  
1.10887-10 3.217423-8-8.34162-10 2.85809-10 4.376630-8-2.416141-9424032151 442  
2.89847-10 5.189256-8-1.530108-9 3.22125-10 1.338474-8-4.716627-9424032151 443  
2.35364-10 5.628909-9 3.48194-11 3.40497-10 2.008961-8-2.591792-9424032151 444  
3.51847-10 2.066739-8 3.739493-9 2.50622-10 3.337578-9-4.919231-9424032151 445  
3.28712-10 9.395570-9 1.156173-8 5.08845-10 1.307948-8 2.475333-8424032151 446  
2.04861-10 4.146189-9 1.681463-2 2.361238-7 6.141415-8 1.882179-5424032151 447  
-2.108609-7 1.383844-7 2.493604-5-8.325612-7 1.520973-7 3.169388-5424032151 448  
-1.705154-6 1.772793-7 7.938727-6-2.557694-6 1.326467-7 3.351067-6424032151 449  
-1.759473-6 1.862165-7 1.111356-5-2.041909-6 1.837665-7 1.226570-5424032151 450  
6.105637-6 1.222353-7 1.839879-6-1.206020-6 1.666033-7 5.931200-6424032151 451  
5.823804-6 2.667470-7 8.183540-6 1.454055-5 1.147953-7 2.470444-6424032151 452  
1.607627-2 6.586785-7-3.572962-5-3.449774-9 1.062372-9 1.703501-7424032151 453  
-1.495433-8 2.117520-9 2.188900-7-8.198255-9 1.442598-9 5.953228-8424032151 454  
-2.191493-8 1.085987-9 2.536866-8-1.734174-8 1.493469-9 8.977234-8424032151 455  
9.214400-9 1.801617-9 9.735682-8-1.380278-7 1.801935-9 3.807748-8424032151 456  
-6.601941-8 1.788230-9 5.483531-8 5.581484-8 2.496178-9 6.108844-8424032151 457  
1.071949-7 9.65432-10 1.923962-8 3.812443-8 1.175044-5-9.65655-10424032151 458  
3.18409-10 4.888064-8-2.971124-9 3.26594-10 5.820782-8-1.733357-9424032151 459  
3.65042-10 1.510744-8-5.429148-9 2.67514-10 6.357378-9-6.59049-10424032151 460  
3.83547-10 2.269377-8-2.795892-9 4.01406-10 2.318040-8 2.165317-9424032151 461  
2.92478-10 3.895178-9-6.298710-9 3.76413-10 1.050285-8 1.350239-8424032151 462  
5.79786-10 1.462067-8 2.798263-8 2.33263-10 4.695259-9 2.466407-2424032151 463  
-1.355134-7 8.132917-8 1.463511-5-5.619941-7 9.011720-8 1.863294-5424032151 464  
-9.959129-7 1.053771-7 4.692494-6-1.542634-6 7.897876-8 1.981568-6424032151 465  
-1.181786-6 1.101403-7 6.586794-6-1.184889-6 1.099381-7 7.207207-6424032151 466  
3.148160-6 7.457785-8 1.102228-6-8.962036-7 1.000582-7 3.461673-6424032151 467  
3.575085-6 1.594682-7 4.791005-6 8.613006-6 6.846006-8 1.463706-6424032151 468  
1.214160-3-6.955551-7-1.362909-4 1.361312-7-3.594464-9 7.963940-8424032151 469  
-1.168589-7-3.060713-8 3.022494-8 6.329429-8-1.861312-9-1.082332-8424032151 470  
-1.613916-7-3.013807-9-1.686577-7-1.069205-7-5.336709-9-2.380031-8424032151 471  
9.916411-7-6.433142-9-6.262372-8 4.114141-7-6.039667-9 4.140205-8424032151 472  
-2.503259-7-7.379507-9 5.708762-8-7.548933-8-1.778677-9-9.461619-9424032151 473  
1.985831-7 1.990148-5-9.034747-9 9.38096-10 1.248002-7 4.574025-9424032151 474  
9.32388-10 3.356390-8-1.300597-8 6.41841-10 1.400966-8 2.747906-8424032151 475  
1.031714-9 5.873991-8-3.814900-9 1.087377-9 5.380370-8-7.18110-10424032151 476  
7.67236-10 7.563600-9-1.957549-8 1.047884-9 2.083315-8 3.437022-8424032151 477  
1.575608-9 3.030133-8 6.378600-8 5.61588-10 1.016787-8 9.825070-3424032151 478  
-1.796633-7 1.263316-7 2.578436-5-1.155250-6 1.404805-7 6.310804-6424032151 479  
-1.838474-6 1.030784-7 2.665197-6 6.774372-7 1.542066-7 9.016625-6424032151 480  
-1.996422-6 1.413735-7 1.013325-5 9.735322-6 7.728611-8 1.063057-6424032151 481  
6.590585-7 1.252295-7 4.820322-6 3.845074-6 2.075341-7 6.772715-6424032151 482  
1.163424-5 8.858617-8 1.939577-6 2.974162-3-1.156691-6-1.112448-3424032151 483  
-2.606297-7-9.652229-9-1.275240-7 2.478655-7-6.634631-9-4.871464-8424032151 484  
1.555908-7-7.700092-9-4.818311-7-3.751762-7-1.719204-8-2.032306-8424032151 485  
4.040668-6-2.395750-8-2.823317-7 1.595448-6-1.970952-8 1.253737-7424032151 486  
-9.641131-7-2.334571-8 1.941702-7-2.785353-7-6.396923-9-4.745530-8424032151 487  
1.708836-7 2.459589-5-5.94743-10 9.57731-10 3.721961-8-1.411130-8424032151 488  
6.85476-10 1.560763-8 8.845895-9 1.020708-9 5.959048-8-4.968647-9424032151 489  
1.092075-9 5.774460-8-6.759335-9 8.13973-10 9.981205-9-2.105567-8424032151 490  
1.041618-9 2.468644-8 3.657914-8 1.573651-9 3.461421-8 6.958062-8424032151 491  
5.99827-10 1.148777-8 1.397197-2-2.395463-6 1.665680-7 8.131993-6424032151 492  
-2.169797-6 1.261517-7 3.446510-6-1.632458-6 1.801782-7 1.071432-5424032151 493  
-2.964670-6 1.575576-7 1.296938-5 1.492699-5 7.842910-8 1.381408-6424032151 494  
2.131621-6 1.337435-7 6.581511-6 4.093494-6 2.317541-7 9.102655-6424032151 495  
1.481381-5 1.078489-7 2.518662-6 1.045268-1 5.259534-7 3.054731-4424032151 496  
3.063248-8-4.669279-9-2.088972-7 7.618074-7-4.547529-9-3.197983-7424032151 497  
3.910748-7 7.74409-10-7.693067-7-2.605152-6 6.563095-9-2.924835-9424032151 498  
-8.558291-7 3.612741-9-5.227765-7 1.789089-7 3.46952-10-7.087686-7424032151 499  
-8.252163-7-3.665619-9-1.528074-7 3.940760-7 1.693578-5-1.609301-8424032151 500  
7.85329-10 1.842721-8-2.177156-9 1.122618-9 6.648697-8-6.418870-9424032151 501  
1.207193-9 6.758178-8-1.031086-8 9.29038-10 1.325554-8-2.360330-8424032151 502

1.143950-9	3.097261-8	4.073433-8	1.732318-9	4.206241-8	8.101094-8424032151	503
6.87345-10	1.366177-8	2.741789-2	6.118518-7	3.292600-8	8.514719-7424032151	504
-4.394391-7	4.644380-8	2.769832-6	5.594006-7	4.477013-8	3.169393-6424032151	505
1.931917-6	2.870126-8	4.789237-7	1.232747-7	4.007075-8	1.577739-6424032151	506
1.328622-6	6.494070-8	2.143776-6	3.677291-6	2.845177-8	6.273398-7424032151	507
3.276272-1	6.651699-6	1.262891-4	1.775552-3	5.014765-6	1.992224-3424032151	508
1.755409-6	2.877515-8	4.541715-6	4.625820-6	7.200296-9	8.918274-7424032151	509
-8.818748-7	5.811698-9	3.820189-7	9.634685-7	1.845135-8	2.341531-7424032151	510
-1.327211-6	9.373021-9	1.692751-7	2.442319-7	7.275938-6	1.052239-6424032151	511
-4.882037-9	2.262301-6	3.536157-9	8.93878-10	4.879614-8	6.272989-8424032151	512
9.30464-10	2.074189-8	3.118581-8	9.50018-10	3.121392-8	2.767409-8424032151	513
1.340738-9	3.489217-8	5.901767-8	5.20045-10	1.056086-8	2.794020-2424032151	514
2.899479-4	1.185459-6	1.252511-4	2.267957-7	1.892287-8	1.302446-6424032151	515
-5.665346-7	3.802791-8	4.569646-7	3.901981-7	1.975325-8	8.461822-7424032151	516
5.100469-7	2.930531-8	9.758956-7	1.516875-6	1.226240-8	2.714344-7424032151	517
5.161780-2	3.633592-7	2.351355-4	3.394441-5	9.027393-8	8.180850-6424032151	518
-2.815742-6	1.168146-8	4.651628-7	7.998689-7	8.628719-9	1.843626-7424032151	519
-6.251123-7	7.176262-9	2.314554-7	7.554400-7	4.408677-9	1.516481-7424032151	520
4.021706-7	2.245461-5	8.946241-8	9.86570-10	2.305984-8	1.233754-7424032151	521
1.456048-9	3.644614-8	4.908057-8	1.432066-9	5.013697-8	3.496932-8424032151	522
1.978165-9	5.218561-8	8.254232-8	7.36544-10	1.493507-8	2.681767-2424032151	523
5.722484-6	3.807451-8	1.280198-9	8.086259-6	8.939500-8	2.276284-6424032151	524
-3.172865-6	8.550529-8	3.032876-6	2.130210-6	1.169743-7	3.109061-6424032151	525
4.917872-6	4.397594-8	8.946861-7	3.939232-2	3.583029-6	1.205787-4424032151	526
5.955720-5	1.889739-7	4.117919-6	1.850968-5	1.338692-7	2.091887-6424032151	527
-2.153874-6	5.735498-8	1.589202-6	2.911887-6	7.759770-9	8.936556-8424032151	528
4.609888-7	2.399029-5	1.024439-6	6.129772-9	1.845197-7	3.288366-7424032151	529
3.889873-9	1.588320-7	2.520617-8	3.843387-9	9.288609-8	4.633951-8424032151	530
1.005422-9	1.909215-8	2.645434-2	2.032611-5	2.498124-7	1.002136-5424032151	531
-1.229030-5	1.861940-7	9.331979-6	1.304134-7	1.954715-7	6.209830-6424032151	532
3.751259-6	5.647842-8	1.258165-6	1.678432-1	1.089514-5	1.497089-4424032151	533
8.388072-3	1.828023-5	4.085996-3	1.412060-3	4.251353-6	7.036924-4424032151	534
1.904137-4	1.948601-7	5.966519-6	4.143580-7	1.528637-5	5.170559-6424032151	535
-1.271197-8	6.604701-6	6.095431-7	3.071778-9	1.322950-6	1.752539-7424032151	536
9.90972-10	1.074940-8	2.781277-2	9.803089-4	3.666220-6	2.523862-4424032151	537
2.264917-4	1.108890-6	6.247192-5	5.096647-6	2.826160-8	3.492196-7424032151	538
4.050094-2	7.998716-6	1.027548-3	1.089154-2	3.285221-5	2.895753-3424032151	539
-4.798139-4	1.089174-7	1.208534-5	5.676892-7	2.927120-5	2.524150-5424032151	540
-9.173548-8	1.386727-5	9.881616-7	1.51237-10	6.118066-9	2.706315-2424032151	541
3.018851-3	1.987040-5	5.730359-4	5.031770-5	9.425563-9	7.018096-6424032151	542
4.226637-2	8.123486-7	1.128071-3	1.264972-4	1.009937-7	6.307022-5424032151	543
1.154810-6	3.100450-5	2.092782-6	9.92213-10	4.190322-7	2.700619-2424032151	544
7.426409-4	5.196762-7	3.069708-5	5.601968-1	2.198337-5	5.956550-5424032151	545
2.378839-7	6.052932-6	2.802481-2			424032151	546
0.0	0.0	0	0	0	0424032	0 547
0.0	0.0	0	0	0	04240	0 0 548
4.209700+4	9.607350+1	0	0	0	1424033	1 1
0.000000+0	0.000000+0	0	1	0	1424033	1 2
0.000000+0	0.000000+0	1	5	1035	45424033	1 3
1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000-2424033	1 4
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000-1424033	1 5
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000-1424033	1 6
4.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000+0424033	1 7
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000+2424033	1 8
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000+5424033	1 9
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000+6424033	1 10
6.434000+6	8.187300+6	2.000000+7	3.878142-4	0.000000+0	0.000000+0424033	1 11
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	1 12
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	1 13
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	1 14
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	1 15
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	1 16
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	1 17
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	4.128211-4424033	1 18
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	1 19
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	1 20

[illegible]

[illegible]

0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	1	153
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	1	154
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	1	155
0.000000+0	0.000000+0	0.000000+0	1.753264-3	0.000000+0	0.000000+0424033	1	156
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	1	157
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	1	158
2.087119-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	1	159
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	1	160
0.000000+0	0.000000+0	1.519129-3	2.533440-3	2.182656-3	2.026752-3424033	1	161
1.972186-3	1.909824-3	1.894234-3	1.847774-3	1.855258-3	1.824077-3424033	1	162
1.753920-3	1.754076-3	1.777306-3	4.225000-3	3.640000-3	3.380000-3424033	1	163
3.289000-3	3.185000-3	3.159000-3	3.081520-3	3.094000-3	3.042000-3424033	1	164
2.925000-3	2.925260-3	2.964000-3	3.136000-3	2.912000-3	2.833600-3424033	1	165
2.744000-3	2.721600-3	2.654848-3	2.665600-3	2.620800-3	2.520000-3424033	1	166
2.520224-3	2.553600-3	2.704000-3	2.631200-3	2.548000-3	2.527200-3424033	1	167
2.465216-3	2.475200-3	2.433600-3	2.340000-3	2.340208-3	2.371200-3424033	1	168
2.560360-3	2.479400-3	2.459160-3	2.398845-3	2.408560-3	2.368080-3424033	1	169
2.277000-3	2.277202-3	2.307360-3	2.401000-3	2.381400-3	2.322992-3424033	1	170
2.332400-3	2.293200-3	2.205000-3	2.205196-3	2.234400-3	2.361960-3424033	1	171
2.304029-3	2.313360-3	2.274480-3	2.187000-3	2.187194-3	2.216160-3424033	1	172
2.247518-3	2.256621-3	2.218694-3	2.133360-3	2.133550-3	2.161805-3424033	1	173
2.265760-3	2.227680-3	2.142000-3	2.142190-3	2.170560-3	2.190240-3424033	1	174
2.106000-3	2.106187-3	2.134080-3	2.025000-3	2.025180-3	2.052000-3424033	1	175
2.025360-3	2.052182-3	2.079360-3	0.000000+0	0.000000+0	0.000000+0424033	1	176
0.000000+0	0.000000+0	0	0	0	0424033	099999	
4.209700+4	9.607350+1	0	0	0	1424033	2	1
0.000000+0	0.000000+0	0	2	0	1424033	2	2
0.000000+0	0.000000+0	1	5	1035	45424033	2	3
1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000-2424033	2	4
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000-1424033	2	5
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000-1424033	2	6
4.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000+0424033	2	7
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000+2424033	2	8
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000+5424033	2	9
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000+6424033	2	10
6.434000+6	8.187300+6	2.000000+7	8.310536-4	0.000000+0	0.000000+0424033	2	11
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	12
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	13
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	14
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	15
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	16
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	17
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	8.280006-4424033	2	18
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	19
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	20
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	21
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	22
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	23
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	24
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	25
8.277129-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	26
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	27
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	28
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	29
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	30
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	31
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	32
8.275978-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	33
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	34
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	35
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	36
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	37
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	38
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	8.274828-4424033	2	39
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	40
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	41

[illegible]

0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	2.607941-3424033	2	108
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	109
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	110
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	111
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	112
0.000000+0	0.000000+0	0.000000+0	2.607634-3	0.000000+0	0.000000+0424033	2	113
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	114
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	115
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	116
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	117
2.605694-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	118
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	119
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	120
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	121
0.000000+0	0.000000+0	2.600388-3	0.000000+0	0.000000+0	0.000000+0424033	2	122
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	123
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	124
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	125
0.000000+0	0.000000+0	0.000000+0	2.689667-3	0.000000+0	0.000000+0424033	2	126
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	127
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	128
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	129
0.000000+0	0.000000+0	0.000000+0	2.658330-3	0.000000+0	0.000000+0424033	2	130
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	131
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	132
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	133
0.000000+0	0.000000+0	2.596820-3	0.000000+0	0.000000+0	0.000000+0424033	2	134
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	135
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	136
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	137
2.521948-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	138
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	139
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	140
0.000000+0	0.000000+0	0.000000+0	2.525867-3	0.000000+0	0.000000+0424033	2	141
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	142
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	143
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	2.400510-3424033	2	144
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	145
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	146
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	147
2.044758-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	148
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	149
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	150
7.050618-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	151
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	152
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	153
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	154
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	155
0.000000+0	0.000000+0	0.000000+0	5.167438-4	0.000000+0	0.000000+0424033	2	156
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	157
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	158
2.038252-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	159
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033	2	160
0.000000+0	0.000000+0	1.648035-3	1.948608-3	1.924250-3	2.110992-3424033	2	161
3.304514-3	4.522394-3	5.155692-3	5.456102-3	5.610367-3	5.220646-3424033	2	162
5.220646-3	4.716037-3	4.717255-3	2.304000-3	2.275200-3	2.496000-3424033	2	163
3.907200-3	5.347200-3	6.096000-3	6.451200-3	6.633600-3	6.172800-3424033	2	164
6.172800-3	5.576160-3	5.577600-3	2.246760-3	2.464800-3	3.858360-3424033	2	165
5.280360-3	6.019800-3	6.370560-3	6.550680-3	6.095640-3	6.095640-3424033	2	166
5.506458-3	5.507880-3	2.704000-3	4.232800-3	5.792800-3	6.604000-3424033	2	167
6.988800-3	7.186400-3	6.687200-3	6.687200-3	6.040840-3	6.042400-3424033	2	168
6.625960-3	9.067960-3	1.033780-2	1.094016-2	1.124948-2	1.046804-2424033	2	169
1.046804-2	9.456238-3	9.458680-3	1.240996-2	1.414780-2	1.497216-2424033	2	170
1.539548-2	1.432604-2	1.432604-2	1.294134-2	1.294468-2	1.612900-2424033	2	171
1.706880-2	1.755140-2	1.633220-2	1.633220-2	1.475359-2	1.475740-2424033	2	172
1.806336-2	1.857408-2	1.728384-2	1.728384-2	1.561325-2	1.561728-2424033	2	173





[illegible]

0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	129
0.000000+0	0.000000+0	0.000000+0	1.102374-2	0.000000+0	0.000000+0424033102	130
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	131
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	132
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	133
0.000000+0	0.000000+0	1.684908-2	0.000000+0	0.000000+0	0.000000+0424033102	134
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	135
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	136
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	137
2.314749-2	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	138
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	139
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	140
0.000000+0	0.000000+0	0.000000+0	2.997504-2	0.000000+0	0.000000+0424033102	141
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	142
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	143
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	3.783647-2424033102	144
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	145
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	146
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	147
3.837132-2	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	148
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	149
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	150
4.061434-2	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	151
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	152
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	3.516375-2424033102	153
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	154
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	155
0.000000+0	0.000000+0	0.000000+0	4.350979-2	0.000000+0	0.000000+0424033102	156
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	157
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	158
4.351396-2	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	159
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424033102	160
0.000000+0	0.000000+0	1.303707-2	2.002717-2	2.007284-2	2.112330-2424033102	161
2.406914-2	3.091994-2	3.500759-2	3.857914-2	4.311437-2	4.959979-2424033102	162
6.058391-2	6.340073-2	6.384946-2	3.076516-2	3.083532-2	3.244900-2424033102	163
3.697432-2	4.749832-2	5.377764-2	5.926415-2	6.623104-2	7.619376-2424033102	164
9.306724-2	9.739436-2	9.808368-2	3.090564-2	3.252300-2	3.705864-2424033102	165
4.760664-2	5.390028-2	5.939930-2	6.638208-2	7.636752-2	9.327948-2424033102	166
9.761647-2	9.830736-2	3.422500-2	3.899800-2	5.009800-2	5.672100-2424033102	167
6.250780-2	6.985600-2	8.036400-2	9.816100-2	1.027250-1	1.034520-1424033102	168
4.443664-2	5.708464-2	6.463128-2	7.122510-2	7.959808-2	9.157152-2424033102	169
1.118505-1	1.170509-1	1.178794-1	7.333264-2	8.302728-2	9.149790-2424033102	170
1.022541-1	1.176355-1	1.436865-1	1.503671-1	1.514314-1	9.400356-2424033102	171
1.035940-1	1.157722-1	1.331870-1	1.626820-1	1.702458-1	1.714507-1424033102	172
1.141629-1	1.275835-1	1.467751-1	1.792791-1	1.876146-1	1.889425-1424033102	173
1.425818-1	1.640294-1	2.003546-1	2.096700-1	2.111539-1	1.887034-1424033102	174
2.304926-1	2.412093-1	2.429165-1	2.815364-1	2.946263-1	2.967115-1424033102	175
3.083248-1	3.105070-1	3.127046-1	0.000000+0	0.000000+0	0.000000+0424033102	176
0.000000+0	0.000000+0	0	0	0	0424033 099999	

<sup>98</sup>Mo

Resonance Parameters

						4243	0	0	0
4.209800+4	9.706435+1	0	0	1	04243	2151	1		
4.209800+4	1.000000+0	0	0	2	04243	2151	2		
1.000000-5	3.200000+4	1	2	0	04243	2151	3		
0.000000+0	6.600000-1	0	0	2	04243	2151	4		
9.706435+1	0.000000+0	0	0	180	304243	2151	5		
-7.000000+2	5.000000-1	3.858400+0	3.800000+0	5.840000-2	0.000000+04243	2151	6		
467.454000	0.5	8.705000-1	7.820000-1	8.850000-2	0.000000+04243	2151	7		
1526.40000	0.5	1.460000+0	1.390000+0	7.000000-2	0.000000+04243	2151	8		
2.553000+3	5.000000-1	1.700000-1	1.000000-1	7.000000-2	0.000000+04243	2151	9		
3.302000+3	5.000000-1	1.545000+0	1.480000+0	6.499990-2	0.000000+04243	2151	10		
4.486000+3	5.000000-1	5.120000-1	4.280000-1	8.400000-2	0.000000+04243	2151	11		
5.610000+3	5.000000-1	2.031000+0	1.945000+0	8.600000-2	0.000000+04243	2151	12		
6.179000+3	5.000000-1	6.644000+0	6.600000+0	4.400000-2	0.000000+04243	2151	13		
7.515000+3	5.000000-1	4.106000+0	4.035000+0	7.100000-2	0.000000+04243	2151	14		
9.045000+3	5.000000-1	3.595500+1	3.583000+1	1.250000-1	0.000000+04243	2151	15		
1.060000+4	5.000000-1	1.209540+1	1.203000+1	6.539990-2	0.000000+04243	2151	16		
1.159800+4	5.000000-1	2.015000+0	1.936000+0	7.899990-2	0.000000+04243	2151	17		
1.482500+4	5.000000-1	3.856000+0	3.770000+0	8.600000-2	0.000000+04243	2151	18		
1.594000+4	5.000000-1	1.586000+0	1.500000+0	8.600000-2	0.000000+04243	2151	19		
1.650000+4	5.000000-1	2.507000+0	2.440000+0	6.700000-2	0.000000+04243	2151	20		
1.928500+4	5.000000-1	4.678000+0	4.580000+0	9.800000-2	0.000000+04243	2151	21		
2.870000+4	5.000000-1	1.031200+1	1.015000+1	1.620000-1	0.000000+04243	2151	22		
3.061000+4	5.000000-1	4.400000+1	4.390000+1	1.000000-1	0.000000+04243	2151	23		
3.616000+4	5.000000-1	2.168500+1	2.160000+1	8.500000-2	0.000000+04243	2151	24		
3.692000+4	5.000000-1	1.348500+1	1.340000+1	8.500000-2	0.000000+04243	2151	25		
3.777000+4	5.000000-1	1.718500+1	1.710000+1	8.500000-2	0.000000+04243	2151	26		
3.835000+4	5.000000-1	3.178500+1	3.170000+1	8.500000-2	0.000000+04243	2151	27		
3.880000+4	5.000000-1	2.268500+1	2.260000+1	8.500000-2	0.000000+04243	2151	28		
4.486000+4	5.000000-1	1.528500+1	1.520000+1	8.500000-2	0.000000+04243	2151	29		
4.528000+4	5.000000-1	6.108500+1	6.100000+1	8.500000-2	0.000000+04243	2151	30		
4.582000+4	5.000000-1	2.788500+1	2.780000+1	8.500000-2	0.000000+04243	2151	31		
4.611000+4	5.000000-1	1.548500+1	1.540000+1	8.500000-2	0.000000+04243	2151	32		
4.860000+4	5.000000-1	2.888500+1	2.880000+1	8.500000-2	0.000000+04243	2151	33		
4.997000+4	5.000000-1	2.038500+1	2.030000+1	8.500000-2	0.000000+04243	2151	34		
5.279000+4	5.000000-1	2.208500+1	2.200000+1	8.500000-2	0.000000+04243	2151	35		
9.706435+1	0.000000+0	1	0	768	1284243	2151	36		
12.0700000	1.5	1.200309-1	3.090000-5	1.200000-1	0.000000+04243	2151	37		
401.440000	1.5	1.213800-1	1.380000-3	1.200000-1	0.000000+04243	2151	38		
429.203000	0.5	1.805000-1	6.750000-2	1.130000-1	0.000000+04243	2151	39		
612.250000	0.5	1.800000-1	6.000000-2	1.200000-1	0.000000+04243	2151	40		
817.760000	1.5	1.790000-1	5.900000-2	1.200000-1	0.000000+04243	2151	41		
1122.20000	1.5	1.295000-1	9.500000-3	1.200000-1	0.000000+04243	2151	42		
1927.50000	1.5	1.310000-1	1.100000-2	1.200000-1	0.000000+04243	2151	43		
2.026000+3	5.000000-1	1.225500-1	2.550000-3	1.200000-1	0.000000+04243	2151	44		
2.182000+3	5.000000-1	2.980000-1	1.700000-1	1.280000-1	0.000000+04243	2151	45		
2.465000+3	5.000000-1	2.269999-1	9.299990-2	1.340000-1	0.000000+04243	2151	46		
2.617000+3	1.500000+0	1.447000-1	2.470000-2	1.200000-1	0.000000+04243	2151	47		
2.951000+3	5.000000-1	1.778000-1	5.780000-2	1.200000-1	0.000000+04243	2151	48		
3.269000+3	5.000000-1	1.674000-1	4.740000-2	1.200000-1	0.000000+04243	2151	49		
3.804000+3	1.500000+0	2.920000-1	1.860000-1	1.060000-1	0.000000+04243	2151	50		
4.023000+3	1.500000+0	2.501999-1	8.619990-2	1.640000-1	0.000000+04243	2151	51		
4.579000+3	1.500000+0	3.030000-1	1.650000-1	1.380000-1	0.000000+04243	2151	52		
4.858000+3	1.500000+0	3.320000-1	2.060000-1	1.260000-1	0.000000+04243	2151	53		
5.282000+3	1.500000+0	6.590000-1	5.840000-1	7.500000-2	0.000000+04243	2151	54		
5.430000+3	5.000000-1	1.694000-1	4.940000-2	1.200000-1	0.000000+04243	2151	55		
5.651000+3	5.000000-1	7.870000-1	6.410000-1	1.460000-1	0.000000+04243	2151	56		
5.931000+3	5.000000-1	1.311000+0	1.161000+0	1.500000-1	0.000000+04243	2151	57		
6.197000+3	5.000000-1	1.756000-1	5.560000-2	1.200000-1	0.000000+04243	2151	58		
6.690000+3	5.000000-1	2.830000-1	1.780000-1	1.050000-1	0.000000+04243	2151	59		
6.833000+3	1.500000+0	5.294000+0	4.420000-1	8.740000-2	0.000000+04243	2151	60		
7.111000+3	5.000000-1	1.565000-1	3.650000-2	1.200000-1	0.000000+04243	2151	61		
7.196000+3	5.000000-1	2.754000-1	1.840000-1	9.140000-2	0.000000+04243	2151	62		
7.613000+3	5.000000-1	6.460000-1	5.090000-1	1.370000-1	0.000000+04243	2151	63		

7.981000+3	1.500000+0	5.470000-1	4.530000-1	9.400000-2	0.000000+04243	2151	64
8.580000+3	1.500000+0	1.360000+0	1.257000+0	1.030000-1	0.000000+04243	2151	65
8.616000+3	5.000000-1	1.870000-1	6.700000-2	1.200000-1	0.000000+04243	2151	66
8.840000+3	1.500000+0	7.150000-1	5.980000-1	1.170000-1	0.000000+04243	2151	67
9.385000+3	5.000000-1	2.610000-1	2.100000-1	5.100000-2	0.000000+04243	2151	68
9.450000+3	5.000000-1	1.358000-1	1.580000-2	1.200000-1	0.000000+04243	2151	69
9.686000+3	1.500000+0	8.300000-1	7.640000-1	6.600000-2	0.000000+04243	2151	70
9.749000+3	5.000000-1	3.290000-1	2.140000-1	1.150000-1	0.000000+04243	2151	71
1.005300+4	5.000000-1	4.930000-1	3.910000-1	1.020000-1	0.000000+04243	2151	72
1.090000+4	1.500000+0	4.255999-1	3.390000-1	8.659990-2	0.000000+04243	2151	73
1.131000+4	5.000000-1	3.770000-1	3.190000-1	5.800000-2	0.000000+04243	2151	74
1.136100+4	1.500000+0	1.638000+0	1.540000+0	9.800000-2	0.000000+04243	2151	75
1.170300+4	1.500000+0	3.591000+0	3.460000+0	1.310000-1	0.000000+04243	2151	76
1.202000+4	1.500000+0	2.927000+0	2.846000+0	8.100000-2	0.000000+04243	2151	77
1.210000+4	1.500000+0	6.660000-1	5.710000-1	9.500000-2	0.000000+04243	2151	78
1.285600+4	5.000000-1	3.800000-1	2.600000-1	1.200000-1	0.000000+04243	2151	79
1.300500+4	5.000000-1	3.800000-1	2.600000-1	1.200000-1	0.000000+04243	2151	80
1.316000+4	1.500000+0	5.005000+0	4.070000-1	9.350000-2	0.000000+04243	2151	81
1.342000+4	1.500000+0	1.139300+0	1.042000+0	9.729990-2	0.000000+04243	2151	82
1.394300+4	5.000000-1	2.400000-1	1.200000-1	1.200000-1	0.000000+04243	2151	83
1.403000+4	5.000000-1	2.119999-1	9.199990-2	1.200000-1	0.000000+04243	2151	84
1.408000+4	5.000000-1	5.540000-1	4.340000-1	1.200000-1	0.000000+04243	2151	85
1.463000+4	1.500000+0	3.566000-1	2.720000-1	8.460000-2	0.000000+04243	2151	86
1.478500+4	1.500000+0	2.640000+0	2.550000+0	9.000000-2	0.000000+04243	2151	87
1.525000+4	1.500000+0	8.560000-1	7.650000-1	9.100000-2	0.000000+04243	2151	88
1.533000+4	5.000000-1	4.110000-1	2.910000-1	1.200000-1	0.000000+04243	2151	89
1.578000+4	5.000000-1	3.350000-1	2.150000-1	1.200000-1	0.000000+04243	2151	90
1.623800+4	1.500000+0	4.770000-1	3.820000-1	9.500000-2	0.000000+04243	2151	91
1.674000+4	1.500000+0	4.760000-1	3.870000-1	8.900000-2	0.000000+04243	2151	92
1.699500+4	5.000000-1	3.375000+0	3.250000+0	1.250000-1	0.000000+04243	2151	93
1.738000+4	1.500000+0	3.950000-1	2.750000-1	1.200000-1	0.000000+04243	2151	94
1.764000+4	5.000000-1	3.773000+0	3.650000+0	1.230000-1	0.000000+04243	2151	95
1.774500+4	1.500000+0	2.940000-1	1.740000-1	1.200000-1	0.000000+04243	2151	96
1.804500+4	5.000000-1	1.636000-1	4.360000-2	1.200000-1	0.000000+04243	2151	97
1.833500+4	1.500000+0	5.649999-1	4.730000-1	9.199990-2	0.000000+04243	2151	98
1.858000+4	1.500000+0	2.028000-1	8.280000-2	1.200000-1	0.000000+04243	2151	99
1.906000+4	1.500000+0	7.380000-1	6.180000-1	1.200000-1	0.000000+04243	2151	100
1.962500+4	1.500000+0	4.814000+0	4.690000+0	1.240000-1	0.000000+04243	2151	101
1.974500+4	1.500000+0	3.200000-1	2.000000-1	1.200000-1	0.000000+04243	2151	102
1.991000+4	5.000000-1	3.130000-1	1.930000-1	1.200000-1	0.000000+04243	2151	103
2.003000+4	1.500000+0	5.470000-1	4.240000-1	1.230000-1	0.000000+04243	2151	104
2.025500+4	5.000000-1	1.410000+0	1.280000+0	1.300000-1	0.000000+04243	2151	105
2.086500+4	5.000000-1	4.800000-1	3.600000-1	1.200000-1	0.000000+04243	2151	106
2.117000+4	1.500000+0	2.150000-1	9.500000-2	1.200000-1	0.000000+04243	2151	107
2.139500+4	5.000000-1	2.290000-1	1.090000-1	1.200000-1	0.000000+04243	2151	108
2.153000+4	5.000000-1	1.920000-1	7.200000-2	1.200000-1	0.000000+04243	2151	109
2.167500+4	1.500000+0	3.000000-1	1.800000-1	1.200000-1	0.000000+04243	2151	110
2.195000+4	1.500000+0	1.750000+0	1.553000+0	1.970000-1	0.000000+04243	2151	111
2.207000+4	1.500000+0	2.242000+0	2.150000+0	9.199990-2	0.000000+04243	2151	112
2.257000+4	1.500000+0	9.270000-1	8.250000-1	1.020000-1	0.000000+04243	2151	113
2.298000+4	1.500000+0	9.490000-1	8.320000-1	1.170000-1	0.000000+04243	2151	114
2.318000+4	5.000000-1	2.028000-1	8.280000-2	1.200000-1	0.000000+04243	2151	115
2.354500+4	1.500000+0	5.974000+0	5.820000+0	1.540000-1	0.000000+04243	2151	116
2.368000+4	5.000000-1	1.233000+0	1.075000+0	1.580000-1	0.000000+04243	2151	117
2.394500+4	1.500000+0	3.430000-1	2.230000-1	1.200000-1	0.000000+04243	2151	118
2.437000+4	5.000000-1	1.967000+0	1.870000+0	9.699990-2	0.000000+04243	2151	119
2.448000+4	5.000000-1	4.000000-1	2.800000-1	1.200000-1	0.000000+04243	2151	120
2.458000+4	1.500000+0	3.960000+0	3.834000+0	1.260000-1	0.000000+04243	2151	121
2.492000+4	5.000000-1	1.025000+0	9.450000-1	8.000000-2	0.000000+04243	2151	122
2.554000+4	1.500000+0	2.968000+0	2.870000+0	9.800000-2	0.000000+04243	2151	123
2.561000+4	1.500000+0	9.080000-1	8.000000-1	1.080000-1	0.000000+04243	2151	124
2.608000+4	1.500000+0	1.900000+0	1.740000+0	1.600000-1	0.000000+04243	2151	125
2.619000+4	1.500000+0	6.000000-1	4.800000-1	1.200000-1	0.000000+04243	2151	126
2.693000+4	1.500000+0	6.120000-1	4.920000-1	1.200000-1	0.000000+04243	2151	127
2.715000+4	1.500000+0	2.687000+0	2.550000+0	1.370000-1	0.000000+04243	2151	128
2.768000+4	5.000000-1	1.320000+0	1.163000+0	1.570000-1	0.000000+04243	2151	129

2.786000+4	1.500000+0	1.638000+0	1.500000+0	1.380000-1	0.000000+04243	2151	130
2.796000+4	1.500000+0	1.250000+0	1.130000+0	1.200000-1	0.000000+04243	2151	131
2.833000+4	5.000000-1	4.800000-1	3.600000-1	1.200000-1	0.000000+04243	2151	132
2.892000+4	1.500000+0	2.770000-1	1.570000-1	1.200000-1	0.000000+04243	2151	133
2.909000+4	5.000000-1	7.200000-1	6.000000-1	1.200000-1	0.000000+04243	2151	134
2.943000+4	5.000000-1	2.018000+0	1.885000+0	1.330000-1	0.000000+04243	2151	135
2.972000+4	5.000000-1	8.000000-1	6.800000-1	1.200000-1	0.000000+04243	2151	136
2.985000+4	1.500000+0	9.310000-1	7.760000-1	1.550000-1	0.000000+04243	2151	137
3.017000+4	1.500000+0	4.430000-1	3.230000-1	1.200000-1	0.000000+04243	2151	138
3.046000+4	5.000000-1	2.570000-1	1.370000-1	1.200000-1	0.000000+04243	2151	139
3.068000+4	1.500000+0	4.329000+0	4.115000+0	2.140000-1	0.000000+04243	2151	140
3.120000+4	1.500000+0	1.953000+0	1.763000+0	1.900000-1	0.000000+04243	2151	141
3.154000+4	5.000000-1	3.310000+0	3.190000+0	1.200000-1	0.000000+04243	2151	142
3.204000+4	5.000000-1	5.300000+0	5.180000+0	1.200000-1	0.000000+04243	2151	143
3.216000+4	5.000000-1	6.570000+0	6.450000+0	1.200000-1	0.000000+04243	2151	144
3.247000+4	5.000000-1	4.120000+0	4.000000+0	1.200000-1	0.000000+04243	2151	145
3.343000+4	5.000000-1	5.220000+0	5.100000+0	1.200000-1	0.000000+04243	2151	146
3.381000+4	5.000000-1	3.240000+0	3.120000+0	1.200000-1	0.000000+04243	2151	147
3.398000+4	5.000000-1	7.670000+0	7.550000+0	1.200000-1	0.000000+04243	2151	148
3.720000+4	5.000000-1	3.590000+0	3.470000+0	1.200000-1	0.000000+04243	2151	149
3.959000+4	5.000000-1	5.680000+0	5.560000+0	1.200000-1	0.000000+04243	2151	150
4.011000+4	5.000000-1	3.920000+0	3.800000+0	1.200000-1	0.000000+04243	2151	151
4.086000+4	5.000000-1	4.160000+0	4.040000+0	1.200000-1	0.000000+04243	2151	152
4.144000+4	5.000000-1	5.200000+0	5.080000+0	1.200000-1	0.000000+04243	2151	153
4.182000+4	5.000000-1	6.650000+0	6.530000+0	1.200000-1	0.000000+04243	2151	154
4.308000+4	5.000000-1	1.132000+1	1.120000+1	1.200000-1	0.000000+04243	2151	155
4.312000+4	5.000000-1	2.400000+0	2.280000+0	1.200000-1	0.000000+04243	2151	156
4.412000+4	5.000000-1	2.430000+0	2.310000+0	1.200000-1	0.000000+04243	2151	157
4.424000+4	5.000000-1	3.480000+0	3.360000+0	1.200000-1	0.000000+04243	2151	158
4.449000+4	5.000000-1	1.082000+1	1.070000+1	1.200000-1	0.000000+04243	2151	159
4.598000+4	5.000000-1	3.330000+0	3.210000+0	1.200000-1	0.000000+04243	2151	160
4.730000+4	5.000000-1	4.030000+0	3.910000+0	1.200000-1	0.000000+04243	2151	161
4.925000+4	5.000000-1	3.220000+0	3.100000+0	1.200000-1	0.000000+04243	2151	162
4.944000+4	5.000000-1	9.220000+0	9.100000+0	1.200000-1	0.000000+04243	2151	163
5.226000+4	5.000000-1	9.250000+0	9.130000+0	1.200000-1	0.000000+04243	2151	164
3.200000+4	1.000000+6	2	2	0	04243	2151	165
0.000000+0	6.531800-1	1	0	3	04243	2151	166
9.706435+1	0.000000+0	0	0	1	04243	2151	167
5.000000-1	0.000000+0	5	0	108	174243	2151	168
0.000000+0	0.000000+0	1.000000+0	1.000000+0	0.000000+0	0.000000+04243	2151	169
3.200000+4	8.403700+2	0.000000+0	3.899300-2	7.200000-2	0.000000+04243	2151	170
4.000000+4	8.388900+2	0.000000+0	3.892400-2	7.200000-2	0.000000+04243	2151	171
5.000000+4	8.230300+2	0.000000+0	3.818900-2	7.200000-2	0.000000+04243	2151	172
6.000000+4	8.075400+2	0.000000+0	3.747000-2	7.200000-2	0.000000+04243	2151	173
7.000000+4	7.846400+2	0.000000+0	3.640700-2	7.200000-2	0.000000+04243	2151	174
8.000000+4	7.635400+2	0.000000+0	3.542800-2	7.200000-2	0.000000+04243	2151	175
9.000000+4	7.402100+2	0.000000+0	3.434600-2	7.200000-2	0.000000+04243	2151	176
1.000000+5	7.213500+2	0.000000+0	3.347000-2	7.200000-2	0.000000+04243	2151	177
2.000000+5	5.528200+2	0.000000+0	2.565100-2	7.200000-2	0.000000+04243	2151	178
3.000000+5	4.151300+2	0.000000+0	1.926200-2	7.200000-2	0.000000+04243	2151	179
4.000000+5	3.203800+2	0.000000+0	1.486600-2	7.200000-2	0.000000+04243	2151	180
5.000000+5	2.602900+2	0.000000+0	1.207700-2	7.200000-2	0.000000+04243	2151	181
6.000000+5	2.136700+2	0.000000+0	9.914100-3	7.200000-2	0.000000+04243	2151	182
7.000000+5	1.799000+2	0.000000+0	8.347300-3	7.200000-2	0.000000+04243	2151	183
8.000000+5	1.383400+2	1.541600+0	6.418800-3	7.200000-2	0.000000+04243	2151	184
9.000000+5	1.680200+2	3.123300+0	7.795900-3	7.200000-2	0.000000+04243	2151	185
1.000000+6	1.461000+2	3.561100+0	6.779300-3	7.200000-2	0.000000+04243	2151	186
9.706435+1	0.000000+0	1	0	2	04243	2151	187
5.000000-1	0.000000+0	5	0	108	174243	2151	188
0.000000+0	0.000000+0	2.000000+0	1.000000+0	0.000000+0	0.000000+04243	2151	189
3.200000+4	8.403700+2	0.000000+0	4.664100-1	1.070000-1	0.000000+04243	2151	190
4.000000+4	8.388900+2	0.000000+0	4.655800-1	1.070000-1	0.000000+04243	2151	191
5.000000+4	8.230300+2	0.000000+0	4.567800-1	1.070000-1	0.000000+04243	2151	192
6.000000+4	8.075400+2	0.000000+0	4.481800-1	1.070000-1	0.000000+04243	2151	193
7.000000+4	7.846400+2	0.000000+0	4.354800-1	1.070000-1	0.000000+04243	2151	194
8.000000+4	7.635400+2	0.000000+0	4.237700-1	1.070000-1	0.000000+04243	2151	195

9.000000+4	7.402100+2	0.000000+0	4.108200-1	1.070000-1	0.000000+04243	2151	196
1.000000+5	7.213500+2	0.000000+0	4.003500-1	1.070000-1	0.000000+04243	2151	197
2.000000+5	5.528200+2	0.000000+0	3.068200-1	1.070000-1	0.000000+04243	2151	198
3.000000+5	4.151300+2	0.000000+0	2.304000-1	1.070000-1	0.000000+04243	2151	199
4.000000+5	3.203800+2	0.000000+0	1.778100-1	1.070000-1	0.000000+04243	2151	200
5.000000+5	2.602900+2	0.000000+0	1.444600-1	1.070000-1	0.000000+04243	2151	201
6.000000+5	2.136700+2	0.000000+0	1.185800-1	1.070000-1	0.000000+04243	2151	202
7.000000+5	1.799000+2	0.000000+0	9.984400-2	1.070000-1	0.000000+04243	2151	203
8.000000+5	1.383400+2	1.925500+0	7.677700-2	1.070000-1	0.000000+04243	2151	204
9.000000+5	1.680200+2	1.391400+1	9.324800-2	1.070000-1	0.000000+04243	2151	205
1.000000+6	1.461000+2	2.437800+1	8.108800-2	1.070000-1	0.000000+04243	2151	206
1.500000+0	0.000000+0	5	0	108	174243	2151	207
0.000000+0	0.000000+0	2.000000+0	1.000000+0	0.000000+0	0.000000+04243	2151	208
3.200000+4	4.201900+2	0.000000+0	2.332000-1	1.070000-1	0.000000+04243	2151	209
4.000000+4	4.194400+2	0.000000+0	2.327900-1	1.070000-1	0.000000+04243	2151	210
5.000000+4	4.115200+2	0.000000+0	2.283900-1	1.070000-1	0.000000+04243	2151	211
6.000000+4	4.037700+2	0.000000+0	2.240900-1	1.070000-1	0.000000+04243	2151	212
7.000000+4	3.923200+2	0.000000+0	2.177400-1	1.070000-1	0.000000+04243	2151	213
8.000000+4	3.817700+2	0.000000+0	2.118800-1	1.070000-1	0.000000+04243	2151	214
9.000000+4	3.701100+2	0.000000+0	2.054100-1	1.070000-1	0.000000+04243	2151	215
1.000000+5	3.606700+2	0.000000+0	2.001700-1	1.070000-1	0.000000+04243	2151	216
2.000000+5	2.764100+2	0.000000+0	1.534100-1	1.070000-1	0.000000+04243	2151	217
3.000000+5	2.075600+2	0.000000+0	1.152000-1	1.070000-1	0.000000+04243	2151	218
4.000000+5	1.601900+2	0.000000+0	8.890600-2	1.070000-1	0.000000+04243	2151	219
5.000000+5	1.301400+2	0.000000+0	7.223000-2	1.070000-1	0.000000+04243	2151	220
6.000000+5	1.068300+2	0.000000+0	5.929200-2	1.070000-1	0.000000+04243	2151	221
7.000000+5	8.995000+1	0.000000+0	4.992200-2	1.070000-1	0.000000+04243	2151	222
8.000000+5	6.916800+1	9.853900-1	3.838800-2	1.070000-1	0.000000+04243	2151	223
9.000000+5	8.400800+1	9.528700+0	4.662400-2	1.070000-1	0.000000+04243	2151	224
1.000000+6	7.305200+1	1.745100+1	4.054400-2	1.070000-1	0.000000+04243	2151	225
9.706435+1	0.000000+0	2	0	2	04243	2151	226
1.500000+0	0.000000+0	5	0	108	174243	2151	227
0.000000+0	0.000000+0	1.000000+0	1.000000+0	0.000000+0	0.000000+04243	2151	228
3.200000+4	4.201900+2	0.000000+0	2.437100-2	7.200000-2	0.000000+04243	2151	229
4.000000+4	4.194400+2	0.000000+0	2.432800-2	7.200000-2	0.000000+04243	2151	230
5.000000+4	4.115200+2	0.000000+0	2.386800-2	7.200000-2	0.000000+04243	2151	231
6.000000+4	4.037700+2	0.000000+0	2.341900-2	7.200000-2	0.000000+04243	2151	232
7.000000+4	3.923200+2	0.000000+0	2.275500-2	7.200000-2	0.000000+04243	2151	233
8.000000+4	3.817700+2	0.000000+0	2.214300-2	7.200000-2	0.000000+04243	2151	234
9.000000+4	3.701100+2	0.000000+0	2.146600-2	7.200000-2	0.000000+04243	2151	235
1.000000+5	3.606700+2	0.000000+0	2.091900-2	7.200000-2	0.000000+04243	2151	236
2.000000+5	2.764100+2	0.000000+0	1.603200-2	7.200000-2	0.000000+04243	2151	237
3.000000+5	2.075600+2	0.000000+0	1.203900-2	7.200000-2	0.000000+04243	2151	238
4.000000+5	1.601900+2	0.000000+0	9.291100-3	7.200000-2	0.000000+04243	2151	239
5.000000+5	1.301400+2	0.000000+0	7.548300-3	7.200000-2	0.000000+04243	2151	240
6.000000+5	1.068300+2	0.000000+0	6.196300-3	7.200000-2	0.000000+04243	2151	241
7.000000+5	8.995000+1	0.000000+0	5.217100-3	7.200000-2	0.000000+04243	2151	242
8.000000+5	6.916800+1	2.167200-1	4.011800-3	7.200000-2	0.000000+04243	2151	243
9.000000+5	8.400800+1	1.292500+0	4.872400-3	7.200000-2	0.000000+04243	2151	244
1.000000+6	7.305200+1	1.644100+0	4.237000-3	7.200000-2	0.000000+04243	2151	245
2.500000+0	0.000000+0	5	0	108	174243	2151	246
0.000000+0	0.000000+0	1.000000+0	1.000000+0	0.000000+0	0.000000+04243	2151	247
3.200000+4	2.801200+2	0.000000+0	1.624700-2	7.200000-2	0.000000+04243	2151	248
4.000000+4	2.796300+2	0.000000+0	1.621800-2	7.200000-2	0.000000+04243	2151	249
5.000000+4	2.743400+2	0.000000+0	1.591200-2	7.200000-2	0.000000+04243	2151	250
6.000000+4	2.691800+2	0.000000+0	1.561200-2	7.200000-2	0.000000+04243	2151	251
7.000000+4	2.615500+2	0.000000+0	1.517000-2	7.200000-2	0.000000+04243	2151	252
8.000000+4	2.545100+2	0.000000+0	1.476200-2	7.200000-2	0.000000+04243	2151	253
9.000000+4	2.467400+2	0.000000+0	1.431100-2	7.200000-2	0.000000+04243	2151	254
1.000000+5	2.404500+2	0.000000+0	1.394600-2	7.200000-2	0.000000+04243	2151	255
2.000000+5	1.842700+2	0.000000+0	1.068800-2	7.200000-2	0.000000+04243	2151	256
3.000000+5	1.383800+2	0.000000+0	8.025800-3	7.200000-2	0.000000+04243	2151	257
4.000000+5	1.067900+2	0.000000+0	6.194000-3	7.200000-2	0.000000+04243	2151	258
5.000000+5	8.676200+1	0.000000+0	5.032200-3	7.200000-2	0.000000+04243	2151	259
6.000000+5	7.122200+1	0.000000+0	4.130900-3	7.200000-2	0.000000+04243	2151	260
7.000000+5	5.996600+1	0.000000+0	3.478100-3	7.200000-2	0.000000+04243	2151	261

8.000000+5	4.611200+1	1.444800-1	2.674500-3	7.200000-2	0.000000+0	4243	2151	262
9.000000+5	5.600500+1	8.616600-1	3.248300-3	7.200000-2	0.000000+0	4243	2151	263
1.000000+6	4.870200+1	1.096100+0	2.824700-3	7.200000-2	0.000000+0	4243	2151	264
						4243	2	099999

Covariance Data

						4243	0	0	0
42098.0	9.706430+1	0	0	1		0424332151			1
42098.0	1.000000+0	0	0	1		0424332151			2
1.000000-5	3.200000+4	1	2	0		1424332151			3
0.0	7.000000-1	0	1	0		0424332151			4
9.706430+1		0	0	1		0424332151			5
		3	0	102		4424332151			6
467.4540000	0.5	8.705000-1	7.820000-1	8.850000-2		424332151			7
12.07000000	1.5	1.200309-1	3.090000-5	1.200000-1		424332151			8
401.4400000	1.5	1.213800-1	1.380000-3	1.200000-1		424332151			9
429.2030000	0.5	1.805000-1	6.750000-2	1.130000-1		424332151			10
3.858982-3	-4.186035-4	-9.861075-6	-4.069936-9	-3.63329-12	-3.967959	-8424332151			11
-1.019010-7	-6.99536-10	-2.399259-7	4.044427-9	-5.300272-8	1.709598	-7424332151			12
1.845970-2	1.083673-4	1.823414-7	2.13762-10	2.451862-6	3.432708	-6424332151			13
4.353355-8	2.612965-5	4.498072-6	-1.328928-5	3.611930-5	2.460655	-5424332151			14
1.492303-9	1.30706-11	4.563144-8	4.187038-9	1.833536-9	4.503942	-7424332151			15
-2.968965-8	-2.722962-8	1.850039-7	1.389225-5	6.39917-11	2.823380	-8424332151			16
-4.86882-11	1.13076-11	3.500955-9	-9.78545-11	-1.376244-9	4.251939	-9424332151			17
9.07394-13	5.854558-9	-3.67917-12	2.37014-13	5.08126-11	5.79097	-13424332151			18
-5.92488-12	4.60290-11	1.042734-4	-8.233476-9	1.186520-9	4.018143	-7424332151			19
-1.702021-8	-1.733777-7	4.865692-7	8.535428-3	2.491783-7	1.899884	-4424332151			20
-7.868691-8	1.649279-7	-4.783755-7	1.600120-8	3.964024-6	-2.959026	-9424332151			21
2.96977-10	1.941042-9	7.381344-3	9.717711-7	-3.329585-6	9.427140	-6424332151			22
1.871583-4	3.991863-5	-1.189445-4	3.082549-4	-8.700436-4	2.482623	-3424332151			23
0.0	0.0	0	0	0		0424332	0	24	
0.0	0.0	0	0	0		04243	0	018929	
4.209800+4	9.706430+1	0	0	0		1424333	1	1	
0.000000+0	0.000000+0	0	1	0		1424333	1	2	
0.000000+0	0.000000+0	1	5	1035		45424333	1	3	
1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000	-2424333	1	4	
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000	-1424333	1	5	
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000	-1424333	1	6	
4.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000	+0424333	1	7	
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000	+2424333	1	8	
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000	+5424333	1	9	
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000	+6424333	1	10	
6.434000+6	8.187300+6	2.000000+7	4.762870-4	0.000000+0	0.000000	+0424333	1	11	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	12	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	13	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	14	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	15	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	16	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	17	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	4.632826	-4424333	1	18	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	19	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	20	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	21	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	22	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	23	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	24	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	25	
4.532215-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	26	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	27	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	28	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	29	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	30	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	31	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	32	
4.422609-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	33	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000	+0424333	1	34	

[illegible]



[illegible]

2.070045-3	2.115000-3	2.025000-3	2.025000-3	2.025000-3	2.025000-3424333	1	167
2.024640-3	2.070000-3	2.070000-3	2.025000-3	2.070045-3	2.115000-3424333	1	168
2.025000-3	2.025000-3	2.025000-3	2.024640-3	2.070000-3	2.070000-3424333	1	169
2.025000-3	2.070045-3	2.115000-3	2.025000-3	2.025000-3	2.024640-3424333	1	170
2.070000-3	2.070000-3	2.025000-3	2.070045-3	2.115000-3	2.025000-3424333	1	171
2.024640-3	2.070000-3	2.070000-3	2.025000-3	2.070045-3	2.115000-3424333	1	172
2.024280-3	2.069632-3	2.069632-3	2.024640-3	2.069677-3	2.114624-3424333	1	173
2.116000-3	2.116000-3	2.070000-3	2.116046-3	2.162000-3	2.116000-3424333	1	174
2.070000-3	2.116046-3	2.162000-3	2.025000-3	2.070045-3	2.115000-3424333	1	175
2.116092-3	2.162047-3	2.209000-3	0.000000+0	0.000000+0	0.000000+0424333	1	176
0.000000+0	0.000000+0	0	0	0	0424333	099999	
4.209800+4	9.706430+1	0	0	0	1424333	2	1
0.000000+0	0.000000+0	0	2	0	1424333	2	2
0.000000+0	0.000000+0	1	5	1035	45424333	2	3
1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000-2424333	2	4
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000-1424333	2	5
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000-1424333	2	6
4.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000+0424333	2	7
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000+2424333	2	8
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000+5424333	2	9
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000+6424333	2	10
6.434000+6	8.187300+6	2.000000+7	7.837760-4	0.000000+0	0.000000+0424333	2	11
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	12
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	13
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	14
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	15
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	16
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	17
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	7.636932-4424333	2	18
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	19
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	20
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	21
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	22
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	23
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	24
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	25
7.619808-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	26
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	27
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	28
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	29
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	30
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	31
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	32
7.609322-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	33
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	34
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	35
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	36
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	37
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	38
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	7.604358-4424333	2	39
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	40
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	41
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	42
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	43
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	44
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	45
0.000000+0	0.000000+0	0.000000+0	7.602703-4	0.000000+0	0.000000+0424333	2	46
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	47
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	48
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	49
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	50
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	51
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	52
7.601600-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	53
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	54
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	55

[illegible]

0.000000+0	0.000000+0	2.144174-4	0.000000+0	0.000000+0	0.000000+0424333	2	122
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	123
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	124
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	125
0.000000+0	0.000000+0	0.000000+0	2.142418-4	0.000000+0	0.000000+0424333	2	126
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	127
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	128
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	129
0.000000+0	0.000000+0	0.000000+0	2.139491-4	0.000000+0	0.000000+0424333	2	130
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	131
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	132
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	133
0.000000+0	0.000000+0	2.135105-4	0.000000+0	0.000000+0	0.000000+0424333	2	134
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	135
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	136
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	137
2.130432-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	138
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	139
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	140
0.000000+0	0.000000+0	0.000000+0	2.125472-4	0.000000+0	0.000000+0424333	2	141
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	142
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	143
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	2.119354-4424333	2	144
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	145
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	146
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	147
2.084558-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	148
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	149
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	150
2.244903-4	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	151
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	152
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	153
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	154
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	155
0.000000+0	0.000000+0	0.000000+0	5.756712-3	0.000000+0	0.000000+0424333	2	156
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	157
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	158
1.224860-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	159
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333	2	160
0.000000+0	0.000000+0	1.024000-3	2.016000-3	1.824000-3	1.792000-3424333	2	161
2.048000-3	2.368000-3	2.656000-3	2.949248-3	3.456000-3	3.808000-3424333	2	162
3.968000-3	3.647680-3	3.360000-3	3.969000-3	3.591000-3	3.528000-3424333	2	163
4.032000-3	4.662000-3	5.229000-3	5.806332-3	6.804000-3	7.497000-3424333	2	164
7.812000-3	7.181370-3	6.615000-3	3.249000-3	3.192000-3	3.648000-3424333	2	165
4.218000-3	4.731000-3	5.253348-3	6.156000-3	6.783000-3	7.068000-3424333	2	166
6.497430-3	5.985000-3	3.136000-3	3.584000-3	4.144000-3	4.648000-3424333	2	167
5.161184-3	6.048000-3	6.664000-3	6.944000-3	6.383440-3	5.880000-3424333	2	168
4.096000-3	4.736000-3	5.312000-3	5.898496-3	6.912000-3	7.616000-3424333	2	169
7.936000-3	7.295360-3	6.720000-3	5.476000-3	6.142000-3	6.820136-3424333	2	170
7.992000-3	8.806000-3	9.176000-3	8.435260-3	7.770000-3	6.889000-3424333	2	171
7.649612-3	8.964000-3	9.877000-3	1.029200-2	9.461170-3	8.715000-3424333	2	172
8.494203-3	9.953712-3	1.096752-2	1.142834-2	1.050577-2	9.677220-3424333	2	173
1.166400-2	1.285200-2	1.339200-2	1.231092-2	1.134000-2	1.416100-2424333	2	174
1.475600-2	1.356481-2	1.249500-2	1.537600-2	1.413476-2	1.302000-2424333	2	175
1.299372-2	1.196895-2	1.102500-2	0.000000+0	0.000000+0	0.000000+0424333	2	176
0.000000+0	0.000000+0	0	0	0	0424333	099999	
4.209800+4	9.706430+1	0	0	0	1424333102	1	
0.000000+0	0.000000+0	0	102	0	1424333102	2	
0.000000+0	0.000000+0	1	5	1035	45424333102	3	
1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000-2424333102	4	
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000-1424333102	5	
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000-1424333102	6	
4.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000+0424333102	7	
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000+2424333102	8	
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000+5424333102	9	
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000+6424333102	10	

[illegible]

[illegible]

0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333102	143
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	1.103970-2424333102	144
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333102	145
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333102	146
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333102	147
5.706141-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333102	148
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333102	149
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333102	150
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333102	151
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333102	152
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	1.605845-3424333102	153
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333102	154
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333102	155
0.000000+0	0.000000+0	0.000000+0	9.610000-4	0.000000+0	0.000000+0424333102	156
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333102	157
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333102	158
2.025000-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333102	159
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424333102	160
0.000000+0	0.000000+0	2.025000-3	3.195000-3	3.375000-3	3.195000-3424333102	161
3.915000-3	7.470000-3	1.107000-2	1.176525-2	1.188000-2	1.210500-2424333102	162
1.404000-2	1.417005-2	2.007000-2	5.041000-3	5.325000-3	5.041000-3424333102	163
6.177000-3	1.178600-2	1.746600-2	1.856295-2	1.874400-2	1.909900-2424333102	164
2.215200-2	2.235719-2	3.166600-2	5.625000-3	5.325000-3	6.525000-3424333102	165
1.245000-2	1.845000-2	1.960875-2	1.980000-2	2.017500-2	2.340000-2424333102	166
2.361675-2	3.345000-2	5.041000-3	6.177000-3	1.178600-2	1.746600-2424333102	167
1.856295-2	1.874400-2	1.909900-2	2.215200-2	2.235719-2	3.166600-2424333102	168
7.569000-3	1.444200-2	2.140200-2	2.274615-2	2.296800-2	2.340300-2424333102	169
2.714400-2	2.739543-2	3.880200-2	2.755600-2	4.083600-2	4.340070-2424333102	170
4.382400-2	4.465400-2	5.179200-2	5.227174-2	7.403600-2	6.051600-2424333102	171
6.431670-2	6.494400-2	6.617400-2	7.675200-2	7.746294-2	1.097160-1424333102	172
6.835610-2	6.902280-2	7.033005-2	8.157240-2	8.232799-2	1.166067-1424333102	173
6.969600-2	7.101600-2	8.236800-2	8.313096-2	1.177440-1	7.236100-2424333102	174
8.392800-2	8.470541-2	1.199740-1	9.734400-2	9.824568-2	1.391520-1424333102	175
9.915571-2	1.404409-1	1.989160-1	0.000000+0	0.000000+0	0.000000+0424333102	176
0.000000+0	0.000000+0	0	0	0	0424333 099999	

<sup>100</sup>Mo

Resonance Parameters									
						4249	0	0	0
4.210000+4	9.904922+1	0	0	1	04249	2151			1
4.210000+4	1.000000+0	0	0	2	04249	2151			2
1.000000-5	2.600000+4	1	2	0	04249	2151			3
0.000000+0	6.900000-1	0	0	2	04249	2151			4
9.904922+1	0.000000+0	0	0	198	334249	2151			5
-6.000000+2	5.000000-1	3.764400+0	3.700000+0	6.440000-2	0.000000+04249	2151			6
363.924000	0.5	6.600000-1	6.040000-1	5.600000-2	0.000000+04249	2151			7
1404.30000	0.5	1.630000-1	1.070000-1	5.600000-2	0.000000+04249	2151			8
1937.30000	0.5	9.800000-1	9.200000-1	6.000000-2	0.000000+04249	2151			9
2.636000+3	5.000000-1	4.750000-1	4.100000-1	6.500000-2	0.000000+04249	2151			10
3.015000+3	5.000000-1	2.000000+0	1.950000+0	5.000000-2	0.000000+04249	2151			11
4.521000+3	5.000000-1	9.510000-1	8.700000-1	8.100000-2	0.000000+04249	2151			12
4.745000+3	5.000000-1	2.630000-1	1.950000-1	6.800000-2	0.000000+04249	2151			13
5.168000+3	5.000000-1	5.550000+0	5.480000+0	7.000000-2	0.000000+04249	2151			14
5.636000+3	5.000000-1	7.773000+0	7.700000+0	7.300000-2	0.000000+04249	2151			15
7.273000+3	5.000000-1	4.750000+0	4.680000+0	7.000000-2	0.000000+04249	2151			16
7.673000+3	5.000000-1	6.051000+0	6.000000+0	5.100000-2	0.000000+04249	2151			17
8.440000+3	5.000000-1	5.290000-1	4.700000-1	5.900000-2	0.000000+04249	2151			18
8.800000+3	5.000000-1	1.092000+0	1.030000+0	6.200000-2	0.000000+04249	2151			19
9.658000+3	5.000000-1	2.967000+0	2.900000+0	6.700000-2	0.000000+04249	2151			20
1.139800+4	5.000000-1	8.900000-1	7.780000-1	1.120000-1	0.000000+04249	2151			21
1.198500+4	5.000000-1	1.206800+1	1.200000+1	6.800000-2	0.000000+04249	2151			22
1.399700+4	5.000000-1	2.510000+0	2.440000+0	7.000000-2	0.000000+04249	2151			23
1.474800+4	5.000000-1	2.215000+0	2.160000+0	5.500000-2	0.000000+04249	2151			24
1.563500+4	5.000000-1	2.226000+1	2.220000+1	6.000000-2	0.000000+04249	2151			25
1.666600+4	5.000000-1	1.437800+1	1.430000+1	7.800000-2	0.000000+04249	2151			26
1.692500+4	5.000000-1	1.740000+0	1.660000+0	8.000000-2	0.000000+04249	2151			27
1.769600+4	5.000000-1	2.624900+1	2.620000+1	4.900000-2	0.000000+04249	2151			28
1.935500+4	5.000000-1	2.712000+0	2.650000+0	6.200000-2	0.000000+04249	2151			29
2.009400+4	5.000000-1	1.358400+1	1.350000+1	8.400000-2	0.000000+04249	2151			30
2.073500+4	5.000000-1	1.045000+1	1.040000+1	5.000000-2	0.000000+04249	2151			31
2.217400+4	5.000000-1	7.376000+0	7.300000+0	7.600000-2	0.000000+04249	2151			32
2.240000+4	5.000000-1	7.681000+0	7.600000+0	8.100000-2	0.000000+04249	2151			33
2.282200+4	5.000000-1	1.376100+1	1.370000+1	6.100000-2	0.000000+04249	2151			34
2.340300+4	5.000000-1	6.049000+0	6.000000+0	4.900000-2	0.000000+04249	2151			35
2.388000+4	5.000000-1	1.826300+1	1.820000+1	6.300000-2	0.000000+04249	2151			36
2.459000+4	5.000000-1	1.859400+1	1.850000+1	9.400000-2	0.000000+04249	2151			37
2.582700+4	5.000000-1	8.742000+0	8.700000+0	4.200000-2	0.000000+04249	2151			38
9.904922+1	0.000000+0	1	0	546	914249	2151			39
97.3400000	1.5	6.917000-2	1.700000-4	6.900000-2	0.000000+04249	2151			40
506.650000	0.5	9.400000-2	4.000000-3	9.000000-2	0.000000+04249	2151			41
535.800000	0.5	9.420000-2	4.200000-3	9.000000-2	0.000000+04249	2151			42
784.100000	0.5	9.500000-2	5.000000-3	9.000000-2	0.000000+04249	2151			43
1069.17000	1.5	1.340000-1	6.400000-2	7.000000-2	0.000000+04249	2151			44
1260.40000	1.5	1.160000-1	4.700000-2	6.900000-2	0.000000+04249	2151			45
1697.50000	1.5	2.190000-1	1.500000-1	6.900000-2	0.000000+04249	2151			46
1767.90000	0.5	3.100000-1	2.200000-1	9.000000-2	0.000000+04249	2151			47
2.066000+3	5.000000-1	8.650000-2	6.500000-3	8.000000-2	0.000000+04249	2151			48
2.425000+3	1.500000+0	3.160000-1	2.600000-1	5.600000-2	0.000000+04249	2151			49
2.671000+3	1.500000+0	7.200000-2	6.000000-3	6.600000-2	0.000000+04249	2151			50
2.962000+3	1.500000+0	1.058000-1	2.580000-2	8.000000-2	0.000000+04249	2151			51
3.078000+3	5.000000-1	2.110000-1	1.010000-1	1.100000-1	0.000000+04249	2151			52
3.269000+3	1.500000+0	1.729999-1	6.899990-2	1.040000-1	0.000000+04249	2151			53
3.547000+3	1.500000+0	1.150000-1	3.500000-2	8.000000-2	0.000000+04249	2151			54
3.557000+3	5.000000-1	1.720000-1	9.900000-2	7.300000-2	0.000000+04249	2151			55
3.613000+3	1.500000+0	1.410000-1	6.100000-2	8.000000-2	0.000000+04249	2151			56
4.165000+3	1.500000+0	1.070000-1	8.000000-3	9.900000-2	0.000000+04249	2151			57
4.559000+3	1.500000+0	1.765000-1	8.750000-2	8.900000-2	0.000000+04249	2151			58
4.788000+3	5.000000-1	1.120000-1	1.500000-2	9.700000-2	0.000000+04249	2151			59
5.250000+3	5.000000-1	1.430000-1	6.300000-2	8.000000-2	0.000000+04249	2151			60
5.732000+3	5.000000-1	9.930000-2	1.930000-2	8.000000-2	0.000000+04249	2151			61
6.005000+3	5.000000-1	7.210000-1	6.600000-1	6.100000-2	0.000000+04249	2151			62
6.126000+3	1.500000+0	2.500000-1	1.750000-1	7.500000-2	0.000000+04249	2151			63



6.393000+3	1.500000+0	3.550000-1	2.750000-1	8.000000-2	0.000000+04249	2151	64
6.690000+3	1.500000+0	2.200000-1	1.400000-1	8.000000-2	0.000000+04249	2151	65
7.095000+3	1.500000+0	2.170000-1	1.380000-1	7.900000-2	0.000000+04249	2151	66
7.628000+3	5.000000-1	2.420000-1	1.620000-1	8.000000-2	0.000000+04249	2151	67
7.642000+3	5.000000-1	3.490000-1	2.690000-1	8.000000-2	0.000000+04249	2151	68
7.703000+3	5.000000-1	1.064000+0	1.000000+0	6.400000-2	0.000000+04249	2151	69
7.940000+3	1.500000+0	1.670000-1	1.050000-1	6.200000-2	0.000000+04249	2151	70
8.215000+3	1.500000+0	2.060000-1	1.170000-1	8.900000-2	0.000000+04249	2151	71
9.008000+3	1.500000+0	6.280000-1	5.500000-1	7.800000-2	0.000000+04249	2151	72
9.253000+3	5.000000-1	1.120000-1	3.200000-2	8.000000-2	0.000000+04249	2151	73
9.610000+3	1.500000+0	2.800000-1	2.050000-1	7.500000-2	0.000000+04249	2151	74
9.833000+3	5.000000-1	2.830000-1	2.100000-1	7.300000-2	0.000000+04249	2151	75
9.943000+3	5.000000-1	1.480000-1	6.800000-2	8.000000-2	0.000000+04249	2151	76
1.021000+4	1.500000+0	8.840000-1	8.250000-1	5.900000-2	0.000000+04249	2151	77
1.042000+4	1.500000+0	1.950000-1	1.380000-1	5.700000-2	0.000000+04249	2151	78
1.064800+4	5.000000-1	7.310000-1	6.700000-1	6.100000-2	0.000000+04249	2151	79
1.094000+4	1.500000+0	2.350000-1	1.650000-1	7.000000-2	0.000000+04249	2151	80
1.105500+4	1.500000+0	1.950000-1	1.030000-1	9.200000-2	0.000000+04249	2151	81
1.159300+4	5.000000-1	4.110000-1	3.350000-1	7.600000-2	0.000000+04249	2151	82
1.172800+4	5.000000-1	2.975000+0	2.900000+0	7.500000-2	0.000000+04249	2151	83
1.215200+4	5.000000-1	4.570000-1	3.770000-1	8.000000-2	0.000000+04249	2151	84
1.246300+4	5.000000-1	3.283000+0	3.200000+0	8.300000-2	0.000000+04249	2151	85
1.256800+4	5.000000-1	3.120000-1	2.200000-1	9.200000-2	0.000000+04249	2151	86
1.264200+4	5.000000-1	2.280000-1	1.900000-1	3.800000-2	0.000000+04249	2151	87
1.268800+4	5.000000-1	6.740000-1	5.800000-1	9.400000-2	0.000000+04249	2151	88
1.272500+4	1.500000+0	2.440000-1	1.650000-1	7.900000-2	0.000000+04249	2151	89
1.306000+4	5.000000-1	7.380000-1	6.700000-1	6.800000-2	0.000000+04249	2151	90
1.342900+4	1.500000+0	1.710000-1	9.100000-2	8.000000-2	0.000000+04249	2151	91
1.354500+4	1.500000+0	2.980000+0	2.900000+0	8.000000-2	0.000000+04249	2151	92
1.394100+4	5.000000-1	6.430000-1	5.700000-1	7.300000-2	0.000000+04249	2151	93
1.420300+4	5.000000-1	1.048000+0	9.900000-1	5.800000-2	0.000000+04249	2151	94
1.526100+4	1.500000+0	2.310000-1	1.580000-1	7.300000-2	0.000000+04249	2151	95
1.534600+4	1.500000+0	2.455000+0	2.375000+0	8.000000-2	0.000000+04249	2151	96
1.558100+4	5.000000-1	4.000000-1	3.200000-1	8.000000-2	0.000000+04249	2151	97
1.575700+4	1.500000+0	4.570000-1	3.680000-1	8.900000-2	0.000000+04249	2151	98
1.589800+4	1.500000+0	2.560000+0	2.500000+0	6.000000-2	0.000000+04249	2151	99
1.601700+4	1.500000+0	4.350000-1	3.550000-1	8.000000-2	0.000000+04249	2151	100
1.647000+4	5.000000-1	5.891000+0	5.800000+0	9.100000-2	0.000000+04249	2151	101
1.680000+4	1.500000+0	6.770000-1	5.900000-1	8.700000-2	0.000000+04249	2151	102
1.713200+4	1.500000+0	5.500000-1	4.500000-1	1.000000-1	0.000000+04249	2151	103
1.752500+4	1.500000+0	3.220000-1	2.250000-1	9.700000-2	0.000000+04249	2151	104
1.800900+4	1.500000+0	6.400000-1	5.600000-1	8.000000-2	0.000000+04249	2151	105
1.864500+4	1.500000+0	4.300000-1	3.500000-1	8.000000-2	0.000000+04249	2151	106
1.906400+4	1.500000+0	1.620000-1	8.200000-2	8.000000-2	0.000000+04249	2151	107
1.966300+4	1.500000+0	3.930000-1	2.850000-1	1.080000-1	0.000000+04249	2151	108
1.989500+4	1.500000+0	2.333000+0	2.200000+0	1.330000-1	0.000000+04249	2151	109
2.014700+4	1.500000+0	1.660000-1	8.600000-2	8.000000-2	0.000000+04249	2151	110
2.056300+4	5.000000-1	1.160000-1	3.600000-2	8.000000-2	0.000000+04249	2151	111
2.067200+4	5.000000-1	1.420000-1	6.200000-2	8.000000-2	0.000000+04249	2151	112
2.087700+4	1.500000+0	1.332000+0	1.245000+0	8.700000-2	0.000000+04249	2151	113
2.121300+4	1.500000+0	3.302000+0	3.200000+0	1.020000-1	0.000000+04249	2151	114
2.157100+4	1.500000+0	6.630000+0	6.500000+0	1.300000-1	0.000000+04249	2151	115
2.181000+4	1.500000+0	1.520000+0	1.410000+0	1.100000-1	0.000000+04249	2151	116
2.223200+4	1.500000+0	4.570000-1	3.770000-1	8.000000-2	0.000000+04249	2151	117
2.296000+4	1.500000+0	3.016000+0	2.900000+0	1.160000-1	0.000000+04249	2151	118
2.315300+4	1.500000+0	2.077000+0	2.000000+0	7.700000-2	0.000000+04249	2151	119
2.352100+4	5.000000-1	3.560000-1	2.760000-1	8.000000-2	0.000000+04249	2151	120
2.359400+4	5.000000-1	1.520000-1	7.200000-2	8.000000-2	0.000000+04249	2151	121
2.391400+4	5.000000-1	1.360000-1	5.600000-2	8.000000-2	0.000000+04249	2151	122
2.423500+4	1.500000+0	2.030000-1	1.230000-1	8.000000-2	0.000000+04249	2151	123
2.434100+4	5.000000-1	2.946000+0	2.900000+0	4.600000-2	0.000000+04249	2151	124
2.443800+4	1.500000+0	2.310000+0	2.200000+0	1.100000-1	0.000000+04249	2151	125
2.498200+4	1.500000+0	2.021000+0	1.950000+0	7.100000-2	0.000000+04249	2151	126
2.522200+4	1.500000+0	5.560000-1	4.700000-1	8.600000-2	0.000000+04249	2151	127
2.574000+4	1.500000+0	4.340000+0	4.250000+0	9.000000-2	0.000000+04249	2151	128
2.597500+4	1.500000+0	5.302000+0	5.200000+0	1.020000-1	0.000000+04249	2151	129

2.616500+4	1.500000+0	7.720000-1	7.000000-1	7.200000-2	0.000000+04249	2151	130
2.600000+4	1.000000+6	2	2	0	04249	2151	131
0.000000+0	6.098900-1	1	0	3	04249	2151	132
9.904922+1	0.000000+0	0	0	1	04249	2151	133
5.000000-1	0.000000+0	5	0	114	184249	2151	134
0.000000+0	0.000000+0	1.000000+0	1.000000+0	0.000000+0	0.000000+04249	2151	135
2.600000+4	6.170000+2	0.000000+0	3.948800-2	6.400000-2	0.000000+04249	2151	136
3.000000+4	6.170000+2	0.000000+0	3.948800-2	6.400000-2	0.000000+04249	2151	137
4.000000+4	6.170000+2	0.000000+0	3.948800-2	6.400000-2	0.000000+04249	2151	138
5.000000+4	6.170000+2	0.000000+0	3.948800-2	6.400000-2	0.000000+04249	2151	139
6.000000+4	6.170000+2	0.000000+0	3.948800-2	6.400000-2	0.000000+04249	2151	140
7.000000+4	6.170000+2	0.000000+0	3.948800-2	6.400000-2	0.000000+04249	2151	141
8.000000+4	6.170000+2	0.000000+0	3.948800-2	6.400000-2	0.000000+04249	2151	142
9.000000+4	6.170000+2	0.000000+0	3.948800-2	6.400000-2	0.000000+04249	2151	143
1.000000+5	6.170000+2	0.000000+0	3.948800-2	6.400000-2	0.000000+04249	2151	144
2.000000+5	4.356300+2	0.000000+0	2.788000-2	6.400000-2	0.000000+04249	2151	145
3.000000+5	3.221600+2	0.000000+0	2.061900-2	6.400000-2	0.000000+04249	2151	146
4.000000+5	2.470800+2	0.000000+0	1.581300-2	6.400000-2	0.000000+04249	2151	147
5.000000+5	1.955200+2	0.000000+0	1.251300-2	6.400000-2	0.000000+04249	2151	148
6.000000+5	2.083400+2	1.196100-2	1.333400-2	6.400000-2	0.000000+04249	2151	149
7.000000+5	1.853900+2	1.181900-1	1.186500-2	6.400000-2	0.000000+04249	2151	150
8.000000+5	1.548900+2	3.411900+0	9.913200-3	6.400000-2	0.000000+04249	2151	151
9.000000+5	1.270800+2	4.152800+0	8.133400-3	6.400000-2	0.000000+04249	2151	152
1.000000+6	1.039900+2	4.382000+0	6.655400-3	6.400000-2	0.000000+04249	2151	153
9.904922+1	0.000000+0	1	0	2	04249	2151	154
5.000000-1	0.000000+0	5	0	114	184249	2151	155
0.000000+0	0.000000+0	2.000000+0	1.000000+0	0.000000+0	0.000000+04249	2151	156
2.600000+4	6.170000+2	0.000000+0	3.171400-1	9.300000-2	0.000000+04249	2151	157
3.000000+4	6.170000+2	0.000000+0	3.171400-1	9.300000-2	0.000000+04249	2151	158
4.000000+4	6.170000+2	0.000000+0	3.171400-1	9.300000-2	0.000000+04249	2151	159
5.000000+4	6.170000+2	0.000000+0	3.171400-1	9.300000-2	0.000000+04249	2151	160
6.000000+4	6.170000+2	0.000000+0	3.171400-1	9.300000-2	0.000000+04249	2151	161
7.000000+4	6.170000+2	0.000000+0	3.171400-1	9.300000-2	0.000000+04249	2151	162
8.000000+4	6.170000+2	0.000000+0	3.171400-1	9.300000-2	0.000000+04249	2151	163
9.000000+4	6.170000+2	0.000000+0	3.171400-1	9.300000-2	0.000000+04249	2151	164
1.000000+5	6.170000+2	0.000000+0	3.171400-1	9.300000-2	0.000000+04249	2151	165
2.000000+5	4.356300+2	0.000000+0	2.239100-1	9.300000-2	0.000000+04249	2151	166
3.000000+5	3.221600+2	0.000000+0	1.655900-1	9.300000-2	0.000000+04249	2151	167
4.000000+5	2.470800+2	0.000000+0	1.270000-1	9.300000-2	0.000000+04249	2151	168
5.000000+5	1.955200+2	0.000000+0	1.005000-1	9.300000-2	0.000000+04249	2151	169
6.000000+5	2.083400+2	2.738000+0	1.070900-1	9.300000-2	0.000000+04249	2151	170
7.000000+5	1.853900+2	9.144400+0	9.529300-2	9.300000-2	0.000000+04249	2151	171
8.000000+5	1.548900+2	1.785900+1	7.961500-2	9.300000-2	0.000000+04249	2151	172
9.000000+5	1.270800+2	2.454000+1	6.532100-2	9.300000-2	0.000000+04249	2151	173
1.000000+6	1.039900+2	2.816600+1	5.345100-2	9.300000-2	0.000000+04249	2151	174
1.500000+0	0.000000+0	5	0	114	184249	2151	175
0.000000+0	0.000000+0	2.000000+0	1.000000+0	0.000000+0	0.000000+04249	2151	176
2.600000+4	3.085000+2	0.000000+0	1.585700-1	9.300000-2	0.000000+04249	2151	177
3.000000+4	3.085000+2	0.000000+0	1.585700-1	9.300000-2	0.000000+04249	2151	178
4.000000+4	3.085000+2	0.000000+0	1.585700-1	9.300000-2	0.000000+04249	2151	179
5.000000+4	3.085000+2	0.000000+0	1.585700-1	9.300000-2	0.000000+04249	2151	180
6.000000+4	3.085000+2	0.000000+0	1.585700-1	9.300000-2	0.000000+04249	2151	181
7.000000+4	3.085000+2	0.000000+0	1.585700-1	9.300000-2	0.000000+04249	2151	182
8.000000+4	3.085000+2	0.000000+0	1.585700-1	9.300000-2	0.000000+04249	2151	183
9.000000+4	3.085000+2	0.000000+0	1.585700-1	9.300000-2	0.000000+04249	2151	184
1.000000+5	3.085000+2	0.000000+0	1.585700-1	9.300000-2	0.000000+04249	2151	185
2.000000+5	2.178100+2	0.000000+0	1.119600-1	9.300000-2	0.000000+04249	2151	186
3.000000+5	1.610800+2	0.000000+0	8.279600-2	9.300000-2	0.000000+04249	2151	187
4.000000+5	1.235400+2	0.000000+0	6.350000-2	9.300000-2	0.000000+04249	2151	188
5.000000+5	9.776100+1	0.000000+0	5.024900-2	9.300000-2	0.000000+04249	2151	189
6.000000+5	1.041700+2	2.738000+0	5.354400-2	9.300000-2	0.000000+04249	2151	190
7.000000+5	9.269700+1	9.144400+0	4.764600-2	9.300000-2	0.000000+04249	2151	191
8.000000+5	7.744700+1	1.582700+1	3.980800-2	9.300000-2	0.000000+04249	2151	192
9.000000+5	6.354200+1	2.043200+1	3.266100-2	9.300000-2	0.000000+04249	2151	193
1.000000+6	5.199500+1	2.273300+1	2.672600-2	9.300000-2	0.000000+04249	2151	194
9.904922+1	0.000000+0	2	0	2	04249	2151	195

1.500000+0	0.000000+0		5	0	114	184249	2151	196
0.000000+0	0.000000+0	1.000000+0	1.000000+0	0.000000+0	0.000000+04249	2151	197	
2.600000+4	3.085000+2	0.000000+0	2.468000-2	6.400000-2	0.000000+04249	2151	198	
3.000000+4	3.085000+2	0.000000+0	2.468000-2	6.400000-2	0.000000+04249	2151	199	
4.000000+4	3.085000+2	0.000000+0	2.468000-2	6.400000-2	0.000000+04249	2151	200	
5.000000+4	3.085000+2	0.000000+0	2.468000-2	6.400000-2	0.000000+04249	2151	201	
6.000000+4	3.085000+2	0.000000+0	2.468000-2	6.400000-2	0.000000+04249	2151	202	
7.000000+4	3.085000+2	0.000000+0	2.468000-2	6.400000-2	0.000000+04249	2151	203	
8.000000+4	3.085000+2	0.000000+0	2.468000-2	6.400000-2	0.000000+04249	2151	204	
9.000000+4	3.085000+2	0.000000+0	2.468000-2	6.400000-2	0.000000+04249	2151	205	
1.000000+5	3.085000+2	0.000000+0	2.468000-2	6.400000-2	0.000000+04249	2151	206	
2.000000+5	2.178100+2	0.000000+0	1.742500-2	6.400000-2	0.000000+04249	2151	207	
3.000000+5	1.610800+2	0.000000+0	1.288700-2	6.400000-2	0.000000+04249	2151	208	
4.000000+5	1.235400+2	0.000000+0	9.883200-3	6.400000-2	0.000000+04249	2151	209	
5.000000+5	9.776100+1	0.000000+0	7.820800-3	6.400000-2	0.000000+04249	2151	210	
6.000000+5	1.041700+2	1.625700+0	8.333700-3	6.400000-2	0.000000+04249	2151	211	
7.000000+5	9.269700+1	2.424900+0	7.415800-3	6.400000-2	0.000000+04249	2151	212	
8.000000+5	7.744700+1	2.685700+0	6.195700-3	6.400000-2	0.000000+04249	2151	213	
9.000000+5	6.354200+1	2.738200+0	5.083400-3	6.400000-2	0.000000+04249	2151	214	
1.000000+6	5.199500+1	2.701300+0	4.159600-3	6.400000-2	0.000000+04249	2151	215	
2.500000+0	0.000000+0		5	0	114	184249	2151	216
0.000000+0	0.000000+0	1.000000+0	1.000000+0	0.000000+0	0.000000+04249	2151	217	
2.600000+4	2.056700+2	0.000000+0	1.645300-2	6.400000-2	0.000000+04249	2151	218	
3.000000+4	2.056700+2	0.000000+0	1.645300-2	6.400000-2	0.000000+04249	2151	219	
4.000000+4	2.056700+2	0.000000+0	1.645300-2	6.400000-2	0.000000+04249	2151	220	
5.000000+4	2.056700+2	0.000000+0	1.645300-2	6.400000-2	0.000000+04249	2151	221	
6.000000+4	2.056700+2	0.000000+0	1.645300-2	6.400000-2	0.000000+04249	2151	222	
7.000000+4	2.056700+2	0.000000+0	1.645300-2	6.400000-2	0.000000+04249	2151	223	
8.000000+4	2.056700+2	0.000000+0	1.645300-2	6.400000-2	0.000000+04249	2151	224	
9.000000+4	2.056700+2	0.000000+0	1.645300-2	6.400000-2	0.000000+04249	2151	225	
1.000000+5	2.056700+2	0.000000+0	1.645300-2	6.400000-2	0.000000+04249	2151	226	
2.000000+5	1.452100+2	0.000000+0	1.161700-2	6.400000-2	0.000000+04249	2151	227	
3.000000+5	1.073900+2	0.000000+0	8.591000-3	6.400000-2	0.000000+04249	2151	228	
4.000000+5	8.236000+1	0.000000+0	6.588800-3	6.400000-2	0.000000+04249	2151	229	
5.000000+5	6.517400+1	0.000000+0	5.213900-3	6.400000-2	0.000000+04249	2151	230	
6.000000+5	6.944800+1	1.083800+0	5.555800-3	6.400000-2	0.000000+04249	2151	231	
7.000000+5	6.179800+1	1.616600+0	4.943800-3	6.400000-2	0.000000+04249	2151	232	
8.000000+5	5.163100+1	1.790400+0	4.130500-3	6.400000-2	0.000000+04249	2151	233	
9.000000+5	4.236100+1	1.825400+0	3.388900-3	6.400000-2	0.000000+04249	2151	234	
1.000000+6	3.466400+1	1.800800+0	2.773100-3	6.400000-2	0.000000+04249	2151	235	

4249 2 099999

Covariance Data

						4249 0 0	0
42100.0	9.904900+1	0	0	1		0424932151	1
42100.0	1.000000+0	0	0	1		0424932151	2
7.100000-4	2.600000+4	1	2	0		1424932151	3
0.0	7.000000-1	0	1	0		0424932151	4
9.904900+1		0	0	1		0424932151	5
		3	0	102		4424932151	6
363.9240000	0.5	6.600000-1	6.040000-1	5.600000-2		424932151	7
97.34000000	1.5	6.917000-2	1.700000-4	6.900000-2		424932151	8
506.6500000	0.5	9.400000-2	4.000000-3	9.000000-2		424932151	9
535.8000000	0.5	9.420000-2	4.200000-3	9.000000-2		424932151	10
4.834522-3-4.401830-3		1.491826-4-2.146813-8-8.78980-10-2.260652-6424932151					11
-1.132884-6-1.806972-8-1.656223-6-1.788445-7-2.169003-8-1.869683-6424932151							12
2.187687-2-9.529179-4 1.070238-7 5.124209-9 1.318419-5 6.310032-6424932151							13
1.058294-7 9.465043-6 1.056387-6 1.264471-7 1.064869-5 8.222799-5424932151							14
-7.049966-9 2.12517-11-8.068154-8-2.436665-7 1.082288-9-1.227878-7424932151							15
-7.218213-8 8.75437-10-1.374294-7 3.245107-4-2.99775-11-1.515893-5424932151							16
5.800840-8-3.95665-10 2.167252-8 7.115155-9-3.66387-10 2.779656-8424932151							17
1.43184-10 3.408594-7 3.99312-11 1.51721-11 7.44282-10-1.25865-11424932151							18
1.68999-11 8.12526-10 1.895557-3 6.072063-7 3.192603-8 1.936828-6424932151							19
2.575248-7 3.636542-8 2.088879-6 1.288039-2-7.379047-6-4.548548-4424932151							20
4.297072-7-6.32978-10 1.426970-6 1.602073-7-2.855093-6-1.512474-9424932151							21
4.00363-10 1.643636-8 7.612046-3 2.369448-7 1.837105-8 1.766583-6424932151							22
1.071359-2-1.998574-6-1.034379-4 1.520005-7-5.151280-6 7.583320-3424932151							23





0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	131
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	132
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	133
0.000000+0	0.000000+0	8.115848-3	0.000000+0	0.000000+0	0.000000+0424933	1	134
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	135
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	136
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	137
8.137303-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	138
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	139
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	140
0.000000+0	0.000000+0	0.000000+0	8.154271-3	0.000000+0	0.000000+0424933	1	141
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	142
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	143
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	8.169629-3424933	1	144
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	145
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	146
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	147
8.198759-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	148
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	149
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	150
7.910324-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	151
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	152
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	153
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	154
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	155
0.000000+0	0.000000+0	0.000000+0	9.410783-4	0.000000+0	0.000000+0424933	1	156
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	157
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	158
6.472363-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	159
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	1	160
0.000000+0	0.000000+0	7.325648-3	4.724568-3	4.758804-3	4.724568-3424933	1	161
4.741686-3	4.707450-3	4.707450-3	4.741001-3	4.793040-3	4.861512-3424933	1	162
4.724568-3	4.793211-3	4.947102-3	3.047040-3	3.069120-3	3.047040-3424933	1	163
3.058080-3	3.036000-3	3.036000-3	3.057638-3	3.091200-3	3.135360-3424933	1	164
3.047040-3	3.091310-3	3.190560-3	3.091360-3	3.069120-3	3.080240-3424933	1	165
3.058000-3	3.058000-3	3.079795-3	3.113600-3	3.158080-3	3.069120-3424933	1	166
3.113711-3	3.213680-3	3.047040-3	3.058080-3	3.036000-3	3.036000-3424933	1	167
3.057638-3	3.091200-3	3.135360-3	3.047040-3	3.091310-3	3.190560-3424933	1	168
3.069160-3	3.047000-3	3.047000-3	3.068717-3	3.102400-3	3.146720-3424933	1	169
3.058080-3	3.102511-3	3.202120-3	3.025000-3	3.025000-3	3.046560-3424933	1	170
3.080000-3	3.124000-3	3.036000-3	3.080110-3	3.179000-3	3.025000-3424933	1	171
3.046560-3	3.080000-3	3.124000-3	3.036000-3	3.080110-3	3.179000-3424933	1	172
3.068274-3	3.101952-3	3.146266-3	3.057638-3	3.102063-3	3.201658-3424933	1	173
3.136000-3	3.180800-3	3.091200-3	3.136112-3	3.236800-3	3.226240-3424933	1	174
3.135360-3	3.180914-3	3.283040-3	3.047040-3	3.091310-3	3.190560-3424933	1	175
3.136224-3	3.236916-3	3.340840-3	0.000000+0	0.000000+0	0.000000+0424933	1	176
0.000000+0	0.000000+0	0	0	0	0424933	099999	
4.210000+4	9.904900+1	0	0	0	1424933	2	1
0.000000+0	0.000000+0	0	2	0	1424933	2	2
0.000000+0	0.000000+0	1	5	1035	45424933	2	3
1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000-2424933	2	4
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000-1424933	2	5
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000-1424933	2	6
4.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000+0424933	2	7
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000+2424933	2	8
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000+5424933	2	9
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000+6424933	2	10
6.434000+6	8.187300+6	2.000000+7	7.116090-4	0.000000+0	0.000000+0424933	2	11
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	2	12
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	2	13
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	2	14
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	2	15
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	2	16
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	2	17
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	6.486700-4424933	2	18
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	2	19



[illegible]



0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	2	152
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	2	153
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	2	154
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	2	155
0.000000+0	0.000000+0	0.000000+0	1.070533-3	0.000000+0	0.000000+0424933	2	156
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	2	157
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	2	158
7.568826-3	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	2	159
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933	2	160
0.000000+0	0.000000+0	7.569000-3	6.281400-3	5.707200-3	5.881200-3424933	2	161
6.768600-3	7.586400-3	8.473800-3	9.569130-3	1.141440-2	1.282380-2424933	2	162
1.296300-2	1.186593-2	1.131000-2	5.212840-3	4.736320-3	4.880720-3424933	2	163
5.617160-3	6.295840-3	7.032280-3	7.941278-3	9.472640-3	1.064228-2424933	2	164
1.052780-2	9.847358-3	9.386000-3	4.303360-3	4.434560-3	5.103680-3424933	2	165
5.720320-3	6.389440-3	7.215344-3	8.606720-3	9.669440-3	9.774400-3424933	2	166
8.947184-3	8.528000-3	4.569760-3	5.259280-3	5.894720-3	6.584240-3424933	2	167
7.435324-3	8.869120-3	9.964240-3	1.007240-2	9.219964-3	8.788000-3424933	2	168
6.052840-3	6.784160-3	7.577720-3	8.557222-3	1.020736-2	1.146772-2424933	2	169
1.159220-2	1.061114-2	1.011400-2	7.603840-3	8.493280-3	9.591128-3424933	2	170
1.144064-2	1.285328-2	1.299280-2	1.189321-2	1.133600-2	9.486760-3424933	2	171
1.071303-2	1.277888-2	1.435676-2	1.451260-2	1.328439-2	1.266200-2424933	2	172
1.209780-2	1.443069-2	1.621253-2	1.638851-2	1.500154-2	1.429870-2424933	2	173
1.721344-2	1.933888-2	1.954880-2	1.789437-2	1.705600-2	2.172676-2424933	2	174
2.196260-2	2.010389-2	1.916200-2	2.220100-2	2.032211-2	1.937000-2424933	2	175
1.860223-2	1.773070-2	1.690000-2	0.000000+0	0.000000+0	0.000000+0424933	2	176
0.000000+0	0.000000+0	0	0	0	0424933	099999	
4.210000+4	9.904900+1	0	0	0	1424933102	1	
0.000000+0	0.000000+0	0	102	0	1424933102	2	
0.000000+0	0.000000+0	1	5	1035	45424933102	3	
1.000000-5	3.000000-3	7.500000-3	1.000000-2	2.530000-2	3.000000-2424933102	4	
4.000000-2	5.000000-2	7.000000-2	1.000000-1	1.500000-1	2.000000-1424933102	5	
2.250000-1	2.500000-1	2.750000-1	3.250000-1	3.500000-1	3.750000-1424933102	6	
4.000000-1	6.250000-1	1.000000+0	1.770000+0	3.000000+0	4.750000+0424933102	7	
6.000000+0	8.100000+0	1.000000+1	3.000000+1	1.000000+2	5.500000+2424933102	8	
3.000000+3	1.700000+4	2.500000+4	1.000000+5	4.000000+5	9.000000+5424933102	9	
1.400000+6	1.850000+6	2.354000+6	2.479000+6	3.000000+6	4.800000+6424933102	10	
6.434000+6	8.187300+6	2.000000+7	0.000000+0	0.000000+0	0.000000+0424933102	11	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	12	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	13	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	14	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	15	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	16	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	17	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	18	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	19	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	20	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	21	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	22	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	23	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	24	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	25	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	26	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	27	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	28	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	29	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	30	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	31	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	32	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	33	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	34	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	35	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	36	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	37	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	38	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	39	
0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0	0.000000+0424933102	40	

[illegible]

[illegible]

8.872133-3	8.854048-3	9.287331-3	1.305501-2	1.668988-2	4.055908-2424933102	173
8.836000-3	9.268400-3	1.302840-2	1.665586-2	4.047640-2	9.721960-3424933102	174
1.366596-2	1.747093-2	4.245716-2	1.920996-2	2.455853-2	5.968116-2424933102	175
3.139630-2	7.629801-2	1.854164-1	0.000000+0	0.000000+0	0.000000+0424933102	176
0.000000+0	0.000000+0	0	0	0	0424933	099999

## References

- [1] M. WILLIAMS, *et al*, “SCALE-6 Sensitivity/Uncertainty Methods and Covariance Data,” Nuclear Data Sheets 109, 2008
- [2] V. MCLANE, *et al*, “ENDF-102 Data Formats and Procedures for the Evaluated Nuclear Data File ENDF-6,” National Nuclear Data Center, Brookhaven National Laboratory, April 2001
- [3] M. HERMAN, *et al*, “ENDF-6 Formats Manual,” National Nuclear Data Center, Brookhaven National Laboratory, July 2010
- [4] N. LARSON, “A Concise Method for Storing and Communicating the Data Covariance Matrix,” Oak Ridge National Laboratory, ORNL/TM-2008/104, August 2008
- [5] O. IWAMOTO, *et al*, “Covariance Evaluation for Actinide Nuclear Data in JENDL-4,” Journal of the Korean Physical Society, Vol. 59, No. 2, August 2011
- [6] R. LITTLE, *et al*, “Low-Fidelity Covariance Project,” Nuclear Data Sheets 109, 2008
- [7] R. DUNAVANT, *et al*, “Uranium-Molybdenum Fuel Foil Fabrication Development Activities at the Y-12 National Security Complex,” Y-12 National Security Complex, International RERTR Meeting, 2006
- [8] M. DEHART, *et al*, “Evaluation of Core Physics Analysis Methods for Conversion of the INL Advanced Test Reactor to Low Enrichment Fuel,” Idaho National Laboratory, PHYSOR 2012, April 2012
- [9] A. M. LANE, *et al*, “R-Matrix Theory of Nuclear Reactions,” Reviews of Modern Physics, Volume 30, Number 2, Part I, April 1958
- [10] L. LEAL, “Brief Review of the R-Matrix Theory,” MIT OpenCourseWare, Neutron Interactions and Applications, Spring 2010

- [11] L. LEAL, "An Overview of the Methodologies for Cross Section Evaluation in the Resonance Region," Nuclear Data Symposium for Criticality Safety and Reactor Applications, April 2011
- [12] N.M. LARSON, *et al*, "A Systematic Description of the Generation of Covariance Matrices," Oak Ridge National Laboratory, PHYSOR 2006, September 2006
- [13] L.LEAL, *et al*, "ORNL Resolved Resonance Covariance Generation for ENDF/B-VII.1," Oak Ridge National Laboratory, Nuclear Data Sheets, September 2012
- [14] F.H. FROHNER, "Evaluation and Analysis of Nuclear Resonance Data," Nuclear Energy Agency, JEFF Report 18, 2000
- [15] G. ARBANAS, *et al*, "Retroactive Covariance Matrix for  $^{235}\text{U}$  in the Resolved-Resonance Region," Oak Ridge National Laboratory, PHYSOR 2006, September 2006
- [16] "RSICC Peripheral Shielding Routine Collection NJOY99.0," Oak Ridge National Laboratory, PSR-480, March 2000
- [17] D. CULLEN, "PREPRO 2010: 2010 ENDF/B Pre-processing Codes (ENDF/B-VII Tested)," The Nuclear Data Section, International Atomic Energy Agency, IAEA-NDS-39, October 2010
- [18] HPRR STAFF, "Operating Manual for the Health Physics Research Reactor," Oak Ridge National Laboratory, ORNL/TM-9870, November 1985
- [19] OPERATIONS DIVISION STAFF, "Technical Specifications Health Physics Research Reactor," Oak Ridge National Laboratory, ORNL/TM-4637/R1, March 1986
- [20] "International Handbook of Evaluated Criticality Safety Benchmark Experiments," Nuclear Energy Agency, Nuclear Science, September 2010

- [21] B. REARDEN, et al, "TSUNAMI Primer: A Primer for Sensitivity/Uncertainty Calculations with SCALE," Oak Ridge National Laboratory, ORNL/TM-2009/027, January 2009
- [22] M. WILLIAMS, et al, "An Adjustment Code to Determine Biases and Uncertainties in Nuclear System Responses by Consolidating Differential Data and Benchmark Integral Experiments, Office of Nuclear Material Safety and Safeguards, December 2006
- [23] S. BRAGG-SITTON, *et al*, "Reactor Testing and Qualification: Prioritized High-Level Criticality Testing Needs, "Idaho National Laboratory, INL/EXT-11-22725, September 2011
- [24] "Detailed Description of Alternatives," Draft Site-Wide Environmental Impact Statement for the Continued Operation of the Department of Energy/National Nuclear Security Administration Nevada National Security Site and Off-Site Locations in the State of Nevada, July 2011
- [25] R. SANCHEZ, *et al*, "Critical Mass Experiment Using U-235 Foils and Lucite Plates," Los Alamos National Laboratory, LA-UR-98-597, July 1998
- [26] "MCNP A General Monte Carlo N-Particle Transport Code, Version 5," Los Alamos National Laboratory, LA-CP-03-0245, April 2003
- [27] "Getting Started with SCALE 6 for Windows XP and Vista Rev. 2," RSICC code package C00750/MNYCP/00, March 2009
- [28] R. WILLIAMS III, *et al*, "Compendium of Material Composition Data for Radiation Transport Modeling," Pacific Northwest National Laboratory, PNNL-15870, April 2006
- [29] B. REARDEN, *et al*, "Bias Assessment of  $^{233}\text{U}$  Systems Using SCALE TSURFER," Trans. Am. Nucl. Soc. 102, 307-311, 2010
- [30] "MCNPX User's Manual v2.6.0", Los Alamos National Laboratory, LA-CP-07-1473, April

2008

- [31] R. MOSTELLER, *et al*, “The Initial Set of Zeus Experiments: Intermediate-Spectrum Critical Assemblies with a Graphite-HEU Core Surrounded by a Copper Reflector,” International Handbook of Evaluated Criticality Safety Benchmark Experiments, HEU-MET-INTER-006
- [32] D. LOAIZA, *et al*, “Polyethylene Reflected and Moderated Highly Enriched Uranium System with Aluminum,” International Handbook of Evaluated Criticality Safety Benchmark Experiments, HEU-MET-THERM-008
- [33] R. BREWER, *et al*, “Polyethylene Reflected and Moderated Highly Enriched Uranium System with Silicon,” International Handbook of Evaluated Criticality Safety Benchmark Experiments, HEU-MET-THERM-001
- [34] G. LEINWEBER, *et al*, “Resonance Parameters and Uncertainties Derived from Epithermal Neutron Capture and Transmission Measurements of Natural Molybdenum,” Nuclear Science and Engineering, Issue 164, August 2009
- [35] M. B. CHADWICK, *et al*, “ENDF/B-VII.1 Nuclear Data for Science and Technology: Cross Sections, Covariances, Fission Product Yields and Decay Data,” Los Alamos National Laboratory, Nuclear Data Sheets 112, 2011
- [36] D. SMITH, “Quality Assurance for ENDF/B-VII.1 Covariances,” Argonne National Laboratory, 2010 CSEWG Meeting, Santa Fe, NM
- [37] S. F. MUGHABGHAB, “Atlas of Neutron Resonances, Fifth Edition,” Elsevier Press, 2006
- [38] C. M. MATTOON, *et al*, “Issues in Neutron Cross Section Covariances,” NNDC, Brookhaven National Laboratory, Journal of the Korean Physical Society, Vol. 59, No. 2, August 2011



- [39] M. HERMAN, *et al*, “COMMARA-2.0 Neutron Cross Section Covariance Library,” Brookhaven National Laboratory, BNL-94830-2011, March 2011
- [40] M. HERMAN, “Covariance Evaluation Methodology for Neutron Cross Sections,” Brookhaven National Laboratory, BNL-81623-2008, September 2008
- [41] T. KAWANO, “How Does KALMAN Work?,” Los Alamos National Laboratory, Cross Section Evaluation Working Group Meeting, November 2007
- [42] N. M. LARSON, “Updated Users’ Guide for SAMMY: Multilevel R-Matrix Fits to Neutron Data Using Bayes’ Equations,” ORNL/TM-9179/R6, Oak Ridge National Laboratory, July 2003
- [43] R. E. MACFARLANE, “RSICC Peripheral Shielding Routine Collection NJOY99.0,” Oak Ridge National Laboratory, PSR-480 NJOY99.0, March 2000
- [44] D. WIARDA, “RSICC Peripheral Science Routine Collection AMPX-6,” Oak Ridge National Laboratory, PSR-562, October 2010
- [45] G. LEINWEBER, *et al*, “Resonance Parameters and Uncertainties Derived from Epithermal Neutron Capture and Transmission Measurements of Natural Molybdenum,” Nuclear Science and Engineering, Issue 164, August 2009
- [46] G. LEINWEBER, *et al*, “Neutron Cross Section Measurements of Elemental Molybdenum and Resonance Parameter Analysis,” International Conference on Nuclear Data for Science and Technology, 2007
- [47] P. SCHILLEBEECKX, *et al*, “Determination of Resonance Parameters and their Covariances from Neutron Induced Reaction Cross Section Data,” Nuclear Data Sheets Issue 113, 2012
- [48] L. LEAL, *et al*, “ORNL Resolved Resonance Covariance Generation for ENDF/B-VII.1,” Oak Ridge National Laboratory, Nuclear Data Sheets, September 2012

- [49] G. ARBANAS, *et al*, “Retroactive Covariance Matrix for  $^{235}\text{U}$  in the Resolved-Resonance Region,” Oak Ridge National Laboratory, PHYSOR 2006, September 2006
- [50] M. HERMAN, *et al*, “Fast Neutron Covariances for Evaluated Data Files,” Brookhaven National Laboratory, BNL-75893-2006-CP, May 2006

## **Vita**

Christopher van der Hoeven is the son of Guido and Emily van der Hoeven. He attended North Raleigh Christian Academy of Raleigh, NC, and upon graduation 2003 enrolled in the Nuclear Engineering program at Texas A&M University in College Station, TX. Graduating in December of 2007, Christopher next attended the University of Texas at Austin in the Mechanical Engineering graduate program.. During his graduate career he completed research internships at Sandia National Laboratory, the Y-12 National Security Complex, and Oak Ridge National Laboratory. After earning his M.S.E in December of 2009, Christopher continued in the Mechanical Engineering graduate program to complete his Doctorate of Philosophy in 2013.

Permanent address (or email): [cvanderh@gmail.com](mailto:cvanderh@gmail.com)

This dissertation was typed by the author.